

SERVICE BULLETIN

from: TRIO-KENWOOD COMMUNICATIONS, INC.

R-1000

#823

SUBJECT: R-1000 RF ATTENUATOR 10dB STEP OPTION

DATE 4/22/80

The RF Attenuator may be converted from the standard 20dB step to 10dB step by replacing resistors on the RX unit X55-1250-00.

REPLACE	WITH	TYPE
R1	No change	
2	R3 1.2KΩ	R (Radial)
3	1.8ΚΩ	R
4	R7 1.2KΩ	A (Axial)
5	4.7ΚΩ	A
6	15ΚΩ	R
7	1.8ΚΩ	A
8	1.2ΚΩ	R
9	No Change	•
10	R16 56Ω	A
11	No Change	
12	100 Ω	R
13	68 Ω	A
14	R13 220 Ω	Α
15	820 Ω	A
16	100 Ω	Α
17	No Change	
18	R12 56Ω	R

NOTE: How to Solder on the PC Board.

- 1. Use a LOW POWER PENCIL, 35W or less.
- 2. Use rosin core solder, small diameter.
- 3. Do NOT create solder bridges or splotches.
- 4. Do NOT overheat or otherwise lift the foil from the board.
- 5. Wash excess flux away with FRESH trichlor. and a small flux brush. Neatness counts It's YOUR radio.

JEB/yn