


NOTE: This assemby step is for generic brand pulleys only. If you are using genuine Gates brand pulleys, skip this page and see the next page.


В

Note the plate orientation!

This side is short. This side is long.

Top View





В

Assembled View

	1	1 M3 Standoff, 20mm long, 6mm wide	
	2 M4 Shoulder Screw, 25mm long 3 M3 Buttonhead Screw, 8mm long		1
			2
	4	M5 Shim, 0.2mm thick, 7mm OD	4
	5	20T Idler pulley, 2GT, 5mm bore	2
	6	M5 Washer, 0.8-1.2mm thick	2

DESCRIPTION

Left Corner Generic Pulley Assembly Created by: last edited: Joshua Vasquez 5/31/2020

SCALE: 1:1 SHEET 2 OF 7

ITEM NO.

7

Left Corner Pulley Reinforcement Plate

NOTE: This assemby step is for **Gates** brand pulleys only. If you are using **generic** brand pulleys, skip this page and see the previous page.


В


Note the plate orientation!


This side is short.

This side is long.


Top View







Exploded View



В

Assembled View

A


ITEM NO.	DESCRIPTION	QTY.
1	M3 Standoff, 20mm long, 6mm wide	2
2	M4 Shoulder Screw, 25mm long	1
3	M3 Buttonhead Screw, 8mm long	2
4	M5 Shim, 0.2mm thick, 7mm OD	2
5	20T Idler pulley, 2GT, 5mm bore	2
6	Left Corner Pulley Reinforcement Plate	1


Left Corner Gates Pulley Assembly				
© BY	Created by: Joshua Vasquez	last edited: 5/31/2020		
	SCALE: 1:1	SHEET 3 OF 7		

2

•







Assembled View



ITEM NO. DESCRIPTION		
1	1 Left Corner Plate with Insert Installed	
5 M3 Buttonhead Screw, 10mm long		2
6 M5 Buttonhead Screw, 20mm long		3
9 M5 Drop-In T-Nut for 20x20 Extrusion		3
11 Left Corner Pulley Reinforcement Plate		1

В


	Created by:	last edited:
CC BY	Joshua Vasquez	5/31/2020
	SCALE: 1:1	SHEET 4 OF 7

2


.

NOTE: This assemby step is for **generic** brand pulleys only. If you are using genuine **Gates** brand pulleys, skip this page and see the next page.


Top View В



Note the plate orientation! Also note that this orientation is different from the prior pulley assembly.



Exploded View



В

Assembled View


ITEM NO.	DESCRIPTION	
1	M3 Standoff, 20mm long, 6mm wide	2
2	M4 Shoulder Screw, 25mm long	1
3	20T Idler pulley, 2GT, 5mm bore	2
4	M5 Shim, 0.2mm thick, 7mm OD	4
5	M3 Buttonhead Screw, 8mm long	2
6	M5 Washer, 0.8-1.2mm thick	2
7	Left Corner Pulley Reinforcement Plate	1

Right Corner Generic Pulley Assembly


	Created by:	last edited:
CCC BY	Joshua Vasquez	5/31/2020
	SCALE: 1:1	SHEET 5 OF 7

NOTE: This assemby step is for Gates brand pulleys only. If you are using generic brand pulleys, skip this page and see the previous page.


B Top View



Note the plate orientation! Also note that this orientation is different from the prior pulley assembly.



Exploded View



В

Assembled View


ITEM NO.	DESCRIPTION	QTY.
1	M3 Standoff, 20mm long, 6mm wide	2
2	M4 Shoulder Screw, 25mm long	1
3	M5 Shim, 0.2mm thick, 7mm OD	2
4	20T Idler pulley, 2GT, 5mm bore	2
5	Left Corner Pulley Reinforcement Plate	1
6	M3 Buttonhead Screw, 8mm long	2


Right Corner Gates Pulley Assembly				
© BY	Created by: Joshua Vasquez	last edited: 5/31/2020		
	SCALE: 1:1	SHEET 6 OF 7		

A

2

•





Assembled View

Exploded View

ITEM NO. DESCRIPTION		
1	Right Corner Plate with Insert Installed	1
3	Right Corner Pulley Assembly	1
5	M3 Buttonhead Screw, 10mm long	2
7	M5 Buttonhead Screw, 20mm long	3
9	M5 Drop-In T-Nut for 20x20 Extrusion	3

Right Corner Pulley Plate Assembly				
60	(i)	Created by:	last edited:	
	BY	Joshua Vasquez	5/31/2020	
		SCALE: 1:1	SHEET 7 OF 7	

.

В

2

•