EXACT SIZE: outer box 43 × 35 × 33 mm | sticker surfaces only

These decals fit the OUTSIDE of your box. Dry-fit and align before peeling.



FRONT

43 × 35 mm / OLED

BACK

43 × 35 mm

RIGHT SIDE / USB-C

33 × 35 mm

LEFT SIDE

33 × 35 mm

TOP / KEYRING

43 × 33 mm



BOTTOM / BUTTON

43 × 33 mm

HOLE / CUTOUT NOTES

PINK DOTTED LINE

= tentative opening.

OLED window 27 × 16 mm

Check screen + PCB first.

USB and button holes:

mark using real parts.

Do not rely on image

measurements alone.

BLUE/YELLOW graphics

are PRINTED accents.

Button is underneath.

USB-C is RIGHT side.

Keyring requires a

reinforced metal eyelet.

PRINT CALIBRATION — measure after printing



50 mm (must measure exactly 5.0 cm)

PRINT 100% / ACTUAL SIZE / NO FIT-TO-PAGE

Use matte sticker paper. Keep all printed design elements inside their black panel outlines.

IMPORTANT: If printed via Canva, export as PDF Print and check the 50 mm line again.