

Applications Group: (847) 600-8440

Fax: (847) 600-8444


Shure Inc. 5800 Touhy Ave Niles, IL 60714 USA

MICROPHONES AND ELECTRONIC COMPONENTS

Using the P4800 with AMX / Crestron Systems


Wiring


The P4800 uses a standard 7 wire RS-232 port for control. Crestron and AMX controllers use 5 wire RS-232. In order to use a P4800 with Crestron or AMX, a custom cable will need to be built. The following diagram shows the cable. For a 5 volt supply, the resistor should be 1kohms.



All wires are straight through. The 9 pin connectors have numbers stamped on them. Follow those stamped numbers for the pin out. Connect the RX, TX, GND, RTS, and CTS to the five wire RS-232 port on the control unit. The P4800 requires a voltage of 5 to 12 volts on the DTR line. This voltage tells the microprocessor to accept any data that it receives on the TX line.

Computer Interface - RS232 Pinout








Table 1, RS-232 Pinout

P4800	COMPUTER	PIN#
_		1
TX	RX	2
RX	TX	3
DTR	DTR	4
GND	GND	5
DSR	DSR	6
RTS	RTS	7
CTS	CTS	8
_	_	9

Specifications

Baud: 19200
Data bits: 8
Stop bits: 1
Parity: none
Flow control: none

Page 1 6/15/04 RW

P4800 RS232 Commands

CHANGING PRESETS	
CHANGE SETTINGS ON P4800	4
Inputs – Change Setting	
Mute	
Polarity	
+4/-10 scaling	
Volume control	
Outputs - Change Settings	6
Mute	6
Polarity	6
+4/-10 scaling	
Output Pad (-20 dB)	
Volume Control	8
Matrix Mixer – Change Settings	
Mute – Mixpoint	
Mute – Mixer Output	
Polarity – Mixpoint	
Polarity – Mixer Output	
Volume Control – Mixpoint	
Volume Control – Mixer Output	
Activate Mixpoint (route an input to an output)	13
QUERYING THE P4800 TO FIND OUT ITS SETTINGS	
Inputs – Query Settings	
Mute	14
Polarity	
+4/-10 scaling	14
Volume setting	15
Outputs – Query Settings	
Mute	
Polarity	16
+4/-10 scaling	16
Output Pad (-20 dB)	
Volume setting	
Matrix Mixer – Query Settings	
Mute – Mixpoint	
Mute – Mixer Output	
Polarity – Mixpoint	
Polarity – Mixer Output	18
Volume Control – Mixpoint	
Volume Control – Mixer Output	19
Activate Mixpoint (route an input to an output)	19

CHANGING PRESETS

The format to change presets is as follows:

C*n*h *pp*h

Where n is the device ID set via the DIP switches on the P4800 unit (0 to 15), and pp is the preset number minus one. pp has a range from 0 to 127.

For example, if the P4800 is set to device ID 15 and preset #3 is desired, the string would look like:

AMX:

SEND_STRING P4800, "\$CF,\$02"

Crestron (SIMPL):

\XCF\X02

Once the command is sent, the P4800 will echo the command and then send a return string to acknowledge the change.

CHANGE SETTINGS ON P4800

Note: <Device ID> is a hexadecimal number ranging from 00h to 0Fh. This number should match the DIP switch setting on the back of the P4800. Once a command is sent, the P4800 will echo the command and then send a return string to acknowledge the change. The return strings can be seen in the Query section of this white paper.

Inputs - Change Setting

<u>Mute</u>

Toggle Mute

Input 1:	F0h 00h 01h 00h <device id=""> 0Ah 69h 06h 00h 04h 00h F7h</device>
Input 2:	F0h 00h 01h 00h <device id=""> 0Ah 69h 06h 00h 05h 00h F7h</device>
Input 3:	F0h 00h 01h 00h <device id=""> 0Ah 69h 06h 00h 06h 00h F7h</device>
Input 4:	F0h 00h 01h 00h <device id=""> 0Ah 69h 06h 00h 07h 00h F7h</device>

Force Mute

Input 1:	F0h 00h 01h 00h <device id=""> 0Ah 69h 01h 00h 04h 7Fh F7h</device>
Input 2:	F0h 00h 01h 00h <device id=""> 0Ah 69h 01h 00h 05h 7Fh F7h</device>
Input 3:	F0h 00h 01h 00h <device id=""> 0Ah 69h 01h 00h 06h 7Fh F7h</device>
Input 4:	F0h 00h 01h 00h <device id=""> 0Ah 69h 01h 00h 07h 7Fh F7h</device>

Force Unmute

Input 1:	F0h 00h 01h 00h <device id=""> 0Ah 69h 01h 00h 04h 00h F7h</device>
Input 2:	F0h 00h 01h 00h <device id=""> 0Ah 69h 01h 00h 05h 00h F7h</device>
Input 3:	F0h 00h 01h 00h <device id=""> 0Ah 69h 01h 00h 06h 00h F7h</device>
Input 4:	F0h 00h 01h 00h <device id=""> 0Ah 69h 01h 00h 07h 00h F7h</device>

Polarity

Toggle Polarity

Input 1:	F0h 00h 01h 00h <device id=""> 0Ah 69h 06h 00h 08h 00h F7h</device>
Input 2:	F0h 00h 01h 00h <device id=""> 0Ah 69h 06h 00h 09h 00h F7h</device>
Input 3:	F0h 00h 01h 00h <device id=""> 0Ah 69h 06h 00h 0Ah 00h F7h</device>
Input 4:	F0h 00h 01h 00h <device id=""> 0Ah 69h 06h 00h 0Bh 00h F7h</device>

Force Polarity (+)

Input 1:	F0h 00h 01h 00h <device id=""> 0Ah 69h 01h 00h 08h 00h F7h</device>
Input 2:	F0h 00h 01h 00h <device id=""> 0Ah 69h 01h 00h 09h 00h F7h</device>
Input 3:	F0h 00h 01h 00h <device id=""> 0Ah 69h 01h 00h 0Ah 00h F7h</device>
Input 4:	F0h 00h 01h 00h <device id=""> 0Ah 69h 01h 00h 0Bh 00h F7h</device>

Force Polarity (-)

Input 1:	F0h 00h 01h 00h <device id=""> 0Ah 69h 01h 00h 08h 7Fh F7h</device>
Input 2:	F0h 00h 01h 00h <device id=""> 0Ah 69h 01h 00h 09h 7Fh F7h</device>
Input 3:	F0h 00h 01h 00h <device id=""> 0Ah 69h 01h 00h 0Ah 7Fh F7h</device>
Input 4:	F0h 00h 01h 00h <device id=""> 0Ah 69h 01h 00h 0Bh 7Fh F7h</device>

+4/-10 scaling

Toggle

Input 1:	F0h 00h 01h 00h <device id=""> 0Ah 69h 06h 00h 0Ch 00h F7h</device>
Input 2:	F0h 00h 01h 00h <device id=""> 0Ah 69h 06h 00h 0Dh 00h F7h</device>
Input 3:	F0h 00h 01h 00h <device id=""> 0Ah 69h 06h 00h 0Eh 00h F7h</device>
Input 4:	F0h 00h 01h 00h <device id=""> 0Ah 69h 06h 00h 0Fh 00h F7h</device>

Force +4 dBu scaling

Input 1:	F0h 00h 01h 00h <device id=""> 0Ah 69h 01h 00h 0Ch 00h F7h</device>
Input 2:	F0h 00h 01h 00h <device id=""> 0Ah 69h 01h 00h 0Dh 00h F7h</device>
Input 3:	F0h 00h 01h 00h <device id=""> 0Ah 69h 01h 00h 0Eh 00h F7h</device>
Input 4:	F0h 00h 01h 00h <device id=""> 0Ah 69h 01h 00h 0Fh 00h F7h</device>

Force -10 dBV scaling

```
Input 1: F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 00h 0Ch 7Fh F7h F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 00h 0Dh 7Fh F7h F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 00h 0Eh 7Fh F7h F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 00h 0Fh 7Fh F7h F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 00h 0Fh 7Fh F7h
```

Volume control

Set volume to a specific value

```
Input 1: F0h 00h 01h 00h <Device ID> 0Ah 69h 00h 00h 00h <VA> F7h Input 2: F0h 00h 01h 00h <Device ID> 0Ah 69h 00h 00h 01h <VA> F7h Input 3: F0h 00h 01h 00h <Device ID> 0Ah 69h 00h 00h 02h <VA> F7h F0h 00h 01h 00h <Device ID> 0Ah 69h 00h 00h 03h <VA> F7h
```

```
where, <VA> = [ 2 * (Control Setting) ] & 7Fh
```

i.e., multiply the control setting by 2 and then logically AND that product with 7Fh.

The valid range for "Control Setting" is (-30) to (30). Each integer increase (or decrease) in the Control Setting is equal to 1 dB change.

Increase/Decrease volume by a relative amount

```
Input 1: F0h 00h 01h 00h <Device ID> 0Ah 69h 04h 00h 00h <VA> F7h F0h 00h 01h 00h <Device ID> 0Ah 69h 04h 00h 01h <VA> F7h F0h 00h 01h 00h <Device ID> 0Ah 69h 04h 00h 02h <VA> F7h F0h 00h 01h 00h <Device ID> 0Ah 69h 04h 00h 03h <VA> F7h F0h 00h 01h 00h <Device ID> 0Ah 69h 04h 00h 03h <VA> F7h
```

```
where, \langle VA \rangle = [2 * (dB Change)] \& 7Fh
```

i.e., multiply the amount of change (in dB) by 2 and then logically AND that product with 7Fh. For example, to decrease the volume by 2 dB:

```
<VA> = [2 * (-2)] & 7Fh
<VA> = [-4] & 7Fh
<VA> = 7Ch
```

It is not necessary to calculate this equation by hand. Both AMX and Crestron can be programmed to calculate this equation.

Outputs - Change Settings

Mute

Toggle mute

F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 46h 00h F7h Output 1: Output 2: F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 47h 00h F7h Output 3: F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 48h 00h F7h Output 4: F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 49h 00h F7h Output 5: F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 4Ah 00h F7h F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 4Bh 00h F7h Output 6: F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 4Ch 00h F7h Output 7: Output 8: F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 4Dh 00h F7h

Force mute

Output 1: F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 46h 7Fh F7h F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 47h 7Fh F7h Output 2: Output 3: F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 48h 7Fh F7h Output 4: F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 49h 7Fh F7h Output 5: F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 4Ah 7Fh F7h Output 6: F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 4Bh 7Fh F7h F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 4Ch 7Fh F7h Output 7: Output 8: F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 4Dh 7Fh F7h

Force unmute

Output 1: F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 46h 00h F7h Output 2: F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 47h 00h F7h Output 3: F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 48h 00h F7h Output 4: F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 49h 00h F7h Output 5: F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 4Ah 00h F7h Output 6: F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 4Bh 00h F7h Output 7: F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 4Ch 00h F7h Output 8: F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 4Dh 00h F7h

Polarity

Toggle polarity

Output 1: F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 4Eh 00h F7h Output 2: F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 4Fh 00h F7h Output 3: F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 50h 00h F7h Output 4: F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 51h 00h F7h Output 5: F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 52h 00h F7h Output 6: F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 53h 00h F7h Output 7: F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 55h 00h F7h Output 8: F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 55h 00h F7h

Force polarity (+)

```
Output 1:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 4Eh 00h F7h
Output 2:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 4Fh 00h F7h
Output 3:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 50h 00h F7h
Output 4:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 51h 00h F7h
Output 5:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 52h 00h F7h
Output 6:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 53h 00h F7h
Output 7:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 55h 00h F7h
Output 8:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 55h 00h F7h
```

Force polarity (-)

```
Output 1:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 4Eh 7Fh F7h
Output 2:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 4Fh 7Fh F7h
Output 3:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 50h 7Fh F7h
Output 4:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 51h 7Fh F7h
Output 5:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 52h 7Fh F7h
Output 6:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 53h 7Fh F7h
Output 7:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 55h 7Fh F7h
Output 8:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 55h 7Fh F7h
```

+4/-10 scaling

Toggle scaling

Output 1:	F0h 00h 01h 00h <device id=""> 0Ah 69h 06h 03h 56h 00h F7h</device>
Output 2:	F0h 00h 01h 00h <device id=""> 0Ah 69h 06h 03h 57h 00h F7h</device>
Output 3:	F0h 00h 01h 00h <device id=""> 0Ah 69h 06h 03h 58h 00h F7h</device>
Output 4:	F0h 00h 01h 00h <device id=""> 0Ah 69h 06h 03h 59h 00h F7h</device>
Output 5:	F0h 00h 01h 00h <device id=""> 0Ah 69h 06h 03h 5Ah 00h F7h</device>
Output 6:	F0h 00h 01h 00h <device id=""> 0Ah 69h 06h 03h 5Bh 00h F7h</device>
Output 7:	F0h 00h 01h 00h <device id=""> 0Ah 69h 06h 03h 5Ch 00h F7h</device>
Output 8:	F0h 00h 01h 00h <device id=""> 0Ah 69h 06h 03h 5Dh 00h F7h</device>

Force +4 dBu scaling

```
F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 56h 00h F7h
Output 1:
Output 2:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 57h 00h F7h
Output 3:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 58h 00h F7h
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 59h 00h F7h
Output 4:
Output 5:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 5Ah 00h F7h
Output 6:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 5Bh 00h F7h
Output 7:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 5Ch 00h F7h
Output 8:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 5Dh 00h F7h
```

Force -10 dBV scaling

```
Output 1:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 56h 7Fh F7h
Output 2:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 57h 7Fh F7h
Output 3:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 58h 7Fh F7h
Output 4:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 59h 7Fh F7h
Output 5:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 5Ah 7Fh F7h
Output 6:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 5Bh 7Fh F7h
Output 7:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 5Ch 7Fh F7h
Output 8:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 5Dh 7Fh F7h
```

Output Pad (-20 dB)

Toggle pad

```
F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 5Eh 00h F7h
Output 1:
Output 2:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 5Fh 00h F7h
Output 3:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 60h 00h F7h
Output 4:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 61h 00h F7h
Output 5:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 62h 00h F7h
Output 6:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 63h 00h F7h
Output 7:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 64h 00h F7h
Output 8:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 03h 65h 00h F7h
```

Force pad off

```
Output 1:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 5Eh 00h F7h
Output 2:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 5Fh 00h F7h
Output 3:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 60h 00h F7h
Output 4:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 61h 00h F7h
Output 5:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 62h 00h F7h
Output 6:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 63h 00h F7h
Output 7:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 64h 00h F7h
Output 8:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 65h 00h F7h
```

Force pad on

```
Output 1:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 5Eh 7Fh F7h
Output 2:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 5Fh 7Fh F7h
Output 3:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 60h 7Fh F7h
Output 4:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 61h 7Fh F7h
Output 5:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 62h 7Fh F7h
Output 6:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 63h 7Fh F7h
Output 7:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 64h 7Fh F7h
Output 8:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 03h 65h 7Fh F7h
```

Volume Control

Set volume to a specific value

```
Output 1:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 00h 03h 3Eh <VA> F7h
Output 2:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 00h 03h 3Fh <VA> F7h
Output 3:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 00h 03h 40h <VA> F7h
Output 4:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 00h 03h 41h <VA> F7h
Output 5:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 00h 03h 42h <VA> F7h
Output 6:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 00h 03h 43h <VA> F7h
Output 7:
           F0h 00h 01h 00h <Device ID> 0Ah 69h 00h 03h 44h <VA> F7h
Output 8:
          F0h 00h 01h 00h <Device ID> 0Ah 69h 00h 03h 45h <VA> F7h
```

where, $\langle VA \rangle = [2 * (Control Setting)] \& 7Fh$

i.e., multiply the control setting by 2 and then logically AND that product with 7Fh.

The valid range for "Control Setting" is (-30) to (30). Each integer increase (or decrease) in the Control Setting is equal to 1 dB change.

Increase/Decrease volume by a relative amount

```
Output 1: F0h 00h 01h 00h <Device ID> 0Ah 69h 04h 03h 3Eh <VA> F7h Output 2: F0h 00h 01h 00h <Device ID> 0Ah 69h 04h 03h 3Fh <VA> F7h Output 3: F0h 00h 01h 00h <Device ID> 0Ah 69h 04h 03h 40h <VA> F7h Output 4: F0h 00h 01h 00h <Device ID> 0Ah 69h 04h 03h 41h <VA> F7h Output 5: F0h 00h 01h 00h <Device ID> 0Ah 69h 04h 03h 42h <VA> F7h Output 6: F0h 00h 01h 00h <Device ID> 0Ah 69h 04h 03h 43h <VA> F7h Output 7: F0h 00h 01h 00h <Device ID> 0Ah 69h 04h 03h 44h <VA> F7h F0h 00h 01h 00h <Device ID> 0Ah 69h 04h 03h 44h <VA> F7h F0h 00h 01h 00h <Device ID> 0Ah 69h 04h 03h 45h <VA> F7h
```

where, $\langle VA \rangle = [2 * (dB Change)] \& 7Fh$

i.e., multiply the amount of change (in dB) by 2 and then logically AND that product with 7Fh. For example, to decrease the volume by 2 dB:

$$= [2 * (-2)] & 7Fh$$

 $= [-4] & 7Fh$
 $= 7Ch$

It is not necessary to calculate this equation by hand. Both AMX and Crestron can be programmed to calculate this equation.

Matrix Mixer - Change Settings

The matrix mixer signal processor in the P4800 unit has 4 inputs and N outputs (NOUTPUTS). When there is no cross over processor or splitter in the preset, N is 8, i.e. a 4 x 8 mixer. If there is a cross over or splitter, N is reduced by the number of cross over/splitter channels minus one.

For example: One 3-way cross over in the preset makes the matrix mixer a 4 x 6 mixer.

NMIXPOINTS is defined as: NMIXPOINTS = 4 * NOUTPUTS

Therefore, a 4 x 8 mixer has 32 mixpoints (NMIXPOINTS=32), a 4x6 has 24 mixpoints (NMIXPOINTS=24).

Mix Point 1 gain is input channel 1 gain for matrix mixer output 1

Mix Point 2 gain is input channel 2 gain for matrix mixer output 1

Mix Point 3 gain is input channel 3 gain for matrix mixer output 1

Mix Point 4 gain is input channel 4 gain for matrix mixer output 1

Mix Point 5 gain is input channel 1 gain for matrix mixer output 2 Etc.

Mute - Mixpoint

Note: $\langle ID \rangle = NMIXPOINTS + 15 + (Mix Point #)$

Toggle Mute

F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 00h <ID> 00h F7h

Force Mute

F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 00h <ID> 7Fh F7h

Force Unmute

F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 00h <ID> 00h F7h

Mute - Mixer Output

Note: The <IDMSB> and <IDLSB> values must be calculated as follows:

```
<IDMSB> = [((4 * NMIXPOINTS) + NOUTPUTS + 15 + (NOutput #)) >> 7] & 7Fh
<IDLSB> = ((4 * NMIXPOINTS) + NOUTPUTS + 15 + (NOutput #)) & 7Fh
```

where ">> 7" means right shift by 7 bits and "&" denotes logical AND.

Toggle Mute (BUG – DOES NOT WORK)

F0h 00h 01h 00h <Device ID> 0Ah 69h 06h <IDMSB> <IDLSB> 00h F7h

Force Mute

F0h 00h 01h 00h <Device ID> 0Ah 69h 01h <IDMSB <IDLSB> 7Fh F7h

Force Unmute

F0h 00h 01h 00h <Device ID> 0Ah 69h 01h <IDMSB> <IDLSB> 00h F7h

Polarity - Mixpoint

Note: $\langle ID \rangle = (2 * NMIXPOINTS) + 15 + (Mix Point #)$

Toggle Polarity

F0h 00h 01h 00h <Device ID> 0Ah 69h 06h 00h <ID> 00h F7h

Force Polarity (+)

F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 00h <ID> 00h F7h

Force Polarity (-)

F0h 00h 01h 00h <Device ID> 0Ah 69h 01h 00h <ID> 7Fh F7h

Polarity - Mixer Output

Note: The <IDMSB> and <IDLSB> values must be calculated as follows:

```
<IDMSB> = [((4 * NMIXPOINTS) + (2 * NOUTPUTS) + 15 + (NOutput #)) >> 7] & 7Fh < IDLSB> = ((4 * NMIXPOINTS) + (2 * NOUTPUTS) + 15 + (NOutput #)) & 7Fh
```

where ">> 7" means right shift by 7 bits and "&" denotes logical AND.

Toggle Polarity (BUG – DOES NOT WORK)

F0h 00h 01h 00h <Device ID> 0Ah 69h 06h <IDMSB> <IDLSB> 00h F7h

Force Polarity (+)

F0h 00h 01h 00h <Device ID> 0Ah 69h 01h <IDMSB> <IDLSB> 00h F7h

Force Polarity (-)

F0h 00h 01h 00h <Device ID> 0Ah 69h 01h <IDMSB> <IDLSB> 7Fh F7h

Volume Control – Mixpoint

Note: $\langle ID \rangle = (Mix Point \#) + 15$

Set volume to a specific value

F0h 00h 01h 00h <Device ID> 0Ah 69h 00h 00h <ID> <VA> F7h

where, <VA> = (Control Setting) & 7Fh i.e., logically AND the control setting with 7Fh.

The valid range for "Control Setting" is (0) to (127) from the following table.

Control Setting		
<va></va>	Gain value (dB)	
0	-Infinity	
1-26	-105 to -42.5,	
	in 2.5 dB steps	
27-127	-40.0 to +10.0,	
	in 0.5 dB steps	

Increase/Decrease volume by a relative amount

F0h 00h 01h 00h <Device ID> 0Ah 69h 05h 00h <ID> <VA> F7h

where, $\langle VA \rangle = [2 * (dB Change)] \& 7Fh$

i.e., multiply the amount of change (in dB) by 2 and then logically AND that product with 7Fh.

Volume Control – Mixer Output

Note: The <IDMSB> and <IDLSB> values must be calculated as follows:

<IDMSB> = [((4 * NMIXPOINTS) + 15 + (NOutput #)) >> 7] & 7Fh <IDLSB> = ((4 * NMIXPOINTS) + 15 + (NOutput #)) & 7Fh

where ">> 7" means right shift by 7 bits and "&" denotes logical AND.

Set volume to a specific value

F0h 00h 01h 00h <Device ID> 0Ah 69h 00h <IDMSB> <IDLSB> <VA> F7h

where, <VA> = (Control Setting) & 7Fh i.e., logically AND the control setting with 7Fh.

The valid range for "Control Setting" is (0) to (127) from the following table.

Control Setting	
<u><va></va></u>	Gain value (dB)
0	-Infinity
1-26	-105 to -42.5,
	in 2.5 dB steps
27-127	-40.0 to +10.0,
	in 0.5 dB steps

Increase/Decrease volume by a relative amount (BUG - DOES NOT WORK)

F0h 00h 01h 00h <Device ID> 0Ah 69h 05h <IDMSB> <IDLSB> <VA> F7h

where, $\langle VA \rangle = [2 * (dB Change)] \& 7Fh$

i.e., multiply the amount of change (in dB) by 2 and then logically AND that product with 7Fh.

Activate Mixpoint (route an input to an output)

Note: The <IDMSB> and <IDLSB> values must be calculated as follows:

$$\langle IDMSB \rangle = [((3 * NMIXPOINTS) + 15 + (Mix Point #)) \rangle 7] \& 7Fh < IDLSB \rangle = ((3 * NMIXPOINTS) + 15 + (Mix Point #)) & 7Fh$$

where ">> 7" means right shift by 7 bits and "&" denotes logical AND.

Toggle Activation (BUG - DOES NOT WORK)

F0h 00h 01h 00h <Device ID> 0Ah 69h 06h <IDMSB> <IDLSB> 00h F7h

Force Activation

F0h 00h 01h 00h <Device ID> 0Ah 69h 01h <IDMSB> <IDLSB> 7Fh F7h

Force Deactivation

F0h 00h 01h 00h <Device ID> 0Ah 69h 01h <IDMSB> <IDLSB> 00h F7h

QUERYING THE P4800 TO FIND OUT ITS SETTINGS

The following list of commands can be sent to the P4800 to query the status of its settings. After the query command is sent, the P4800 will first send an echo of the query command and then it will send a return string with the status of the particular setting.

Inputs - Query Settings

Mute

Note: <VA> equals 00h when the input is unmuted and equals 7Fh when the input is muted.

Input 1:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 00h 04h F7h</device>
•	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 00h 04h <va> 00h F7h</va></device>
Input 2:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 00h 05h F7h</device>
•	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 00h 05h <va> 00h F7h</va></device>
Input 3:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 00h 06h F7h</device>
•	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 00h 06h <va> 00h F7h</va></device>
Input 4:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 00h 07h F7h</device>
•	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 00h 07h <va> 00h F7h</va></device>

Polarity

Note: <VA> equals 00h when the input is (+) polarity and equals 01h when the input is (-) polarity.

Input 1:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 00h 08h F7h</device>
-	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 00h 08h <va> 00h F7h</va></device>
Input 2:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 00h 09h F7h</device>
-	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 00h 09h <va> 00h F7h</va></device>
Input 3:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 00h 0Ah F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 00h 0Ah <va> 00h F7h</va></device>
Input 4:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 00h 0Bh F7h</device>
•	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 00h 0Bh <va> 00h F7h</va></device>

+4/-10 scaling

Note: <VA> equals 00h when the input is +4 dBu scaling and equals 01h when the input is -10 dBV scaling.

Input 1:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 00h 0Ch F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 00h 0Ch <va> 00h F7h</va></device>
Input 2:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 00h 0Dh F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 00h 0Dh <va> 00h F7h</va></device>
Input 3:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 00h 0Eh F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 00h 0Eh <va> 00h F7h</va></device>
Input 4:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 00h 0Fh F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 00h 0Fh <va> 00h F7h</va></device>

Volume setting

Note: <VA> equals an integer from -60 to +60. Divide <VA> by 2 to get to a dB scale.

Input 1:	Query command: Return string:	F0h 00h 01h 00h <device id=""> 0Ah 70h 00h 00h F7h F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 00h 00h <va> 00h F7h</va></device></device>
Input 2:	Query command:	Foh 00h 01h 00h < Device ID > 0Ah 70h 00h 01h F7h
iliput 2.	Return string:	Foh 00h 01h 00h < Device ID + 10h > 0Ah 00h 00h 01h < VA > 00h F7h
Innut O		
Input 3:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 00h 02h F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 00h 02h <va> 00h F7h</va></device>
Input 4:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 00h 03h F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 00h 03h <va> 00h F7h</va></device>

Outputs - Query Settings

<u>Mute</u>

Note: <VA> equals 00h when the output is unmuted and equals 7Fh when the output is muted.

Output 1:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 46h F7h</device>
'	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 46h <va> 00h F7h</va></device>
Output 2:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 47h F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 47h <va> 00h F7h</va></device>
Output 3:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 48h F7h</device>
•	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 48h <va> 00h F7h</va></device>
Output 4:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 49h F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 49h <va> 00h F7h</va></device>
Output 5:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 4Ah F7h</device>
-	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 4Ah <va> 00h F7h</va></device>
Output 6:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 4Bh F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 4Bh <va> 00h F7h</va></device>
Output 7:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 4Ch F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 4Ch <va> 00h F7h</va></device>
Output 8:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 4Dh F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 4Dh <va> 00h F7h</va></device>

Polarity

Note: <VA> equals 00h when the output is (+) polarity and equals 01h when the output is (-) polarity.

Output 1:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 4Eh F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 4Eh <va> 00h F7h</va></device>
Output 2:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 4Fh F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 4Fh <va> 00h F7h</va></device>
Output 3:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 50h F7h</device>
·	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 50h <va> 00h F7h</va></device>
Output 4:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 51h F7h</device>
·	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 51h <va> 00h F7h</va></device>
Output 5:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 52h F7h</device>
·	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 52h <va> 00h F7h</va></device>
Output 6:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 53h F7h</device>
·	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 53h <va> 00h F7h</va></device>
Output 7:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 54h F7h</device>
·	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 54h <va> 00h F7h</va></device>
Output 8:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 55h F7h</device>
•	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 55h <va> 00h F7h</va></device>

+4/-10 scaling

Note: <VA> equals 00h when the output is +4 dBu scaling and equals 01h when the output is -10 dBV scaling.

Output 1:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 56h F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 56h <va> 00h F7h</va></device>
Output 2:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 57h F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 57h <va> 00h F7h</va></device>
Output 3:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 58h F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 58h <va> 00h F7h</va></device>
Output 4:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 59h F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 59h <va> 00h F7h</va></device>

Output 5:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 5Ah F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 5Ah <va> 00h F7h</va></device>
Output 6:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 5Bh F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 5Bh <va> 00h F7h</va></device>
Output 7:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 5Ch F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 5Ch <va> 00h F7h</va></device>
Output 8:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 5Dh F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 5Dh <va> 00h F7h</va></device>

Output Pad (-20 dB)

Note: <VA> equals 00h when the output pad is not engaged and equals 01h when the output pad is engaged.

Output 1:	Query command: Return string:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 5Eh F7h F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 5Eh <va> 00h F7h</va></device></device>
Output 2:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 5Fh F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 5Fh <va> 00h F7h</va></device>
Output 3:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 60h F7h</device>
-	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 60h <va> 00h F7h</va></device>
Output 4:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 61h F7h</device>
-	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 61h <va> 00h F7h</va></device>
Output 5:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 62h F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 62h <va> 00h F7h</va></device>
Output 6:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 63h F7h</device>
•	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 63h <va> 00h F7h</va></device>
Output 7:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 64h F7h</device>
-	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 64h <va> 00h F7h</va></device>
Output 8:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 65h F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 65h <va> 00h F7h</va></device>

Volume setting

Note: $\langle VA \rangle$ equals an integer from -60 to +60. Divide $\langle VA \rangle$ by 2 to get to a dB scale.

Output 1:	Query command: Return string:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 3Eh F7h F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 3Eh <va> 00h F7h</va></device></device>
Output 2:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 3Fh F7h</device>
·	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 3Fh <va> 00h F7h</va></device>
Output 3:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 40h F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 40h <va> 00h F7h</va></device>
Output 4:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 41h F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 41h <va> 00h F7h</va></device>
Output 5:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 42h F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 42h <va> 00h F7h</va></device>
Output 6:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 43h F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 43h <va> 00h F7h</va></device>
Output 7:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 44h F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 44h <va> 00h F7h</va></device>
Output 8:	Query command:	F0h 00h 01h 00h <device id=""> 0Ah 70h 03h 45h F7h</device>
	Return string:	F0h 00h 01h 00h <device +="" 10h="" id=""> 0Ah 00h 03h 45h <va> 00h F7h</va></device>

Matrix Mixer - Query Settings

Mute - Mixpoint

Note: <VA> equals 00h when the mixpoint is unmuted and equals 7Fh when the mixpoint is muted.

<ID> = NMIXPOINTS + 15 + (Mix Point #)

Query command: F0h 00h 01h 00h <Device ID> 0Ah 70h 00h <ID> F7h

Return string: F0h 00h 01h 00h <Device ID + 10h> 0Ah 00h 00h <ID> <VA> 00h F7h

<u>Mute – Mixer Output</u>

Note: <VA> equals 00h when the mixer output is unmuted and equals 7Fh when the mixer output is muted.

The <IDMSB> and <IDLSB> values must be calculated as follows:

<IDMSB> = [((4 * NMIXPOINTS) + NOUTPUTS + 15 + (NOutput #)) >> 7] & 7Fh <IDLSB> = ((4 * NMIXPOINTS) + NOUTPUTS + 15 + (NOutput #)) & 7Fh

where ">> 7" means right shift by 7 bits and "&" denotes logical AND.

Query command: F0h 00h 01h 00h <Device ID> 0Ah 70h <IDMSB> <IDLSB> F7h

Return string: F0h 00h 01h 00h <Device ID + 10h> 0Ah 00h <IDMSB> <IDLSB> <VA> 00h F7h

Polarity - Mixpoint

Note: <VA> equals 00h when the mixpoint is (+) polarity and equals 01h when the mixpoint is (-) polarity.

 $\langle ID \rangle = (2 * NMIXPOINTS) + 15 + (Mix Point #)$

Query command: F0h 00h 01h 00h <Device ID> 0Ah 70h 00h <ID> F7h

Return string: F0h 00h 01h 00h <Device ID + 10h> 0Ah 00h 00h <ID> <VA> 00h F7h

Polarity – Mixer Output

Note: <VA> equals 00h when the mixer output is (+) polarity and equals 01h when the mixer output is (-) polarity. The <IDMSB> and <IDLSB> values must be calculated as follows:

 $\langle IDMSB \rangle = [((4 * NMIXPOINTS) + (2 * NOUTPUTS) + 15 + (NOutput #)) \rangle 7] & 7Fh \\ \langle IDLSB \rangle = ((4 * NMIXPOINTS) + (2 * NOUTPUTS) + 15 + (NOutput #)) & 7Fh$

where ">> 7" means right shift by 7 bits and "&" denotes logical AND.

Query command: F0h 00h 01h 00h <Device ID> 0Ah 70h <IDMSB> <IDLSB> F7h

Return string: F0h 00h 01h 00h <Device ID + 10h> 0Ah 00h <IDMSB> <IDLSB> <VA> 00h F7h

Volume Control – Mixpoint

Note: $\langle ID \rangle = (Mix Point \#) + 15$

<VA> equals the settings in the following table.

<u><va></va></u>	Gain value (dB)
0	-Infinity
1-26	-105 to -42.5,
	in 2.5 dB steps
27-127	-40.0 to +10.0,
	in 0.5 dB steps

Query command: F0h 00h 01h 00h <Device ID> 0Ah 70h 00h <ID> F7h

Return string: F0h 00h 01h 00h <Device ID + 10h> 0Ah 00h 00h <ID> <VA> 00h F7h

Volume Control – Mixer Output

Note: The <IDMSB> and <IDLSB> values must be calculated as follows:

<IDMSB> = [((4 * NMIXPOINTS) + 15 + (NOutput #)) >> 7] & 7Fh <IDLSB> = ((4 * NMIXPOINTS) + 15 + (NOutput #)) & 7Fh

where ">> 7" means right shift by 7 bits and "&" denotes logical AND.

<VA> equals the settings in the following table.

<va></va>	Gain value (dB)
0	-Infinity
1-26	-105 to -42.5,
	in 2.5 dB steps
27-127	-40.0 to +10.0,
	in 0.5 dB steps

Query command: F0h 00h 01h 00h <Device ID> 0Ah 70h <IDMSB> <IDLSB> F7h

Return string: F0h 00h 01h 00h <Device ID + 10h> 0Ah 00h <IDMSB> <IDLSB> <VA> 00h F7h

Activate Mixpoint (route an input to an output)

Note: <VA> equals 00h when the mixpoint is not activated and equals 01h when the mixpoint is activated. The <IDMSB> and <IDLSB> values must be calculated as follows:

 $\langle IDMSB \rangle = [((3 * NMIXPOINTS) + 15 + (Mix Point #)) \rangle 7] \& 7Fh$ $\langle IDLSB \rangle = ((3 * NMIXPOINTS) + 15 + (Mix Point #)) \& 7Fh$

where ">> 7" means right shift by 7 bits and "&" denotes logical AND.

Query command: F0h 00h 01h 00h <Device ID> 0Ah 70h <IDMSB> <IDLSB> F7h

Return string: F0h 00h 01h 00h <Device ID + 10h> 0Ah 00h <IDMSB> <IDLSB> <VA> 00h F7h