



A (x2)

FOR
FRONT LEFT




B (x2)

FOR
MIDDLE LEFT




C (x2)

FOR
REAR LEFT



D (x2)

E (x2)
M 10



F
M8 x25 (x2)

M8
(x12)

M8 x25 (x8)
M6 x25 (x2)

M10 (x2)
M8 (x12)
M6 (x2)




M10 (x2)
M8 (x4)





ERKUL®
Products & Quality



RANGE ROVER SPORT 2005-2013 RUNNING BOARD




instructions



FRONT BRACKET



MIDDLE BRACKET



REAR BRACKET