WW.	Environmental Analysis Teaching	Date: 6/12/2017	Number: 70 v0.1
	and Research Laboratory		
POMONA	Standard Operating Procedure	Title: ICP-MS Guide	
POMONA COLLEGE	Approved By: TBD	Revision Date: M	arch 2, 2018

1. Scope and Application

- 1.1 The scope of this SOP is train researchers...
- ${\bf 1.2}$ The applications of this SOP are for...

2. Summary of Method

2.1 This SOP does this...

Contents

1	Scope and Application	1
2	Summary of Method	1
3	Acknowledgements	3
4	Definitions	3
5	Biases and Interferences	3
6	Health and Safety Safety and Personnnel Protective Equipment	3
7	Personnel & Training Responsibilities	3
8	Required Materials and Apparati	3
9	Reagents and Standards	3
10	Consumables	3
11	Estimated Time	4
12	Sample Collection, Preservation, and Storage	4

Author: Marc and Haley
File: ICP-MS Guilde v01.tex

13	Procedure	4
	Set up	4
	Creating a Method	5
	Using Batch Templates	5
	Queue Window	5
	Running a Batch	5
14	Maintenance	5
	Cleaning Nebulizer	5
	Pump Oil	5
	Checking Torch	6
	Sample and Skimmer Cone	6
	Lenses	6
15	Data Analysis and Calculations	7
16	QC/QA Criteria	7
	Tuning	7
	Pulse versus Analog Mode	7
17	Trouble Shooting	7
18	References	7

3. Acknowledgements

4. Definitions

4.1 Term1: is...

5. Biases and Interferences

5.1 Biases and interferences can come from...

6. Health and Safety

6.1 Describe the risk...

Safety and Personnnel Protective Equipment

7. Personnel & Training Responsibilities

- **7.1** Researchers training is required before this the procedures in this method can be used...
- 7.2 Researchers using this SOP should be trained for the following SOPs:
- SOP01 Laboratory Safety
- SOP02 Field Safety

8. Required Materials and Apparati

- **8.1** Item 1 w/catalog number!
- **8.2** Item 2

9. Reagents and Standards

10. Consumables

- Sample Cone
- Skimmer Cone
- peristaltic pumps
- bonnet and quartz stuff
- Pump Oil

Author: Marc and Haley

Page: 3 of 7

11. Estimated Time

- 11.1 This procedure requires XX minutes...
- 12. Sample Collection, Preservation, and Storage
- 13. Procedure

Set up

- 13.1 Option versus Dilution gas
- **13.2** Check tubing, replace drain tubing Monthly.
- 13.3 Check gas supply regulators pressures

Gas	Pressure	Reorder #
Argon	100 psi	??
Oxygen		

- 13.4 Turn on chiller
- 13.5 Open argon valve
- 13.6 Connect drain and sample tubes to peristaltic pump and clamp.
- 13.7 Connect internal standard, should be diluted to 1 ppm or $1\mu/\text{mL}$.
- 13.8 Check Settings, nebulizer, post rotate yes!
- 13.9 Turn on circulate water
- **13.10** Startup Configuration
- **13.11** Instrument set up various tests done that should be checked.
- 13.12 Tuning solutions... Peripump, .5 uL solution.. internal standard concedtration will be... speed to 0.3 because the tube stretches out. Stabilizes to 30s, acquisition speed... probe rinse...
- 13.13 Check Default Standard Setting
- **13.14** P/A solutions
- 13.15 Turn on Plasma Mode
- 13.16 Enable Configure Ignition Sequence is checked for liquid samples

Author: Marc and Haley

13.17 Check meters

IF/Backing Pressure Analyzer Pressure Water Redirected Power Forced Power

13.18

Creating a Method

Using Batch Templates

13.19 Batch Template

Queue Window

- 13.20 Skip Warm-up
- 13.21 check for bubble moving into pump in tube
- **13.22** Autotuning solutions DI water?
- 13.23 Check autoscale on 'Real Time Display'
- 13.24 Check Mainframe performance report, record rsd ¡6 %... check counts... oxides...cerium (mass 140/156) ¡ 2 double charges (mass 70 mass 40...) ¡ 3, high matrix. check resolution axis around 7. peak width about 10%, .65 .8, 6.9

Running a Batch

- **13.25** Prepare . . .
- 13.26

14. Maintenance

Cleaning Nebulizer

- 14.1 Soak components in 5% nitric acid. Do not sonicate the nebularizer.
- 14.2 Neebulizer should be tight.
- 14.3 Replace jacket

Pump Oil

14.4 Replace pump oil every 3-4 months. Pump oil will break down and be the final resting place for all ions.

Author: Marc and Haley

Page: 5 of 7

14.5

Checking Torch

- 14.6 Open cover
- 14.7 Shield can get ugly and needs to be replaced.
- **14.8** Don't seem to worry about finger prints on the outside.
- 14.9 Replace tab and torch bonnet stuff yearly

Sample and Skimmer Cone

- **14.10** Use software to "maintenance" and torch is moved.
- **14.11** Check and potentially Replace cones... depends on sample matrix, often a recently replaced cone are not stable.
- **14.12** Unscrew ring (use tool if needed)
- **14.13** Clean with sonicator, ;?1% citronox dilute.
- **14.14** Use skimmer cone tool and unscrew it.
- **14.15** Be careful of the graphite o-ring
- **14.16** To replace, finger tighten skimmer cone.
- 14.17 Do not use skimmer cone tool until it's been finger threaded.
- 14.18 Replace sample cone
- **14.19** Initialize to put torch back in.
- 14.20 Close cover

Lenses

- 14.21 Using 3mm allen wrench...
- 14.22 Do not touch lens with hands w/o gloves
- 14.23 Loosen and pull them out.
- **14.24** Omega lens...
- **14.25** Cleaned as part of the PM (preventative maintance).

Author: Marc and Haley

- 14.26 Can check lens test via software.
- 15. Data Analysis and Calculations
- 16. QC/QA Criteria

Tuning

Pulse versus Analog Mode

- **16.1** With low concentrations, versus high concetration.
- **16.2** Using P/A solution
- 17. Trouble Shooting
- 18. References
 - **18.1** APHA, AWWA. WEF. (2012) Standard Methods for examination of water and wastewater. 22nd American Public Health Association (Eds.). Washington. 1360 pp. (2014).

https://crustal.usgs.gov/laboratories/icpms/intro.html

Author: Marc and Haley Page: 7 of 7