WW.	Environmental Analysis Teaching	Date: 6/12/2017	Number: 70 v0.1
	and Research Laboratory		
POMONA	Standard Operating Procedure	Title: ICP-MS Guide	
POMONA COLLEGE	Approved By: TBD	Revision Date: M	arch 2, 2018

## 1. Scope and Application

- 1.1 The scope of this SOP is train researchers...
- ${\bf 1.2}$  The applications of this SOP are for...

## 2. Summary of Method

2.1 This SOP does this...

### Contents

1	Scope and Application	1
2	Summary of Method	1
3	Acknowledgements	3
4	Estimated Time	3
5	Definitions	3
6	Notable Biases and Interferences	3
7	Health and Safety Safety and Personnnel Protective Equipment	<b>3</b>
8	Personnel & Training Responsibilities	3
9	Required Materials and Apparati	3
10	Reagents and Standards	3
11	Consumables	3
<b>12</b>	Sample Collection, Preservation, and Storage	4

Author: Marc and Haley
File: ICP-MS Guilde v01.tex

<b>13</b>	Procedure	4
	Set up	4
	Creating a Method	Ę
	Using Batch Templates	
	Queue Window	
	Running a Batch	
14	Maintenance	Ę
	Cleaning Nebulizer	Ę
	Pump Oil	
	Checking Torch	
	Sample and Skimmer Cone	
	Lenses	(
<b>15</b>	Data Analysis and Calculations	7
<b>16</b>	QC/QA Criteria	7
	Tuning	7
	Pulse versus Analog Mode	7
<b>17</b>	Trouble Shooting	7
18	References	7

- 3. Acknowledgements
- 4. Estimated Time
  - **4.1** This procedure requires XX minutes...
- 5. Definitions
  - **5.1** Term1: is...
- 6. Notable Biases and Interferences
- 7. Health and Safety
  - 7.1 Describe the risk...

### Safety and Personnnel Protective Equipment

- 8. Personnel & Training Responsibilities
  - **8.1** Researchers training is required before this the procedures in this method can be used...
  - **8.2** Researchers using this SOP should be trained for the following SOPs:
  - SOP01 Laboratory Safety
  - SOP02 Field Safety
- 9. Required Materials and Apparati
  - **9.1** Item 1 w/catalog number!
  - **9.2** Item 2
- 10. Reagents and Standards
- 11. Consumables
  - 11.1 Biases and interferences can come from...
  - Sample Cone

Author: Marc and Haley

- Skimmer Cone
- peristaltic pumps
- bonnet and quartz stuff
- Pump Oil
- 12. Sample Collection, Preservation, and Storage
- 13. Procedure

Set up

- 13.1 Option versus Dilution gas
- **13.2** Check tubing, replace drain tubing Monthly.
- 13.3 Check gas supply regulators pressures

Gas	Pressure	Reorder #
Argon	100 psi	??
Oxygen		

- 13.4 Turn on chiller
- 13.5 Open argon valve
- 13.6 Connect drain and sample tubes to peristaltic pump and clamp.
- 13.7 Connect internal standard, should be diluted to 1 ppm or  $1\mu/\text{mL}$ .
- 13.8 Check Settings, nebulizer, post rotate yes!
- 13.9 Turn on circulate water
- 13.10 Startup Configuration
- **13.11** Instrument set up various tests done that should be checked.
- 13.12 Tuning solutions... Peripump, .5 uL solution.. internal standard concdetration will be... speed to 0.3 because the tube stretches out. Stabilizes to 30s, acquisition speed... probe rinse...
- 13.13 Check Default Standard Setting
- **13.14** P/A solutions
- 13.15 Turn on Plasma Mode

Author: Marc and Haley

- 13.16 Enable Configure Ignition Sequence is checked for liquid samples
- 13.17 Check meters

IF/Backing Pressure Analyzer Pressure Water Redirected Power Forced Power

13.18

#### Creating a Method

#### **Using Batch Templates**

13.19 Batch Template

#### Queue Window

- 13.20 Skip Warm-up
- 13.21 check for bubble moving into pump in tube
- **13.22** Autotuning solutions DI water?
- 13.23 Check autoscale on 'Real Time Display'
- 13.24 Check Mainframe performance report, record rsd ¡6 %... check counts... oxides...cerium (mass 140/156) ¡ 2 double charges (mass 70 mass 40...) ¡ 3, high matrix. check resolution axis around 7. peak width about 10%, .65 .8, 6.9 ....

#### Running a Batch

- **13.25** Prepare . . .
- 13.26

#### 14. Maintenance

### Cleaning Nebulizer

- **14.1** Soak components in 5% nitric acid. Do not sonicate the nebularizer.
- **14.2** Neebulizer should be tight.
- 14.3 Replace jacket

Author: Marc and Haley

Page: 5 of 7

#### Pump Oil

**14.4** Replace pump oil every 3-4 months. Pump oil will break down and be the final resting place for all ions.

14.5

### **Checking Torch**

- 14.6 Open cover
- 14.7 Shield can get ugly and needs to be replaced.
- 14.8 Don't seem to worry about finger prints on the outside.
- 14.9 Replace tab and torch bonnet stuff yearly

#### Sample and Skimmer Cone

- 14.10 Use software to "maintenance" and torch is moved.
- **14.11** Check and potentially Replace cones... depends on sample matrix, often a recently replaced cone are not stable.
- **14.12** Unscrew ring (use tool if needed)
- 14.13 Clean with sonicator, 7.1% citronox dilute.
- 14.14 Use skimmer cone tool and unscrew it.
- **14.15** Be careful of the graphite o-ring
- **14.16** To replace, finger tighten skimmer cone.
- 14.17 Do not use skimmer cone tool until it's been finger threaded.
- 14.18 Replace sample cone
- 14.19 Initialize to put torch back in.
- 14.20 Close cover

#### Lenses

- **14.21** Using 3mm allen wrench...
- 14.22 Do not touch lens with hands w/o gloves

Author: Marc and Haley

Page: 6 of 7

- 14.23 Loosen and pull them out.
- **14.24** Omega lens...
- 14.25 Cleaned as part of the PM (preventative maintance).
- 14.26 Can check lens test via software.
- 15. Data Analysis and Calculations
- 16. QC/QA Criteria

Tuning

Pulse versus Analog Mode

- **16.1** With low concentrations, versus high concetration.
- 16.2 Using P/A solution
- 17. Trouble Shooting
- 18. References
  - **18.1** APHA, AWWA. WEF. (2012) Standard Methods for examination of water and wastewater. 22nd American Public Health Association (Eds.). Washington. 1360 pp. (2014).

https://crustal.usgs.gov/laboratories/icpms/intro.html

Author: Marc and Haley Page: 7 of 7