## Blinky POV AVR SMT Kit V5.1 Suggest to install in order...

R5..R12 - 330 ohm resistor



R1,R2,R4 - 10k resistor



R3 - 750 ohm resistor



C1 - 0.1uF



D1-D8 - red LED



D11 - green LED



U1 - ATTiny84 microcontroller



SW1 - pushbutton



D9, D10 - photodiode



2 pin header

(battery, next to "V5.1")



BT1 - Battery Case

