## Blinky POV AVR SMT Kit V1.0 Suggest to install in order...

R5..R12 - 330 ohm resistor



R1,R2,R4 - 10k resistor



R3 - 750 ohm resistor



C1 - 0.1uF



D1-D8 - red LED



D11 - green LED



U1 - ATTiny84 microcontroller



SW1 - pushbutton



D9, D10 - photodiode



J1 - 6 pin header



BT1 - Battery Case

