

Y1 pins 4 and 6 are swapped.

Cut traces leading to both.

Connect the horizontal trace with pin 4 (labeled W1)

Connect pin 6 with 2.5V on either C175 or pad of R132. (labeled W2)
Do whichever you find easier.