Title: GENERATION OF BASIC SIGNALS USING MATLAB

AIM: To generate basic signals unit impulse, unit step, unit ramp signal and Exponential signals.

Objective: To generate basic signals like unit impulse, unit step, unit ramp signal and Exponential signals using MATIab.

Write a function in MATLAB to generate


- a) x(t) = 4t2+3,
- b) y(t)=3t+5,
- c) x[n] = 2n2+1
- d) y[n]=8n+3
- a) x(t) = 4t2+3

Description

In problem (a) x(t) is the continuous signal with dependent variable t is in the form of linear second order polynomial equation. The curve of this equation is a parabola

Matlab Program

```
t = linspace(-100,100,1000);
x = 4*t.*t+3;
plot(t,x);
xlabel('t');
ylabel('x');
```



b) y(t)=3t+5


Description

In problem (b) x(t) is the continuous signal with dependent variable t is in the form of linear first order polynomial equation. The curve of this equation is a straight line.

Matlab Program

```
t = linspace(-100,100,1000);
x = 3*t+5;
plot(t,x);
xlabel('t');
ylabel('x');
```

Output of the program




c) x[n] = 2n2+1

Description

In problem (c) x[n] is the discrete signal with dependent variable n where n is the integer. The equation (c) is in the form of a second order polynomial equation. The curve of this equation is a discrete sampled parabola.

Matlab Program

```
n=-29:30;
x = 2*n.*n+1;
stem(n,x);
xlabel('n');
ylabel('x');
```




d) y[n]=8n+3

Description

In problem (d) x[n] is the discrete signal with dependent variable n where n is the integer. The equation (d) is in the form of a first order polynomial equation. The curve of this equation is a discrete sampled straight line.

Matlab Program

```
n=-29:30;
x = 8*n+3;
stem(n,x);
xlabel('n');
ylabel('x');
```



Write a function in MATLAB to generate samples

- (a) unit impulse
- (b) unit step
- (c) unit ramp
- (d) square (amplitude 2, duty cycle 50%, frequency, sampling rate, total time duration)
- (e) triangular (with the following input parameters: frequency, sampling rate, total time duration.)
- (f) exponential (growing and decaying) and
- (g) sinusoidal signal (with the following input parameters: amplitude, phase, frequency, sampling rate, total time duration.) in continuous and discrete time domain.

a) Unit impulse

Description

An ideal impulse signal is a signal that is zero everywhere but at the origin (t = 0), it is infinitely high. Although, the area of the impulse is finite. The unit impulse signal is the most widely used standard signal used in the analysis of signals and systems.

Continuous-Time Unit Impulse Signal

The continuous-time unit impulse signal is denoted by $\delta(t)$ and is defined as –

δ(t)={

1 for t=0

 $0 \text{ for } t \neq 0$

Hence, by the definition, the unit impulse signal has zero amplitude everywhere except at t = 0. At the origin (t = 0) the amplitude of the impulse signal is infinity so that the area under the curve is unity. The continuous-time impulse signal is also called Dirac Delta Signal.

Discrete-Time Unit Impulse Signal

The discrete-time unit impulse signal is denoted by $\delta(n)$ and is defined as –

 $\delta(n)=\{1 \text{ for } n=0\}$


0 for n≠0 }

The discrete-time signal is also called unit sample sequence

Matlab Program

```
t = (-1:0.01:1)';
imp = t==0;
subplot(2,1,1);
plot(t,imp);
xlabel('t');
ylabel('imp');
subplot(2,1,2);
n = -20:20;
imp1 = n==0;
stem(n,imp1);
xlabel('n');
ylabel('imp');
```

Output of the program



b) Unit step

Description


The unit step function, u(t), is defined as $u(t)=\{0\ t<0\ 1\ t>0\ \}$

That is, u is a function of time t, and u has value zero when time is negative and value one when time is positive

Matlab Program

```
t = linspace(-100,100,1000);
unit = t>=0;
subplot(2,1,1);
plot(t,unit);
xlabel('t');
ylabel('u(t)');
n = -20:20;
uint1 = n>=0;
subplot(2,1,2);
stem(n,uint1);
xlabel('n');
ylabel('u(n)');
```

Output of the program




c) Ramp

Description

A ramp function or ramp signal is a type of standard signal which starts at t = 0 and increases linearly with time. The unit ramp function has unit slope.

```
t = linspace(-100, 100, 1000);
```

```
unit = (t>=0).*t;
subplot(2,1,1);
plot(t,unit);
xlabel('t');
ylabel('u(t)');
n = -20:20;
uint1 = (n>=0).*n;
subplot(2,1,2);
stem(n,uint1);
xlabel('n');
ylabel('u(n)');
```




d) Square (amplitude 2, duty cycle 50%, frequency, sampling rate, total time duration)

Description

The square wave, also called a pulse train, or pulse wave, is a periodic waveform consisting of instantaneous transitions between two levels. The square wave is sometimes also called the Rademacher function.

```
t = linspace(-100,100,1000); % time from -100 ms to 100 ms f = 100; %frequency in Hz duty = 50; %duty cycle
```

```
amp = 2;
x = amp * square(2*pi*f*t,50)
subplot(2,1,1);
plot(t,x);
xlabel('t');
ylabel('x');
f = .05; % f reduce to .05 for sampling in 1hz
n = -100:100;
z = 2*square(2*pi*f*n,50);
subplot(2,1,2);
stem(n,z);
xlabel('n');
ylabel('x');
```




e) Triangular (with the following input parameters: frequency, sampling rate, total time duration.)

Description

A triangular wave or triangle wave is a non-sinusoidal waveform named for its triangular shape. It is a periodic, piecewise linear, continuous real function.

```
t = linspace(-100,100,1000); % time from -100 ms to 100 ms f = 100; %frequency in Hz duty = 50; %duty cycle amp = 2; x = amp*sawtooth(2*pi*f*t,1/2);
```

```
subplot(2,1,1);
plot(t,x)
xlabel('t');
ylabel('x');
n = -100:100;
f = .05; % f reduce to .05 for sampling in 1hz
z = amp*sawtooth(2*pi*f*n,1/2);
subplot(2,1,2);
stem(n,z)
xlabel('n');
ylabel('x');
```



f) Exponential (growing and decaying)


Description

An exponential function is a Mathematical function in the form $f(x) = a^x$, where "x" is a variable and "a" is a constant which is called the base of the function and it should be greater than 0. The most commonly used exponential function base is the transcendental number e, which is approximately equal to 2.71828.

exponential growing function is given by e^(+2*pi*f*t) Matlab Program

```
t = linspace(-100,100,1000); % time from -100 ms to 100 ms f = 0.05; %frequency in Hz duty = 50; %duty cycle amp = 2;
```


```
x = amp*exp(2*pi*f*t);
subplot(2,1,1);
plot(t,x)
xlabel('t');
ylabel('x');
n = -100:100;
f = .05; % f reduce to .05 for sampling in 1hz
z = amp*exp(2*pi*f*n);
subplot(2,1,2);
stem(n,z)
xlabel('n');
ylabel('x');
```



exponential growing function is given by e^(-2*pi*f*t) Matlab Program

```
t = linspace(-100,100,1000); % time from -100 ms to 100 ms
f = 0.05; %frequency in Hz
duty = 50; %duty cycle
amp = 2;
x = amp*exp(-2*pi*f*t);
subplot(2,1,1);
plot(t,x)
xlabel('t');
ylabel('x');
n = -100:100;
f = .05; % f reduce to .05 for sampling in 1hz
z = amp*exp(-2*pi*f*n);
subplot(2,1,2);
```

```
stem(n,z)
xlabel('n');
ylabel('x');
```



g) Sinusoidal signal (with the following input parameters: amplitude, phase, frequency, sampling rate, total time duration.) in continuous and discrete time domain.

Description

A sinusoidal function or sinusoidal signal is a function that describes a smooth periodic oscillation.

Continuous-Time Sinusoidal Signal

A sinusoidal signal which is defined for every instant of time is called continuous-time sinusoidal signal. The continuous time sinusoidal signal is given as follows – $x(t) = A \sin(\omega t + \varphi) = A \sin(2\pi f t + \varphi)$

Where.

- A is the amplitude of the signal. That is the peak deviation of the signal from zero.
- ω =2 π f is the angular frequency in radians per seconds.
- f is the frequency of the signal in Hz.
- φ is the phase angle in radians.

All the continuous-time sinusoidal signals are periodic signals. The time period (T) of a continuous-time sinusoidal signal is given by,

$$T = 1/f = 2*\pi/\omega$$

Discrete-Time Sinusoidal Signal

A sinusoidal signal which is defined only at discrete instants of time is called discrete-time sinusoidal signal. The discrete-time sinusoidal signal is given as follows –

$$x(n) = A \sin(\omega n + \varphi) = A \sin(2\pi f n + \varphi)$$

Where,


- A is the amplitude of the signal.
- ω =2 π f is the angular frequency in radians per seconds.
- f is the frequency of the signal in Hz.
- φ is the phase angle in radians.
- n is an integer.

The time period of the discrete-time sinusoidal signal is given by,

 $N = 2*\pi/\omega*m$ where m is integer

Matlab Program

```
t = linspace(-100,100,1000); % time from -100 ms to 100 ms
f = 100; % frequency in Hz
amp = 2;
x = amp * sin(2*pi*f*t)
subplot(2,1,1);
plot(t,x);
xlabel('t');
ylabel('x');
f = .05; % f reduce to .05 for samping in 1hz
n = -100:100;
z = 2*sin(2*pi*f*n);
subplot(2,1,2);
stem(n,z);
xlabel('n');
ylabel('x');
```



Write a function in MATLAB to study transformation on

- (a) amplitude scaling by factor of 3 (+ve and -ve)
- (b) time-scaling (compression and dilation)
- (c) time shifting (+ve and -ve factor)

(a) amplitude scaling by factor of 3 (+ve and -ve)

Description

The process of rescaling the amplitude of a signal, i.e., the amplitude of the signal is either amplified or attenuated, is known as amplitude scaling. In the amplitude scaling operation on signals, the shape of the resulting signal remains the same as that of the original signal but the amplitude is altered (i.e., increased or decreased).


Let us take a function

$$x(t) = 4t^2+3$$

Positive scaling


Matlab Program

```
t = linspace(-100,100,1000);
scale = 3;
x = 4*t.*t+3;
subplot(2,1,1);
plot(t,x);
xlabel('t');
ylabel('x');
subplot(2,1,2);
plot(t,scale*x);
xlabel('t');
ylabel('t');
```



Negative scaling Matlab Program

```
t = linspace(-100,100,1000);
scale = - 3;
x = 4*t.*t+3;
subplot(2,1,1);
plot(t,x);
xlabel('t');
ylabel('x');
subplot(2,1,2);
plot(t,scale*x);
xlabel('t');
ylabel('t');
```



(b) time-scaling (compression and dilation)


Description

The process of multiplying a constant to the time axis of a signal is known as time scaling of the signal. The time scaling of a signal may be time compression or time expansion depending upon the value of the constant or scaling factor.

Let us take a function of square wave with frequency 100 Hz and amplitude 2V and duty 50%.

Compression


```
t = linspace(-100, 100, 1000); % time from -100 ms to 100 ms
f = 100; %frequency in Hz
duty = 50; %duty cycle
amp = 2;
scale =2;
x = amp * square(2*pi*f*t,50);
t1 = scale*t;
y = amp * square(2*pi*f*t1,50);
subplot(2,1,1);
plot(t,x);
xlabel('t');
ylabel('x');
subplot(2,1,2);
plot(t,y);
xlabel('t');
ylabel('y');
```



Dilation

Matlab Program

```
t = linspace(-100, 100, 1000); % time from -100 ms to 100 ms
f = 100; %frequency in Hz
duty = 50; %duty cycle
amp = 2;
scale =1/10;
x = amp * square(2*pi*f*t,50);
t1 = scale*t;
y = amp * square(2*pi*f*t1,50);
subplot(2,1,1);
plot(t,x);
xlabel('t');
ylabel('x');
subplot(2,1,2);
plot(t,y);
xlabel('t');
ylabel('y');
```



(c) time shifting (+ve and -ve factor)

Description

Time shifting or Shifting of a signal in time means that the signal may be either delayed in the time axis or advanced in the time axis.

The time shifting of a continuous time signal x(t) is represented as,

$$y(t) = x(t - t0)$$

The time-shifting of a signal results in the time delay or time advancement.


Let us take a function

$$x(t) = 4t^2+3$$

Time delay


```
t = linspace(-100,100,1000);
t0 = 40;
x = 4*t.*t+3;
subplot(2,1,1);
plot(t,x);
xlabel('t');
ylabel('x');
t1 = t+t0;
y=4*t1.*t1+3;
subplot(2,1,2);
plot(t,y);
xlabel('t');
```

```
ylabel('y');
```



Time delay Matlab Program

```
t = linspace(-100,100,1000);
t0 = 40;
x = 4*t.*t+3;
subplot(2,1,1);
plot(t,x);
xlabel('t');
ylabel('x');
t1 = t-t0;
y=4*t1.*t1+3;
subplot(2,1,2);
plot(t,y);
xlabel('t');
ylabel('t');
```




Write a function in MATLAB to perform addition, subtraction, and multiplication between

(a) x(t)= 2t2+3 and y(t)=4t+8 (b)x[n]= 7n2+5 and y[n]=4n+3

(a) x(t)= 2t2+3 and y(t)=4t+8 Addition


```
t = linspace(-100, 100, 1000);
x = 2*t.*t+3;
y = 4 * t + 8;
z=x+y;
subplot(3,1,1);
plot(t,x);
xlabel('t');
ylabel('x');
subplot(3,1,2);
plot(t,y);
xlabel('t');
ylabel('y');
subplot(3,1,3);
plot(t,z);
xlabel('t');
ylabel('z');
```



Subtraction


Matlab Program

```
t = linspace(-100, 100, 1000);
x = 2*t.*t+3;
y = 4 * t + 8;
z=x-y;
subplot(3,1,1);
plot(t,x);
xlabel('t');
ylabel('x');
subplot(3,1,2);
plot(t,y);
xlabel('t');
ylabel('y');
subplot(3,1,3);
plot(t,z);
xlabel('t');
ylabel('z');
```




Matlab Program

```
t = linspace(-100, 100, 1000);
x = 2*t.*t+3;
y = 4 * t + 8;
z=y-x;
subplot(3,1,1);
plot(t,x);
xlabel('t');
ylabel('x');
subplot(3,1,2);
plot(t,y);
xlabel('t');
ylabel('y');
subplot(3,1,3);
plot(t,z);
xlabel('t');
ylabel('z');
```



Multiplication Matlab Program

```
t = linspace(-100, 100, 1000);
x = 2*t.*t+3;
y = 4 * t + 8;
z = y.*x;
subplot(3,1,1);
plot(t,x);
xlabel('t');
ylabel('x');
subplot(3,1,2);
plot(t,y);
xlabel('t');
ylabel('y');
subplot(3,1,3);
plot(t,z);
xlabel('t');
ylabel('z');
```




(b)x[n] = 7n2+5 and y[n] = 4n+3

Addition


Matlab Program

```
n = -29:30;
x = 7*n.*n+5;
y = 4*n+3;
z=x+y;
subplot(3,1,1);
stem(n,x);
xlabel('n');
ylabel('x');
subplot(3,1,2);
stem(n,y);
xlabel('n');
ylabel('y');
subplot(3,1,3);
stem(n,z);
xlabel('n');
ylabel('z');
```




Subtraction Matlab Program

```
n = -29:30;
x = 7*n.*n+5;
y = 4*n+3;
z=x-y;
subplot(3,1,1);
stem(n,x);
xlabel('n');
ylabel('x');
subplot(3,1,2);
stem(n,y);
xlabel('n');
ylabel('y');
subplot(3,1,3);
stem(n,z);
xlabel('n');
ylabel('z');
```




Subtraction Matlab Program

```
n = -29:30;
x = 7*n.*n+5;
y = 4*n+3;
z = y - x;
subplot(3,1,1);
stem(n,x);
xlabel('n');
ylabel('x');
subplot(3,1,2);
stem(n,y);
xlabel('n');
ylabel('y');
subplot(3,1,3);
stem(n,z);
xlabel('n');
ylabel('z');
```



Multiplication Matlab Program

```
n = -29:30;
x = 7*n.*n+5;
y = 4*n+3;
z = y.*x;
subplot(3,1,1);
stem(n,x);
xlabel('n');
ylabel('x');
subplot(3,1,2);
stem(n,y);
xlabel('n');
ylabel('y');
subplot(3,1,3);
stem(n,z);
xlabel('n');
ylabel('z');
```



Result : All the given signals are generated using matlab and various transformations on the given signal are studied.