

ADC\_XPD\_WAIT = 2, ADC\_RSTB\_WAIT = 1 (drawable stand-ins), CONTINUE\_MODE\_EN = 1, ADC\_SAR1\_PATT\_TYPE = 1 (advance on start), triggered once

x axis is the ADC working clock; the waits count SAR conversions,  $T_{\text{conv}}$  compressed (24 clk real)

