

PIC12(L)F1822/PIC16(L)F182X Memory Programming Specification

This document includes the programming specifications for the following devices:

PIC12F1822
 PIC12LF1822

PIC16F1823
 PIC16LF1823

PIC16F1824
 PIC16LF1824

• PIC16F1825 • PIC16LF1825

PIC16F1826
 PIC16LF1826

• PIC16F1827 • PIC16LF1827

PIC16F1828
 PIC16LF1828

PIC16F1829
 PIC16LF1829

1.0 OVERVIEW

The PIC12(L)F1822 and PIC16(L)F182X devices can be programmed using either the high-voltage In-Circuit Serial Programming $^{\text{TM}}$ (ICSP $^{\text{TM}}$) method or the low-voltage ICSP $^{\text{TM}}$ method.

1.1 Hardware Requirements

1.1.1 HIGH-VOLTAGE ICSP PROGRAMMING

In High-Voltage ICSP $^{\text{TM}}$ mode, these devices require two programmable power supplies: one for VDD and one for the $\overline{\text{MCLR/VPP}}$ pin.

1.1.2 LOW-VOLTAGE ICSP PROGRAMMING

In Low-Voltage ICSPTM mode, these devices can be programmed using a single VDD source in the operating range. The $\overline{MCLR/VPP}$ pin does not have to be brought to a different voltage, but can instead be left at the normal operating voltage.

1.1.2.1 Single-Supply ICSP Programming

The LVP bit in Configuration Word 2 enables single-supply (low-voltage) ICSP programming. The LVP bit defaults to a '1' (enabled) from the factory. The LVP bit may only be programmed to '0' by entering the High-Voltage ICSP mode, where the MCLR/VPP pin is raised to VIHH. Once the LVP bit is programmed to a '0', only the High-Voltage ICSP mode is available and only the High-Voltage ICSP mode can be used to program the device.

- Note 1: The High-Voltage ICSP mode is always available, regardless of the state of the LVP bit, by applying VIHH to the MCLR/VPP pin.
 - 2: While in Low-Voltage ICSP mode, MCLR is always enabled, regardless of the MCLRE bit, and the port pin can no longer be used as a general purpose input.

1.2 Pin Utilization

Five pins are needed for ICSP $^{\text{TM}}$ programming. The pins are listed in Table 1-1 and Table 1-2.

TABLE 1-1: PIN DESCRIPTIONS DURING PROGRAMMING – PIC16(L)F1826, PIC16(L)F1827

Pin Name		Programming	
Pili Name	Function	Pin Type	Pin Description
RB6	ICSPCLK	1	Clock Input – Schmitt Trigger Input
RB7	ICSPDAT	I/O	Data Input/Output – Schmitt Trigger Input
RA5/MCLR/VPP	Program/Verify mode	P ⁽¹⁾	Program Mode Select/Programming Power Supply
VDD	Vdd	Р	Power Supply
Vss	Vss	Р	Ground

Legend: I = Input, O = Output, P = Power

Note 1: In the PIC12(L)F1822 and PIC16(L)F182X, the programming high voltage is internally generated. To activate the Program/Verify mode, high voltage needs to be applied to MCLR input. Since the MCLR is used for a level source, MCLR does not draw any significant current.

TABLE 1-2: PIN DESCRIPTIONS DURING PROGRAMMING – PIC12(L)F1822, PIC16(L)F1823, PIC16(L)F1824, PIC16(L)F1825, PIC16(L)F1828 and PIC16(L)F1829

Pin Name	During Programming		
Pili Name	Function	Pin Type	Pin Description
RA1	ICSPCLK	I	Clock Input – Schmitt Trigger Input
RA0	ICSPDAT	I/O	Data Input/Output – Schmitt Trigger Input
RA3/MCLR/VPP	Program/Verify mode	P ⁽¹⁾	Program Mode Select/Programming Power Supply
VDD	Vdd	Р	Power Supply
Vss	Vss	Р	Ground

Legend: I = Input, O = Output, P = Power

Note 1: In the PIC12(L)F1822 and PIC16(L)F182X, the programming high voltage is internally generated. To activate the Program/Verify mode, high voltage needs to be applied to MCLR input. Since the MCLR is used for a level source, MCLR does not draw any significant current.

2.0 DEVICE PINOUTS

The pin diagrams for the PIC12(L)F1822 and PIC16(L)F182X family are shown in Figure 2-1 through Figure 2-9. The pins that are required for programming are listed in Table 1-1 and shown in bold lettering in the pin diagrams.

FIGURE 2-1: 18-PIN DIAGRAM FOR PIC16(L)F1826/1827




FIGURE 2-2: 20-PIN DIAGRAM FOR PIC16(L)F1826/1827




FIGURE 2-3: 28-PIN DIAGRAM FOR PIC16(L)F1826/1827




FIGURE 2-4: 8-PIN DIAGRAM FOR PIC12(L)F1822




FIGURE 2-5: 8-PIN DIAGRAM FOR PIC12(L)F1822




FIGURE 2-6: 14-PIN DIAGRAM FOR PIC16(L)F1823/1824/1825




FIGURE 2-7: 16-PIN DIAGRAM FOR PIC16(L)F1823/1824/1825




FIGURE 2-8: 20-PIN DIAGRAM FOR PIC16(L)F1828/1829





FIGURE 2-9: 20-PIN DIAGRAM FOR PIC16(L)F1828/1829





3.0 MEMORY MAP

The memory for the PIC12(L)F1822 and PIC16(L)F182X devices is broken into two sections: program memory and configuration memory. Only the size of the program memory changes between devices, the configuration memory remains the same.

PIC12(L)F1822, PIC16(L)F1823 AND PIC16(L)F1826 PROGRAM MEMORY MAPPING FIGURE 3-1: 2 KW 0000h Implemented 07FFh Maps to 0-07FFh **Program Memory** User ID Location 8000h User ID Location 8001h 7FFFh User ID Location 8002h 8000h Implemented 8003h User ID Location 8200h Reserved 8004h Reserved 8005h Maps to **Configuration Memory** Device ID 8006h 8000-81FFh Configuration Word 1 8007h 8008h Configuration Word 2 Calibration Word 1 8009h FFFFh 800Ah Calibration Word 2 800Bh-81FFh Reserved

FIGURE 3-2: PIC16(L)F1827, PIC16(L)F1824 AND PIC16(L)F1828 PROGRAM MEMORY MAPPING





3.1 User ID Location

A user may store identification information (user ID) in four designated locations. The user ID locations are mapped to 8000h-8003h. Each location is 14 bits in length. Code protection has no effect on these memory locations. Each location may be read with code protection enabled or disabled.

Note:

MPLAB[®] IDE only displays the seven Least Significant bits (LSb) of each user ID location, the upper bits are not read. It is recommended that only the seven LSb's be used if MPLAB IDE is the primary tool used to read these addresses.

3.2 Device ID

The device ID word is located at 8006h. This location is read-only and cannot be erased or modified.

REGISTER 3-1: DEVICE ID: DEVICE ID REGISTER⁽¹⁾

R	R	R	R	R	R
DEV8	DEV7	DEV6	DEV5	DEV4	DEV3
bit 13					bit 8

R	R	R	R	R	R	R	R
DEV2	DEV1	DEV0	REV4	REV3	REV2	REV1	REV0
bit 7							bit 0

Legend:	P = Programmable bit	U = Unimplemented bit, read as '0'
R = Readable bit	W = Writable bit	'0' = Bit is cleared
-n = Value at POR	'1' = Bit is set	x = Bit is unknown

bit 13-5 **DEV<8:0>:** Device ID bits

These bits are used to identify the part number.

bit 4-0 **REV<4:0>:** Revision ID bits

These bits are used to identify the revision.

Note 1: This location cannot be written.

TABLE 3-1: DEVICE ID VALUES

DEVIOE	DEVICE ID VALUES					
DEVICE	DEV	REV				
PIC16F1826	10 0111 100	x xxxx				
PIC16F1827	10 0111 101	x xxxx				
PIC16LF1826	10 1000 100	x xxxx				
PIC16LF1827	10 1000 101	x xxxx				
PIC16F1823	10 0111 001	x xxxx				
PIC16LF1823	10 1000 001	x xxxx				
PIC12F1822	10 0111 000	x xxxx				
PIC12LF1822	10 1000 000	x xxxx				
PIC16F1824	10 0111 010	x xxxx				
PIC16LF1824	10 1000 010	x xxxx				
PIC16F1825	10 0111 011	x xxxx				
PIC16LF1825	10 1000 011	x xxxx				
PIC16F1828	10 0111 110	x xxxx				
PIC16LF1828	10 1000 110	x xxxx				
PIC16F1829	10 0111 111	x xxxx				
PIC16LF1829	10 1000 111	x xxxx				

3.3 Configuration Words

There are two Configuration Words, Configuration Word 1 (8007h) and Configuration Word 2 (8008h). The individual bits within these Configuration Words are used to enable or disable device functions such as the Brown-out Reset, code protection and Power-up Timer.

3.4 Calibration Words

The internal calibration values are factory calibrated and stored in Calibration Words 1 and 2 (8009h, 800Ah).

The Calibration Words do not participate in erase operations. The device can be erased without affecting the Calibration Words.

REGISTER 3-2: CONFIGURATION WORD 1

R/P-1	R/P-1	R/P-1	R/P-1	R/P-1	R/P-1
FCMEN	IESO	CLKOUTEN	BORE	N<1:0>	CPD
bit 13					bit 8

R/P-1	R/P-1	R/P-1	R/P-1	R/P-1	R/P-1	R/P-1	R/P-1
CP	MCLRE	PWRTE	WDTE	E<1:0>		FOSC<2:0>	
bit 7							bit 0

Legend:	W = Writable bit	'0' = Bit is cleared
R = Readable bit	'1' = Bit is set	x = Bit is unknown
-n = Value at POR	U = Unimplemented bit, read as '0'	P = Programmable Bit

bit 13

FCMEN: Fail-Safe Clock Monitor Enable bit

1 = Fail-Safe Clock Monitor is enabled

0 = Fail-Safe Clock Monitor is disabled

bit 12

IESO: Internal External Switchover bit

1 = Internal/External Switchover mode is enabled 0 = Internal/External Switchover mode is disabled

bit 11 CLKOUTEN: Clock Out Enable bit

1 = CLKOUT function is disabled. I/O or oscillator function on CLKOUT pin.

0 = CLKOUT function is enabled on CLKOUT pin

bit 10-9 BOREN<1:0>: Brown-out Reset Enable bits⁽¹⁾

11 = BOR enabled

10 = BOR enabled during operation and disabled in Sleep 01 = BOR controlled by SBOREN bit of the PCON register

00 = BOR disabled

bit 8 CPD: Data Code Protection bit⁽²⁾

1 = Data memory code protection is disabled0 = Data memory code protection is enabled

bit 7 CP: Code Protection bit⁽³⁾

1 = Program memory code protection is disabled 0 = Program memory code protection is enabled

bit 6 MCLRE: MCLR/VPP Pin Function Select bit

If LVP bit = 1:

This bit is ignored.

If LVP bit = 0:

1 = \overline{MCLR}/VPP pin function is \overline{MCLR} ; Weak pull-up enabled.

0 = MCLR/VPP pin function is digital input; MCLR internally disabled; Weak pull-up under control of WPUA register.

bit 5 **PWRTE**: Power-up Timer Enable bit⁽¹⁾

1 = PWRT disabled0 = PWRT enabled

0 = PWRI enabled

bit 4-3 WDTE<1:0>: Watchdog Timer Enable bit

11 = WDT enabled

10 = WDT enabled while running and disabled in Sleep

01 = WDT controlled by the SWDTEN bit in the WDTCON register

00 = WDT disabled

bit 2-0 FOSC<2:0>: Oscillator Selection bits

111 = ECH: External Clock, High-Power mode: on CLKIN pin
 110 = ECM: External Clock, Medium-Power mode: on CLKIN pin
 101 = ECL: External Clock, Low-Power mode: on CLKIN pin

100 = INTOSC oscillator: I/O function on OSC1 pin

011 = EXTRC oscillator: RC function on OSC1 pin

010 = HS oscillator: High-speed crystal/resonator on OSC2 pin and OSC1 pin

001 = XT oscillator: Crystal/resonator on OSC2 pin and OSC1 pin 000 = LP oscillator: Low-power crystal on OSC2 pin and OSC1 pin

Note 1: Enabling Brown-out Reset does not automatically enable Power-up Timer.

2: The entire data EEPROM will be erased when the code protection is turned off during an erase.

3: The entire program memory will be erased when the code protection is turned off.

REGISTER 3-3: CONFIGURATION WORD 2

R/P-1	R/P-1	U-1	R/P-1	R/P-1	R/P-1
LVP	DEBUG	_	BORV	STVREN	PLLEN
bit 13 bit 8					

U-1	U-1	U-1	R-1	U-1	U-1	R/P-1	R/P-1
_	_	_	Reserved ⁽²⁾	_	_	WRT	<1:0>
bit 7							bit 0

Legend:	W = Writable bit	'0' = Bit is cleared
R = Readable bit	'1' = Bit is set	x = Bit is unknown
-n = Value at POR	U = Unimplemented bit, read as '0'	P = Programmable Bit

bit 13 LVP: Low-Voltage Programming Enable bit⁽¹⁾

1 = Low-voltage programming enabled

0 = HV on \overline{MCLR}/VPP must be used for programming

bit 12 **DEBUG:** In-Circuit Debugger Mode bit

1 = In-Circuit Debugger disabled, ICSPCLK and ICSPDAT are general purpose I/O pins 0 = In-Circuit Debugger enabled, ICSPCLK and ICSPDAT are dedicated to the debugger

bit 11 **Unimplemented:** Read as '1'

bit 10 BORV: Brown-out Reset Voltage Selection bit

1 = Brown-out Reset voltage (VBOR), low trip point selected 0 = Brown-out Reset voltage (VBOR), high trip point selected

bit 9 STVREN: Stack Overflow/Underflow Reset Enable bit

1 = Stack overflow or underflow will cause a Reset 0 = Stack overflow or underflow will not cause a Reset

bit 8 **PLLEN:** PLL Enable bit 1 = 4xPLL enabled

0 = 4xPLL disabled

bit 7-5 Unimplemented: Read as '1'
bit 4 Reserved: Read as '1'(2)
bit 3-2 Unimplemented: Read as '1'

bit 1-0 WRT<1:0>: Flash Memory Self-Write Protection bits 2 kW Flash memory (PIC12(L)F1822/PIC16(L)F1823/1826):

11 = Write protection off

10 = 000h to 1FFh write-protected, 200h to 7FFh may be modified by EECON control

01 = 000h to 3FFh write-protected, 400h to 7FFh may be modified by EECON control

00 = 000h to 7FFh write-protected, no addresses may be modified by EECON control

4 kW Flash memory (PIC16(L)F1824/1827/1828):

11 = Write protection off

10 = 000h to 1FFh write-protected, 200h to FFFh may be modified by EECON control

01 = 000h to 7FFh write-protected, 800h to FFFh may be modified by EECON control

00 = 000h to FFFh write-protected, no addresses may be modified by EECON control

8 kW Flash memory (PIC16(L)F1825/1829):

11 = Write protection off

10 = 000h to 1FFh write-protected, 200h to 1FFFh may be modified by EECON control

01 = 000h to FFFh write-protected, 1000h to 1FFFh may be modified by EECON control

00 = 000h to 1FFFh write-protected, no addresses may be modified by EECON control

Note 1: The LVP bit cannot be programmed to '0' when Programming mode is entered via LVP.

2: This bit must be programmed as a '1'.

4.0 PROGRAM/VERIFY MODE

In Program/Verify mode, the program memory and the configuration memory can be accessed and programmed in serial fashion. ICSPDAT and ICSPCLK are used for the data and the clock, respectively. All commands and data words are transmitted LSb first. Data changes on the rising edge of the ICSPCLK and latched on the falling edge. In Program/Verify mode both the ICSPDAT and ICSPCLK are Schmitt Trigger inputs. The sequence that enters the device into Program/Verify mode places all other logic into the Reset state. Upon entering Program/Verify mode, all I/Os are automatically configured as high-impedance inputs and the address is cleared.

4.1 High-Voltage Program/Verify Mode Entry and Exit

There are two different methods of entering Program/ Verify mode via high-voltage:

- VPP First entry mode
- VDD First entry mode

4.1.1 VPP – FIRST ENTRY MODE

To enter Program/Verify mode via the VPP-first method the following sequence must be followed:

- 1. Hold ICSPCLK and ICSPDAT low. All other pins should be unpowered.
- 2. Raise the voltage on MCLR from 0V to VIHH.
- 3. Raise the voltage on VDD FROM 0V to the desired operating voltage.

The VPP-first entry prevents the device from executing code prior to entering Program/Verify mode. For example, when Configuration Word 1 has $\overline{\text{MCLR}}$ disabled (MCLRE = 0), the power-up time is disabled (PWRTE = 0), the internal oscillator is selected (Fosc = 100), and ICSPCLK and ICSPDAT pins are driven by the user application, the device will execute code. Since this may prevent entry, VPP-first entry mode is strongly recommended. See the timing diagram in Figure 8-2.

4.1.2 VDD – FIRST ENTRY MODE

To enter Program/Verify mode via the VDD-first method the following sequence must be followed:

- 1. Hold ICSPCLK and ICSPDAT low.
- Raise the voltage on VDD from 0V to the desired operating voltage.
- Raise the voltage on MCLR from VDD or below to VIHH.

The VDD-first method is useful when programming the device when VDD is already applied, for it is not necessary to disconnect VDD to enter Program/Verify mode. See the timing diagram in Figure 8-1.

4.1.3 PROGRAM/VERIFY MODE EXIT

To exit Program/Verify mode take MCLR to VDD or lower (VIL). See Figures 8-3 and 8-4.

4.2 Low-Voltage Programming (LVP) Mode

The Low-Voltage Programming mode allows the PIC12(L)F1822 and PIC16(L)F182X devices to be programmed using VDD only, without high voltage. When the LVP bit of Configuration Word 2 register is set to '1', the low-voltage ICSP programming entry is enabled. To disable the Low-Voltage ICSP mode, the LVP bit must be programmed to '0'. This can only be done while in the High-Voltage Entry mode.

Entry into the Low-Voltage ICSP Program/Verify modes requires the following steps:

- 1. MCLR is brought to VIL.
- A 32-bit key sequence is presented on ICSPDAT, while clocking ICSPCLK.

The key sequence is a specific 32-bit pattern, '0100 1101 0100 0011 0100 1000 0101 0000' (more easily remembered as MCHP in ASCII). The device will enter Program/Verify mode only if the sequence is valid. The Least Significant bit of the Least Significant nibble must be shifted in first.

Once the key sequence is complete, $\overline{\text{MCLR}}$ must be held at V_{IL} for as long as Program/Verify mode is to be maintained.

For low-voltage programming timing, see Figure 8-8 and Figure 8-9.

Exiting Program/Verify mode is done by no longer driving MCLR to VIL. See Figure 8-8 and Figure 8-9.

Note: To enter LVP mode, the LSB of the Least Significant nibble must be shifted in first. This differs from entering the key sequence on other parts.

4.3 Program/Verify Commands

The PIC12(L)F1822 and PIC16(L)F182X implement 13 programming commands; each six bits in length. The commands are summarized in Table 4-1.

Commands that have data associated with them are specified to have a minimum delay of TDLY between the command and the data. After this delay 16 clocks are required to either clock in or clock out the 14-bit data word. The first clock is for the Start bit and the last clock is for the Stop bit.

TABLE 4-1: COMMAND MAPPING

Command	Mapping					Data/Note		
Command	Binary (MSb LSb)				Hex			
Load Configuration	Х	0	0	0	0	0	00h	0, data (14), 0
Load Data For Program Memory	Х	0	0	0	1	0	02h	0, data (14), 0
Load Data For Data Memory	Х	0	0	0	1	1	03h	0, data (8), zero (6), 0
Read Data From Program Memory	Х	0	0	1	0	0	04h	0, data (14), 0
Read Data From Data Memory	Х	0	0	1	0	1	05h	0, data (8), zero (6), 0
Increment Address	Х	0	0	1	1	0	06h	_
Reset Address	Х	1	0	1	1	0	16h	_
Begin Internally Timed Programming	Х	0	1	0	0	0	08h	_
Begin Externally Timed Programming	Х	1	1	0	0	0	18h	_
End Externally Timed Programming	Х	0	1	0	1	0	0Ah	_
Bulk Erase Program Memory	Х	0	1	0	0	1	09h	Internally Timed
Bulk Erase Data Memory	Х	0	1	0	1	1	0Bh	Internally Timed
Row Erase Program Memory	Х	1	0	0	0	1	11h	Internally Timed


4.3.1 LOAD CONFIGURATION

The Load Configuration command is used to access the configuration memory (User ID Locations, Configuration Words, Calibration Words). The Load Configuration command sets the address to 8000h and loads the data latches with one word of data (see Figure 4-1).

After issuing the Load Configuration command, use the Increment Address command until the proper address to be programmed is reached. The address is then programmed by issuing either the Begin Internally Timed Programming or Begin Externally Timed Programming command.

The only way to get back to the program memory (address 0) is to exit Program/Verify mode or issue the Reset Address command after the configuration memory has been accessed by the Load Configuration command.


FIGURE 4-1: LOAD CONFIGURATION



4.3.2 LOAD DATA FOR PROGRAM MEMORY

The Load Data for Program Memory command is used to load one 14-bit word into the data latches. The word programs into program memory after the Begin Internally Timed Programming or Begin Externally Timed Programming command is issued (see Figure 4-2).


FIGURE 4-2: LOAD DATA FOR PROGRAM MEMORY



4.3.3 LOAD DATA FOR DATA MEMORY

The Load Data for Data Memory command will load a 14-bit "data word" when 16 cycles are applied. However, the data memory is only eight bits wide and thus, only the first eight bits of data after the Start bit will be programmed into the data memory. It is still necessary to cycle the clock the full 16 cycles in order to allow the internal circuitry to reset properly (see Figure 4-3).


FIGURE 4-3: LOAD DATA FOR DATA MEMORY COMMAND



4.3.4 READ DATA FROM PROGRAM MEMORY

The Read Data from Program Memory command will transmit data bits out of the program memory map currently accessed, starting with the second rising edge of the clock input. The ICSPDAT pin will go into Output mode on the first falling clock edge, and it will revert to Input mode (high-impedance) after the 16th falling edge of the clock. If the program memory is code-protected (\overline{CP}) , the data will be read as zeros (see Figure 4-4).


FIGURE 4-4: READ DATA FROM PROGRAM MEMORY



4.3.5 READ DATA FROM DATA MEMORY

The Read Data from Data Memory command will transmit data bits out of the data memory starting with the second rising edge of the clock input. The ICSPDAT pin will go into Output mode on the second rising edge, and it will revert to Input mode (high-impedance) after the 16th rising edge. The data memory is eight bits wide, and therefore, only the first eight bits that are output are actual data. If the data memory is codeprotected, the data is read as all zeros. A timing diagram of this command is shown in Figure 4-5.

FIGURE 4-5: READ DATA FROM DATA MEMORY COMMAND




4.3.6 INCREMENT ADDRESS

The address is incremented when this command is received. It is not possible to decrement the address. To reset this counter, the user must use the Reset Address command or exit Program/Verify mode and reenter it.

If the address is incremented from address 7FFFh, it will wrap-around to location 0000h. If the address is incremented from FFFFh, it will wrap-around to location 8000h.


FIGURE 4-6: INCREMENT ADDRESS



4.3.7 RESET ADDRESS

The Reset Address command will reset the address to 0000h, regardless of the current value. The address is used in program memory or the configuration memory.

FIGURE 4-7: RESET ADDRESS




4.3.8 BEGIN INTERNALLY TIMED PROGRAMMING

A Load Configuration or Load Data for Program Memory command must be given before every Begin Programming command. Programming of the addressed memory will begin after this command is received. An internal timing mechanism executes the write. The user must allow for the program cycle time, TPINT, for the programming to complete.

The End Externally Timed Programming command is not needed when the Begin Internally Timed Programming is used to start the programming.

The program memory address that is being programmed is not erased prior to being programmed. However, the EEPROM memory address that is being programmed is erased prior to being programmed with internally timed programming.

FIGURE 4-8: BEGIN INTERNALLY TIMED PROGRAMMING




4.3.9 BEGIN EXTERNALLY TIMED PROGRAMMING

A Load Configuration, Load Data for Program Memory or Load Data for Data Memory command must be given before every Begin Programming command. Programming of the addressed memory will begin after this command is received. To complete the programming the End Externally Timed Programming command must be sent in the specified time window defined by TPEXT. No internal erase is performed for the data EEPROM, therefore, the device should be erased prior to executing this command.

The Begin Externally Timed Programming command cannot be used for programming the Configuration Words (see Figure 4-9).

FIGURE 4-9: BEGIN EXTERNALLY TIMED PROGRAMMING




4.3.10 END EXTERNALLY TIMED PROGRAMMING

This command is required after a Begin Externally Timed Programming command is given. This command must be sent within the time window specified by TPEXT after the Begin Externally Timed Programming command is sent.

After sending the End Externally Timed Programming command, an additional delay (TDIS) is required before sending the next command. This delay is longer than the delay ordinarily required between other commands (see Figure 4-10).

FIGURE 4-10: END EXTERNALLY TIMED PROGRAMMING



4.3.11 BULK ERASE PROGRAM MEMORY

The Bulk Erase Program Memory command performs two different functions dependent on the current state of the address.

Address 0000h-7FFFh:

Program Memory is erased
Configuration Words are erased
If $\overline{\text{CPD}}$ = 0, Data Memory is erased

Address 8000h-8008h:


Program Memory is erased
Configuration Words are erased
User ID Locations are erased
If CPD = 0, Data Memory is erased

A Bulk Erase Program Memory command should not be issued when the address is greater than 8008h.

After receiving the Bulk Erase Program Memory command the erase will not complete until the time interval, TERAB, has expired.

Note: The code protection Configuration bit $\overline{(CP)}$ has no effect on the Bulk Erase Program Memory command.

FIGURE 4-11: BULK ERASE PROGRAM MEMORY



4.3.12 BULK ERASE DATA MEMORY


To perform an erase of the data memory, after a Bulk Erase Data Memory command, wait a minimum of TERAB to complete Bulk Erase.

To erase data memory when data code-protect is active ($\overline{\text{CPD}}$ = 0), the Bulk Erase Program Memory command should be used.

After receiving the Bulk Erase Data Memory command, the erase will not complete until the time interval, TERAB, has expired.

Note: Data memory will not erase if codeprotected (CPD = 0).

FIGURE 4-12: BULK ERASE DATA MEMORY COMMAND



4.3.13 ROW ERASE PROGRAM MEMORY


The Row Erase Program Memory command will erase an individual row. Refer to Table 4-2 for row sizes of specific devices and the PC bits used to address them. If the program memory is code-protected the Row Erase Program Memory command will be ignored. When the address is 8000h-8008h the Row Erase Program Memory command will only erase the user ID locations regardless of the setting of the $\overline{\text{CP}}$ Configuration bit.

After receiving the Row Erase Program Memory command the erase will not complete until the time interval, TERAR, has expired.

TABLE 4-2: PROGRAMMING ROW SIZE AND LATCHES

Devices	PC	Row Size	Number of Latches
PIC16F1826/1827	<15:5>	32	8
PIC12F1822/16F1823	<15:4>	16	16
PIC16F1824/1825	<15:5>	32	32
PIC16F1828/1829	<15:5>	32	32





5.0 PROGRAMMING ALGORITHMS

The PIC12F1822/16F182X devices use internal latches to temporarily store the 14-bit words used for programming. Refer to Table 4-2 for specific latch in formation. The data latches allow the user to write the program words with a single Begin Externally Timed Programming or Begin Internally Timed Programming command. The Load Program Data or the Load Configuration command is used to load a single data latch. The data latch will hold the data until the Begin Externally Timed Programming or Begin Internally Timed Programming command is given.

The data latches are aligned with the LSbs of the address. The PC's address at the time the Begin Externally Timed Programming or Begin Internally Timed Programming command is given will determine which location(s) in memory are written. Writes cannot cross the physical boundary. For example, with the PIC16F1827, attempting to write from address 0002h-0009h will result in data being written to 0008h-000Fh.

If more than the maximum number of data latches are written without a Begin Externally Timed Programming or Begin Internally Timed Programming command, the data in the data latches will be overwritten. The following figures show the recommended flowcharts for programming.







FIGURE 5-2: PROGRAM MEMORY FLOWCHART




- Note 1: This step is optional if device has already been erased or has not been previously programmed.
 - 2: If the device is code-protected or must be completely erased, then Bulk Erase device per Figure 5-8.
 - **3:** See Figure 5-3 or Figure 5-4.

FIGURE 5-3: ONE-WORD PROGRAM CYCLE












FIGURE 5-7: **DATA MEMORY PROGRAM CYCLE**





FIGURE 5-8: **ERASE FLOWCHART**



6.0 CODE PROTECTION

Code protection is controlled using the $\overline{\text{CP}}$ bit in Configuration Word 1. When code protection is enabled, all program memory locations (0000h-7FFFh) read as all '0'. Further programming is disabled for the program memory (0000h-7FFFh).

Data memory is protected with its own code-protect bit (\overline{CPD}) . When data code-protection is enabled $(\overline{CPD}=0)$, all data memory locations read as '0'. Further programming is disabled for the data memory. Data memory can still be programmed and read during program execution.

The user ID locations and Configuration Words can be programmed and read out regardless of the code protection settings.

6.1 Program Memory

Code protection is enabled by programming the \overline{CP} bit in Configuration Word 1 register to '0'.

The only way to disable code protection is to use the Bulk Erase Program Memory command.

6.2 Data Memory

Data memory protection is enabled by programming the $\overline{\text{CPD}}$ bit in Configuration Word 1 register to '0'.

The only way to disable code protection is to use the Bulk Erase Program Memory command.

Note: To ensure system security, if $\overline{\text{CPD}}$ bit = 0, the Bulk Erase Program Memory command will also erase data memory.

7.0 HEX FILE USAGE

In the hex file there are two bytes per program word stored in the Intel[®] INHX32 hex format. Data is stored LSB first, MSB second. Because there are two bytes per word, the addresses in the hex file are 2x the address in program memory. (Example: Configuration Word 1 is stored at 8007h on the PIC12(L)F1822 and PIC16(L)F182X. In the hex file this will be referenced as 1000Eh-1000Fh).

7.1 Configuration Word

To allow portability of code, it is strongly recommended that the programmer is able to read the Configuration Words and user ID locations from the hex file. If the Configuration Words information was not present in the hex file, a simple warning message may be issued. Similarly, while saving a hex file, Configuration Words and user ID information should be included.

7.2 Device ID and Revision

If a device ID is present in the hex file at 1000Ch-1000Dh (8006h on the part), the programmer should verify the device ID (excluding the revision) against the value read from the part. On a mismatch condition the programmer should generate a warning message.

7.3 Data EEPROM

The programmer should be able to read data memory information from a hex file and write data memory contents to a hex file.

The physical address range of the 256 byte data memory is 0000h-00FFh. However, these addresses are logically mapped to address 1E000h-1E1FFh in the hex file. This provides a way of differentiating between the data and program memory locations in this range. The format for data memory storage is one data byte per address location, LSb aligned.

7.4 Checksum Computation

The checksum is calculated by two different methods dependent on the setting of the $\overline{\mathsf{CP}}$ Configuration bit.

TABLE 7-1: CONFIGURATION WORD MASK VALUES

Device	Config. Word 1 Mask	Config. Word 2 Mask					
PIC16F1826	3FFFh	3713h					
PIC16F1827	3FFFh	3713h					
PIC16LF1826	3FFFh	3703h					
PIC16LF1827	3FFFh	3703h					
PIC12F1822	3FFFh	3713h					
PIC12LF1822	3FFFh	3713h					
PIC16F1823	3FFFh	3713h					
PIC16LF1823	3FFFh	3713h					
PIC16F1824	3FFFh	3713h					
PIC16LF1824	3FFFh	3713h					
PIC16F1825	3FFFh	3713h					
PIC16LF1825	3FFFh	3713h					
PIC16F1828	3FFFh	3713h					
PIC16LF1828	3FFFh	3713h					
PIC16F1829	3FFFh	3713h					
PIC16LF1829	3FFFh	3713h					

7.4.1 PROGRAM CODE PROTECTION DISABLED

With the program code protection disabled, the checksum is computed by reading the contents of the PIC12(L)F1822 and PIC16(L)F182X program memory locations and adding up the program memory data starting at address 0000h, up to the maximum user addressable location. Any Carry bit exceeding 16 bits are ignored. Additionally, the relevant bits of the Configuration Words are added to the checksum. All unimplemented Configuration bits are masked to '0'.

Note: Data memory does not effect the checksum.

EXAMPLE 7-1: CHECKSUM COMPUTED WITH PROGRAM CODE PROTECTION DISABLED PIC16F1827, BLANK DEVICE

PIC16F1827	Sum of Memory add	lresses 0000h-0FFFh	F000h
	Configuration Word 1		3FFFh
	Configuration Word 1 mask		3FFFh
	Configuration Word 2		3FFFh
	Configuration Word 2 mask		3713h
	Checksum = F000h + (3FFFh and 3FFFh)		n) + (3FFFh and 3713h)
	= F000h + 3FFFh + 3713h		
		= 6712h	

EXAMPLE 7-2: CHECKSUM COMPUTED WITH PROGRAM CODE PROTECTION DISABLED PIC16LF1827, 00AAh AT FIRST AND LAST ADDRESS

	·	
PIC16LF1827	Sum of Memory addresses 0000h-0FFFh	7156h
	Configuration Word 1	3FFFh
	Configuration Word 1 mask	3FFFh
	Configuration Word 2	3FFFh
	Configuration Word 2 mask	3703h
	Checksum = 7156h + (3FFFh and 3FFFh) + (3FFFh	and 3703h)
	= 7156h + 3FFFh + 3703h	
	= E858h	

7.4.2 PROGRAM CODE PROTECTION ENABLED

With the program code protection enabled, the checksum is computed in the following manner: The Least Significant nibble of each User ID is used to create a 16-bit value. The masked value of User ID location 8000h is the Most Significant nibble. This Sum

of User IDs is summed with the Configuration Words (all unimplemented Configuration bits are masked to (0)).

Note: Data memory does not effect the checksum.

EXAMPLE 7-3: CHECKSUM COMPUTED WITH PROGRAM CODE PROTECTION ENABLED PIC16F1827, BLANK DEVICE

DIG 405 4007	0 5 11 144 1		05751		
PIC16F1827	Configuration Word	1	3F7Fh		
	Configuration Word	1 mask	3FFFh		
	Configuration Word	2	3FFFh		
	Configuration Word	2 mask	3713h		
	User ID (8000h)		0006h		
	User ID (8001h)		0007h		
	User ID (8002h)		0001h		
	User ID (8003h)		0002h		
	Sum of User IDs = (0006h and 000Fh) << 12 + (0007		h and 000Fh) << 8 +		
		(0001h and 000Fh) << 4 + (0	0002h and 000Fh)		
		= 6000h + 0700h + 0010h + 00	002h		
		= 6712h			
	Checksum = (3F7Fh and 3FFFh) + (3FFF		Fh and 3713h) + Sum of User IDs		
	= 3F7Fh +3713h + 6712h				
		= DDA4h			

EXAMPLE 7-4: CHECKSUM COMPUTED WITH PROGRAM CODE PROTECTION ENABLED PIC16LF1827, 00AAh AT FIRST AND LAST ADDRESS

PIC16LF1827	Configuration Word	1 3F7Fh
	Configuration Word	1 mask 3FFFh
	Configuration Word	2 3FFFh
	Configuration Word	2 mask 3703h
	User ID (8000h)	000Eh
	User ID (8001h)	0008h
	User ID (8002h)	0005h
	User ID (8003h)	0008h
	Sum of User IDs	= (000Eh and 000Fh) << 12 + (0008h and 000Fh) << 8 +
		(0005h and 000Fh) << 4 + (0008h and 000Fh)
		= E000h + 0800h + 0050h + 0008h
		= E858h
	Checksum	= (3F7Fh and 3FFFh) + (3FFFh and 3703h) + Sum of User IDs
		= 3F7Fh +3703h + E858h
		= 5EDAh

8.0 ELECTRICAL SPECIFICATIONS

Refer to device specific data sheet for absolute maximum ratings.

TABLE 8-1: AC/DC CHARACTERISTICS TIMING REQUIREMENTS FOR PROGRAM/VERIFY MODE

AC/DC C	HARACTERISTICS		Standard Operating			s (unless °C ≤ TA ≤	otherwise stated) +85°C
Sym.	Characteristics			Тур.	Max.	Units	Conditions/Comments
		Supply Volt	ages and C	urrents			
	VDD						
VDD	Read/Write and Row Erase	PIC12F1822 PIC16F182X	2.1	_	5.5	V	
	operations	PIC12LF1822 PIC16LF182X	2.1	_	3.6	V	
	Bulk Erase operations	PIC12F1822 PIC16F182X	2.7	_	5.5	V	
		PIC12LF1822 PIC16LF182X	2.7	_	3.6	V	
Iddi	Current on VDD, Idle		_	_	1.0	mA	
IDDP	Current on VDD, Programming		_	_	3.0	mA	
	VPP					I	
I PP	Current on MCLR/VPP				600	μА	
VIHH	High voltage on MCLR/VPP for		8.0		9.0	V	
TVHHR	Program/Verify mode entry MCLR rise time (VIL to VIHH) for	•	_	_	1.0	μS	
	Program/Verify mode entry					F	
	I/O pins		1			ı	
VIH	(ICSPCLK, ICSPDAT, MCLR/VPP) input high level		0.8 VDD	_	_	V	
VIL	(ICSPCLK, ICSPDAT, MCLR/VI	PP) input low level	_	_	0.2 VDD	V	
Vон	ICSPDAT output high level		VDD-0.7 VDD-0.7 VDD-0.7	_	_	V	IOH = 3.5 mA, VDD = 5V IOH = 3 mA, VDD = 3.3V IOH = 2 mA, VDD = 1.8V
VoL	ICSPDAT output low level	_	_	Vss+0.6 Vss+0.6 Vss+0.6	V	IOH = 8 mA, VDD = 5V IOH = 6 mA, VDD = 3.3V IOH = 3 mA, VDD = 1.8V	
		Programming	Mode Entr	v and Exit		I	,
TENTS	Programing mode entry setup t ICSPDAT setup time before VD	me: ICSPCLK,	100	_	_	ns	
TENTH	Programing mode entry hold tin	ne: ICSPCLK,	250	_	_	μS	
		Serial F	rogram/Ve	rify		I	II.
TCKL	Clock Low Pulse Width		100	_	_	ns	
Тскн	Clock High Pulse Width		100	_	_	ns	
TDS	Data in setup time before clock	↓	100	_	_	ns	
TDH	Data in hold time after clock↓		100	_	_	ns	
Tco	Clock↑ to data out valid (during a Read Data command)		0	_	80	ns	
TLZD	Clock↓ to data low-impedance Read Data command)		0	_	80	ns	
THZD	Clock↓ to data high-impedance Read Data command)		0	_	80	ns	
TDLY	Data input not driven to next clock input (delay required between command/data or command/ command)		1.0	_	_	μS	
TERAB	Bulk Erase cycle time		_	_	5	ms	
TERAR	Row Erase cycle time		<u> </u>	<u> </u>	2.5	ms	

TABLE 8-1: AC/DC CHARACTERISTICS TIMING REQUIREMENTS FOR PROGRAM/VERIFY

AC/DC CHARACTERISTICS		Standard Operating Conditions (unless otherwise stated) Operating Temperature $-40^{\circ}\text{C} \le \text{TA} \le +85^{\circ}\text{C}$				
Sym. Characteristics		Min.	Тур.	Max.	Units	Conditions/Comments
TPINT	Internally timed programming operation time	_ 	_ _ _	2.5 5 5	ms ms ms	Program memory Configuration Words EEPROM
TPEXT	Externally timed programming pulse	1.0	_	2.1	ms	
TDIS	Time delay from program to compare (HV discharge time)	300	_	_	μS	
TEXIT	Time delay when exiting Program/Verify mode	1	_	_	μS	

8.1 AC Timing Diagrams

FIGURE 8-1: PROGRAMMING MODE ENTRY – VDD FIRST




FIGURE 8-2: PROGRAMMING MODE ENTRY – VPP FIRST




FIGURE 8-3: PROGRAMMING MODE EXIT – VPP LAST




FIGURE 8-4: PROGRAMMING MODE EXIT – VDD LAST




FIGURE 8-5: CLOCK AND DATA




FIGURE 8-6: WRITE COMMAND-PAYLOAD TIMING




FIGURE 8-7: READ COMMAND-PAYLOAD TIMING




FIGURE 8-8: LVP ENTRY (POWERING UP)





FIGURE 8-9: LVP ENTRY (POWERED)



APPENDIX A: REVISION HISTORY

Revision A (06/2009)

Original release of this document.

Revision B (10/2009)

Added PIC12F/LF1822 and PIC16F/LF1823 devices.

Revision C (03/2010)

Added PIC12(L)F1824, PIC16(L)F1825, PIC16(L)F1828 and PIC16(L)F1829 devices; Added Figure 2-8, Figure 2-9 and Figure 3-3.

Revision D (09/2012)

Updated document to new format; Updated Figure 3-3, Register 3-3 and Table 8-1; Other minor corrections.

NOTES:

Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our
 knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data
 Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- · Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights.

QUALITY MANAGEMENT SYSTEM CERTIFIED BY DNV ISO/TS 16949

Trademarks

The Microchip name and logo, the Microchip logo, dsPIC, FlashFlex, KEELOQ, KEELOQ logo, MPLAB, PIC, PICmicro, PICSTART, PIC³² logo, rfPIC, SST, SST Logo, SuperFlash and UNI/O are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

FilterLab, Hampshire, HI-TECH C, Linear Active Thermistor, MTP, SEEVAL and The Embedded Control Solutions Company are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Silicon Storage Technology is a registered trademark of Microchip Technology Inc. in other countries.

Analog-for-the-Digital Age, Application Maestro, BodyCom, chipKIT, chipKIT logo, CodeGuard, dsPICDEM, dsPICDEM.net, dsPICworks, dsSPEAK, ECAN, ECONOMONITOR, FanSense, HI-TIDE, In-Circuit Serial Programming, ICSP, Mindi, MiWi, MPASM, MPF, MPLAB Certified logo, MPLIB, MPLINK, mTouch, Omniscient Code Generation, PICC, PICC-18, PICDEM, PICDEM.net, PICkit, PICtail, REAL ICE, rfLAB, Select Mode, SQI, Serial Quad I/O, Total Endurance, TSHARC, UniWinDriver, WiperLock, ZENA and Z-Scale are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

GestIC and ULPP are registered trademarks of Microchip Technology Germany II GmbH & Co. & KG, a subsidiary of Microchip Technology Inc., in other countries.

All other trademarks mentioned herein are property of their respective companies.

© 2010-2012, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.

Printed on recycled paper.

ISBN: 9781620765968

Microchip received ISO/TS-16949:2009 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC® MCUs and dsPIC® DSCs, KEELOQ® code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.



Worldwide Sales and Service

AMERICAS

Corporate Office 2355 West Chandler Blvd.

Chandler, AZ 85224-6199 Tel: 480-792-7200 Fax: 480-792-7277 Technical Support:

http://www.microchip.com/

support Web Address:

www.microchip.com

Atlanta

Duluth, GA Tel: 678-957-9614 Fax: 678-957-1455

Boston

Westborough, MA Tel: 774-760-0087 Fax: 774-760-0088

Chicago Itasca, IL

Tel: 630-285-0071 Fax: 630-285-0075

Cleveland

Independence, OH Tel: 216-447-0464 Fax: 216-447-0643

Dallas

Addison, TX Tel: 972-818-7423 Fax: 972-818-2924

Detroit

Farmington Hills, MI Tel: 248-538-2250 Fax: 248-538-2260

Indianapolis Noblesville, IN

Tel: 317-773-8323 Fax: 317-773-5453

Los Angeles

Mission Viejo, CA Tel: 949-462-9523 Fax: 949-462-9608

Santa Clara

Santa Clara, CA Tel: 408-961-6444 Fax: 408-961-6445

Toronto

Mississauga, Ontario,

Canada

Tel: 905-673-0699 Fax: 905-673-6509

ASIA/PACIFIC

Asia Pacific Office

Suites 3707-14, 37th Floor Tower 6, The Gateway Harbour City, Kowloon Hong Kong

Tel: 852-2401-1200

Fax: 852-2401-3431

Australia - Sydney

Tel: 61-2-9868-6733 Fax: 61-2-9868-6755

China - Beijing

Tel: 86-10-8569-7000 Fax: 86-10-8528-2104

China - Chengdu Tel: 86-28-8665-5511

Fax: 86-28-8665-7889

China - Chongqing Tel: 86-23-8980-9588

Fax: 86-23-8980-9500 China - Hangzhou

Tel: 86-571-2819-3187 Fax: 86-571-2819-3189

China - Hong Kong SAR

Tel: 852-2401-1200 Fax: 852-2401-3431

China - Nanjing

Tel: 86-25-8473-2460 Fax: 86-25-8473-2470

China - Qingdao

Tel: 86-532-8502-7355 Fax: 86-532-8502-7205

China - Shanghai

Tel: 86-21-5407-5533 Fax: 86-21-5407-5066

China - Shenyang

Tel: 86-24-2334-2829 Fax: 86-24-2334-2393

China - Shenzhen

Tel: 86-755-8203-2660 Fax: 86-755-8203-1760

China - Wuhan

Tel: 86-27-5980-5300 Fax: 86-27-5980-5118

China - Xian

Tel: 86-29-8833-7252 Fax: 86-29-8833-7256

China - Xiamen

Tel: 86-592-2388138 Fax: 86-592-2388130

China - Zhuhai

Tel: 86-756-3210040 Fax: 86-756-3210049

ASIA/PACIFIC

India - Bangalore

Tel: 91-80-3090-4444 Fax: 91-80-3090-4123

India - New Delhi

Tel: 91-11-4160-8631 Fax: 91-11-4160-8632

India - Pune

Tel: 91-20-2566-1512 Fax: 91-20-2566-1513

Japan - Osaka

Tel: 81-66-152-7160 Fax: 81-66-152-9310

Japan - Yokohama

Tel: 81-45-471- 6166 Fax: 81-45-471-6122

Korea - Daegu

Tel: 82-53-744-4301 Fax: 82-53-744-4302

Korea - Seoul

Tel: 82-2-554-7200 Fax: 82-2-558-5932 or 82-2-558-5934

Malaysia - Kuala Lumpur

Tel: 60-3-6201-9857 Fax: 60-3-6201-9859

Malaysia - Penang

Tel: 60-4-227-8870 Fax: 60-4-227-4068

Philippines - Manila

Tel: 63-2-634-9065 Fax: 63-2-634-9069

Singapore

Tel: 65-6334-8870 Fax: 65-6334-8850

Taiwan - Hsin Chu

Tel: 886-3-5778-366 Fax: 886-3-5770-955

Taiwan - Kaohsiung

Tel: 886-7-536-4818 Fax: 886-7-330-9305

Taiwan - Taipei

Tel: 886-2-2500-6610 Fax: 886-2-2508-0102

Thailand - Bangkok

Tel: 66-2-694-1351 Fax: 66-2-694-1350

EUROPE

Austria - Wels

Tel: 43-7242-2244-39 Fax: 43-7242-2244-393

Denmark - Copenhagen

Tel: 45-4450-2828 Fax: 45-4485-2829

France - Paris

Tel: 33-1-69-53-63-20 Fax: 33-1-69-30-90-79

Germany - Munich

Tel: 49-89-627-144-0 Fax: 49-89-627-144-44

Italy - Milan

Tel: 39-0331-742611 Fax: 39-0331-466781

Netherlands - Drunen

Tel: 31-416-690399 Fax: 31-416-690340

Spain - Madrid

Tel: 34-91-708-08-90 Fax: 34-91-708-08-91

UK - Wokingham Tel: 44-118-921-5869

Fax: 44-118-921-5820

11/29/11