

Ready-to-Use Clinging Delimer

Reorder No. 469950 / 6-1 qt.





Features

- Clinging foam
- Concentrated strength
- Non-abrasive

Benefits

- Holds to vertical surfaces
- Removes scale quickly
- Will not harm surfaces

Recommended Uses

For descaling dishmachine equipment.

Specifications

- Light red
- No scent added
- Clear, non-viscous liquid
- High foam
- Less than 2.0 pH use dilution
- 2.8% phosphorus
- cRc approved

Important

Read and understand the label and Safety Data Sheet (SDS). These provide a description of hazards, precautions, personal protective equipment, first aid, 24 Hour Emergency lines, storage data and other safe handling information. The SDS is available using the QR code on the label and is also available from the distributor.

Product Directions

Equipment to use:

Trigger sprayer, sponge, cleaning cloth, paper towels.
NOTE: AVOID FUMES WHEN USING THIS PRODUCT.

Directions for use:

1. Make sure dishmachine is off.
2. Point sprayer directly onto surface to be descaled. Hold nozzle 8-10 inches from surface.
3. Spray over interior surface. Allow foam to work 10-15 minutes.
4. Spray area with clean water and insure the dish tank is drained and cleaned prior to use.
5. Wipe clean with wet cloth, sponge or paper towels. Be sure all foam is removed. Rinse.
6. Repeat if necessary. Do not use on aluminum.

(800) 968-6474 • gfs.com

©2020 Gordon Food Service®

Paper contains a minimum of 10% post-consumer waste fiber.

Gordon FOOD SERVICE
Always at your table™

L006922 01/20