

Concentrated Oven & Grill Cleaner & Degreaser

Reorder No. 184551 / 4-1 gal.





Features

- Non-abrasive formulation
- Institutional strength
- Solvent free
- Has built-in tracers

Benefits

- Does not scratch or abrade surfaces
- Low use cost, fast cleaning action
- Non-flammable
- Alerts operator to neutralize surface

Recommended Uses

For use on grills, ovens, hoods and other stainless surfaces.

Specifications

- Mauve color
- Bland scent/odor
- Clear, non-viscous liquid
- Low foam
- 10.5 - 13.0 pH use dilution
- Phosphorus 0.6%
- cRc approved

Important

Read and understand the label and Safety Data Sheet (SDS). These provide a description of hazards, precautions, personal protective equipment, first aid, 24 Hour Emergency lines, storage data and other safe handling information. The SDS is provided with each container shipped, it is also available from the distributor.

Product Directions

Equipment to use:

Spray bottle, clean cloth or towel.

Directions for use:

For oven and grills: 1. Remove heavy debris from oven or grill surface. 2. Raise or lower temperature of oven or grill to 150°F - 180°F. 3. In a plastic container, dilute 1 part of cleaner to 1 part of water. Spray or pour product on entire oven or grill surface. 4. IMMEDIATELY wipe oven or grill with cloth or non-abrasive pad. 5. Flush with a mild acid solution (vinegar and water). 6. Rinse thoroughly with clean water. 7. Reprocess grill with cooking oils to prevent sticking.
For deep fryers: 1. Drain oil and remove food debris. 2. Fill with water to grease line. 3. In a plastic container, dilute 4 ounces to 1 gallon of water. Add diluted product at 4 ounces to 1 gallon of water. 4. Bring to a low boil for 15 - 20 minutes. 5. Cool, brush, drain, and flush. Rinse and neutralize with a mild acid solution (vinegar and water), then drain. **Note:** Do not use on aluminum.

Distributed exclusively by Gordon Food Service®
1300 Genzon Parkway SW • Wyoming, MI • (800) 968-6474
©2015 Gordon Food Service® • gfs.com