```
Uart
 + blnitialize
 # cSendBuff
 # cReceyBuff
 - fd
 + Uart()
 + ~Uart()
 # Serial_Close()
 # Serial Open()
 # Serial Read()
 # Serial Send()
      ZigBee

    MsqBox

    iIndexBufferIn

    iIndexBufferOut

- bReadyToSend
+ ZigBee()
+ receive()
+ SendCommand()
```

+ SendConfig()
- ConfigZigBee()
- decodeTrame()
- GetConfigDrone()
- GetDroneError()
- GetDroneState()
- GetDroneTime()