Uart + blnitialize # cSendBuff # cReceyBuff - fd + Uart() + ~Uart() # Serial Close() # Serial_Open() # Serial Read() # Serial Send() ZigBee MsqBox iIndexBufferIn iIndexBufferOut bReadyToSend + ZigBee() + receive()

+ SendCommand() + SendConfig() - ConfigZigBee() - decodeTrame() - GetConfigDrone() - GetDroneError() - GetDroneState() - GetDroneTime()