## ТЕМА: 2.3.6. ПАНЕЛИ ГИПСОКАРТОНА

## DRYWALL PANELS

1. A. Use the QR-code and watch the video Installing Drywall Panels.



## B. Match the words and word combinations to their Russian equivalents.

1) cutout a) чертить

2) electrical box b) 1-образный угольник для разметки

3) trace c) вырез

4) keyhole saw d)контур

5) attach e) трещина

6) outline f) прикреплять

7) crack g) лобзик

8) dry wall screw h) электрощит

9) T-square i) саморез

## C. Watch the video Installing Drywall Panels again and put the steps of dry wall installation in the correct order.

- A. Now trace an outline of the electrical box at the appropriate position on the panel. Then cut with a keyhole saw.
- B. To create a cutout for things like an electrical outlet measure across from the point where the edge of the panel will rest to the near and far sides of the electrical box.
- C. Place the panel with the light coloured side up. Measure and mark where you need to cut. Using a T-square and a sharp utility knife score along the mark just deep enough to cut through the face paper and part of the core.
  - D. Fasten the panels to all ceiling joints and perimeter framing using drywall screws.
- E. Once the ceiling is completed apply the walls top panels first. Make sure their top edge is up tight against the ceiling panel.
- F. Once the walls top panels are installed install the bottom panels. Make sure you cut out the bottom panels accurately to leave a half inch gap between the panel and the floor.
  - G. Determine whether you're going to install your panels horizontally or vertically.
  - H. Measure your wall and ceiling surfaces and mark them down.
- D. Speak about dry wall installation according to the ex. 19. C.