

SPIKE 2 VS. SPIKE 3 ŞI DOWNGRADARE A HUB-ULUI

BY SANJAY AND ARVIND SESHAN

This lesson uses SPIKE 3 software

OBIECTIVELE LECȚIEI

Să învățăm cum să dăm downgrade la hub înapoi la SPIKE 2 (Legacy) dacă e necesar.	

CUM SĂ DAI DOWNGRADE LA HUB

PASUL 1: Urmărește instrucțiunile din instrumentarul de Downgrade, CU ATENȚIE:

https://spikelegacy.legoeducation.com/hubdowngrade/

PASUL 2: Mergi înapoi și instalează SPIKE App 2, numită acum SPIKE Legacy App.

PASUL 3: Deschide SPIKE 2 (LEGACY) și updatează Hub-ul așa cum este cerința din pop-up.

Hub-ul tău va fi acum un Hub SPIKE 2.

Citește diferențele dintre SPIKE 2 și SPIKE 3 aici:

(https://legoeducation.atlassian.net/servicedesk/customer/portal/3/article/36817141835)

Connect your Hub in Update Mode


- 1. Make sure the Hub is turned off.
- Hold down the Connection Button and plug in the USB cable.
- Keep holding the Connection Button until the Connection LED start blinking in multiple colors.
- 4. Press the "Open Connection Window" button below and select the hub in the device list





PROGRAMELE SPIKE 2 CARE SE POT DESCHIDE ÎN SPIKE 3

- În nota de lansare a SPIKE 3, se menţionează faptul că poţi deschide proiectele SPIKE 2 (Legacy) în aplicaţia SPIKE 3 App.
- la în considerare faptul că, dacă deschizi un proiect in SPIKE 2 Legacy, apare un pop-up care te avertizează că programul va funcționa diferit.
- Blocurile de cod s-au schimbat. Unele blocuri au fost înlăturate, unele au fost înlocuite cu blocuri alternative care pot sau nu să acționeze în același mod ca în codul original.



Fii atent la schimbările care au fost făcute în codul tău!!!

SPIKE Legacy (2.0.9)

Block	Synchronization	Speed Control	Stall Detection
move ↑ v for 10 rotations v	✓	✓	Permanently On
start moving at 50 50 % speed	✓	✓	Permanently On
start moving straight: 0 at 50 % power	X	X	Permanently On
A start motor	X	✓	Can be enabled/disabled
A ▼ start motor at -50 % power E ▼ start motor at 50 % power	X	X	Can be enabled/disabled

SPIKE 3 (3.2.0)


Block	Synchronization	Speed Control	Stall Detection
move ↑ ▼ for 10 rotations ▼	✓	✓	Permanently Off
start moving at 50 50 % speed	X	✓	Permanently Off
start moving straight: 0 at 50 % power	Block no longer exists		
A v start motor v	X	✓	Permanently On
A ▼ start motor at -50 % power E ▼ start motor at 50 % power	X	X	Permanently On




SPIKE Legacy (2.0.9)

Synchronization slows other motor down to match Rub against Rub against Hold motor Motor Rub against Rub against Rub against Rub against Rub against Motor Rub against Rub against Motor Rub ag

SPIKE 3 (3.2.0)




Notă: unele caracteristici sunt similare, altele nu așa cum se poate observa în graficele de mai sus.



SPIKE Legacy (2.0.9)


Line Graph Line G

SPIKE 3 (3.2.0)






SPIKE Legacy (2.0.9)



SPIKE 3 (3.2.0)

Block no longer exists



SPIKE Legacy (2.0.9)


Line Graph


MESSON

WESTON

WE

SPIKE 3 (3.2.0)






SPIKE Legacy (2.0.9)

Line Graph

INSTITUTE

INSTITUT

SPIKE 3 (3.2.0)



CREDITS

- Această lecție de SPIKE Prime a fost realizată de Sanjay Seshan și Arvind Seshan.
- Mai multe lecții sunt disponibile pe www.primelessons.org
- Această lecție a fost tradusă în limba romană de echipa de robotică FTC ROSOPHIA #21455 RO20



This work is licensed under a Creative Commons Attribution-NonCommercial-ShareAlike 4.0 International License.