REMOVING A HARD DISK FROM A PC

HDD & SSD

HOW TO REMOVE A HARD DRIVE

1. Power Off & Unplug
2. Remove the Battery (If Removable)
3. Flip the laptop over
4. Unscrew and carefully remove the panel



HOW TO REMOVE A HARD DRIVE (CONTINUES…)

5. Locate the Hard Drive
6. Disconnect the Drive
7. Remove the Screws & Slide Out the Drive




Kingston
240GB

UP NEXT...

CREATING A FORENSIC IMAGE