How to start spinning

Before starting to spin, you have to check that the drive wheels are parallel. Make a double check that all of the screws are tightened enough. It is also recommended that the humidity in the room is approximately 60% to work with maschine.

1. Set the starting thread

put the scrap thread into the bottom of the bobbin, then attach the bobbin to the spindle carrier.




2. Wrap the yarn around the cone

Rotate the bobbin with the thread until the thread is on the same height as the traveler. Then put the thread through the hook.



3. Pass the thread through the yarn traveler

pass the thread through the yarn outlet and pause it on the side.




4. Prepare the roving (fibres)

Put the roving neatly behind the maschine. Make sure that the roving has no knot and there is nothing in the way.




5. Set the roving (back)

Put the roving through the back Yarn Guide of the machine and guide them on the drive wheel to the front.




6. Set the roving (front)

Then put the roving through the front Yarn Guide and on the front drive wheel.



7. Put the thread and roving together.

Connect the thread coming from the hook with the roving and twist them a few times with your fingers.



8. Close it.

Close the upper arm with the velcro. Make sure that the roving is between wheels.

