


ITEM 62P1-M

Performance Data	Value							
Output (kW)	22							
Pole	2							
Full Load speed (RPM)								
Full Load Torque (Nm)	71.1							
Full load current @ 380V (A)	40							
Full load current @ 400V (A)	38							
Full load current @ 415V (A)	38							
Efficiency Full load (%)	90.5							
Efficency 3/4 load (%)	89.7							
Efficiency 1/2 load (%)	87.3							
Power Factor Full load	0.93							
Power factor 3/4 load	0.87							
Power Factor 1/2 load	0.8							
Direct on line starting torque ratio	2.5							
Direct on line starting current ratio	7.3							
Direct on line Pull out torque ratio	3.3							
Direct on line Pull up torque ratio	1.4							
Rotor inertia (kgm²)	0.075							
Mean sound pressure @1m on no load (dB(A))	81							



ITEM 62P1-M



IM B3/IM 1001 Foot Dimensions

Α	В	С	н	K	L	AA	AB	вв	НА	AC	HD	HD1	TBW	твн	KK
279	241	121	180	15	700	74	350	295	22	380	445	396	164	200	2 x M40

Shaft drive end dimensions

D	E	F	G	GD	ЕВ	DH	ED
48	110	14	42.5	9	90	M16	15

Shipping Specification


Net Weight	174Kg
Gross Weight	184Kg
Cubage Volume	0.23m ³



ITEM 63P2A-M

Performance Data	Value							
Output (kW)	55							
Pole	2							
Full Load speed (RPM)								
Full Load Torque (Nm)	177							
Full load current @ 380V (A)	100							
Full load current @ 400V (A)	95							
Full load current @ 415V (A)	91							
Efficiency Full load (%)	93							
Efficency 3/4 load (%)								
Efficiency 1/2 load (%)	91.4							
Power Factor Full load	0.9							
Power factor 3/4 load	0.89							
Power Factor 1/2 load	0.84							
Direct on line starting torque ratio	2.6							
Direct on line starting current ratio	7.6							
Direct on line Pull out torque ratio	3.6							
Direct on line Pull up torque ratio	1.9							
Rotor inertia (kgm²)	0.312							
Mean sound pressure @1m on no load (dB(A))	86							





IM B3/IM 1001 Foot Dimensions

A		В	С	Н	K	L	AA	AB	вв	НА	AC	HD	HD1	TBW	твн	KK
40	06	349	168	250	24	945	100	486	512	33	512	625	562	221	290	2 x M63

Shaft drive end dimensions

D	E	F	G	GD	EB	DH	ED
60	140	18	53	11	110	M20 x 42	25

Shipping Specification

onipping specification						
Net Weight	535Kg					
Gross Weight	585Kg					
Cubage Volume	0.6m ³					




ITEM 63P2B-M

Performance Data	Value							
Output (kW)	55							
Pole	2							
Full Load speed (RPM)								
Full Load Torque (Nm)	177							
Full load current @ 380V (A)	100							
Full load current @ 400V (A)	95							
Full load current @ 415V (A)	91							
Efficiency Full load (%)	93							
Efficency 3/4 load (%)								
Efficiency 1/2 load (%)	91.4							
Power Factor Full load	0.9							
Power factor 3/4 load	0.89							
Power Factor 1/2 load	0.84							
Direct on line starting torque ratio	2.6							
Direct on line starting current ratio	7.6							
Direct on line Pull out torque ratio	3.6							
Direct on line Pull up torque ratio	1.9							
Rotor inertia (kgm²)	0.312							
Mean sound pressure @1m on no load (dB(A))	86							

BROOKCROMPTON

ITEM 63P2B-M



IM B3/IM 1001 Foot Dimensions

A	В	С	Н	K	L	AA	АВ	вв	НА	AC	HD	HD1	TBW	твн	KK
406	349	168	250	24	945	100	486	512	33	512	625	562	221	290	2 x M63

Shaft drive end dimensions

D	E	F	G	GD	ЕВ	DH	ED
60	140	18	53	11	110	M20 x 42	25

Shipping Specification

ompping opcome	u 1		
Net Weight	535Kg		
Gross Weight	585Kg		
Cubage Volume	0.6m ³		




ITEM 63P4A-M

Performance Data	Value					
Output (kW)	55					
Pole						
Full Load speed (RPM)						
Full Load Torque (Nm)	177					
Full load current @ 380V (A)	100					
Full load current @ 400V (A)	95					
Full load current @ 415V (A)	91					
Efficiency Full load (%)						
Efficency 3/4 load (%)						
Efficiency 1/2 load (%)						
Power Factor Full load	0.9					
Power factor 3/4 load	0.89					
Power Factor 1/2 load	0.84					
Direct on line starting torque ratio	2.6					
Direct on line starting current ratio	7.6					
Direct on line Pull out torque ratio	3.6					
Direct on line Pull up torque ratio						
Rotor inertia (kgm²)	0.312					
Mean sound pressure @1m on no load (dB(A))	86					

BROOKCROMPTON

ITEM 63P4A-M



IM B3/IM 1001 Foot Dimensions

A	В	С	Н	K	L	AA	АВ	вв	НА	AC	HD	HD1	TBW	твн	KK
406	349	168	250	24	945	100	486	512	33	512	625	562	221	290	2 x M63

Shaft drive end dimensions

	D	E	F	G	GD	ЕВ	DH	ED
l	60	140	18	53	11	110	M20 x 42	25

Shipping Specification

simpping opcomouncin						
Net Weight	535Kg					
Gross Weight	585Kg					
Cubage Volume	0.6m ³					




ITEM 63P4B-M

Performance Data	Value					
Output (kW)	55					
Pole						
Full Load speed (RPM)						
Full Load Torque (Nm)	177					
Full load current @ 380V (A)	100					
Full load current @ 400V (A)	95					
Full load current @ 415V (A)	91					
Efficiency Full load (%)						
Efficency 3/4 load (%)						
Efficiency 1/2 load (%)						
Power Factor Full load	0.9					
Power factor 3/4 load	0.89					
Power Factor 1/2 load	0.84					
Direct on line starting torque ratio	2.6					
Direct on line starting current ratio	7.6					
Direct on line Pull out torque ratio						
Direct on line Pull up torque ratio						
Rotor inertia (kgm²)						
Mean sound pressure @1m on no load (dB(A))	86					

ITEM 63P4B-M





IM B3/IM 1001 Foot Dimensions

A	В	С	Н	K	L	AA	AB	вв	НА	AC	HD	HD1	TBW	твн	KK
406	349	168	250	24	945	100	486	512	33	512	625	562	221	290	2 x M63

Shaft drive end dimensions

D	E	F	G	GD	ЕВ	DH	ED
60	140	18	53	11	110	M20 x 42	25

Shipping Specification


Net Weight	535Kg
Gross Weight	585Kg
Cubage Volume	0.6m ³



ITEM 63P5-M

Performance Data	Value						
Output (kW)	18.5						
Pole	2						
Full Load speed (RPM)							
Full Load Torque (Nm)	60.3						
Full load current @ 380V (A)	36						
Full load current @ 400V (A)	34						
Full load current @ 415V (A)	34						
Efficiency Full load (%)							
Efficency 3/4 load (%)							
Efficiency 1/2 load (%)							
Power Factor Full load	0.87						
Power factor 3/4 load	0.84						
Power Factor 1/2 load	0.81						
Direct on line starting torque ratio	2.4						
Direct on line starting current ratio	7.2						
Direct on line Pull out torque ratio							
Direct on line Pull up torque ratio							
Rotor inertia (kgm²)	0.055						
Mean sound pressure @1m on no load (dB(A))	79						





IM B3/IM 1001 Foot Dimensions

A	В	С	Н	К	L	AA	АВ	вв	НА	AC	HD	HD1	TBW	твн	KK
254	254	108	160	18 x 15	655	54	308	304	20	335	410	359	170	205	2 x M40


Shaft drive end dimensions

D	E	F	G	GD	ЕВ	DH	ED
42	110	12	37	8	90	M16	15

Shipping Specification

Net Weight	122Kg
Gross Weight	129Kg
Cubage Volume	0.17m ³

Shaft drive end






ITEM 63P6-M

Performance Data	Value
Output (kW)	11
Pole	4
Full load speed (RPM)	1450
Full Load Torque (Nm)	72.4
Full load current @ 380V (A)	23.0
Full load current @ 400V (A)	21.6
Full load current @ 415V (A)	21.6
Efficiency Full load (%)	88.4
Efficency 3/4 load (%)	88.9
Efficiency 1/2 load (%)	87.9
Power Factor Full load	0.85
Power factor 3/4 load	0.81
Power Factor 1/2 load	0.72
Direct on line starting torque ratio	2.4
Direct on line starting current ratio	6.4
Direct on line Pull out torque ratio	3.1
Direct on line Pull up torque ratio	2.1
Rotor inertia (kgm²)	0.062
Mean sound pressure @1m on no load (dB(A))	64

ITEM 63P6-M

BROOKCROMPTON



IM B3/IM 1001 Foot Dimensions

Α	В	С	Н	K	L	AA	АВ	вв	НА	AC	HD	HD1	TBW	твн	KK
254	210	108	160	18 x 15	655	54	308	260	20	335	410	359	170	205	2 x M40


Shaft drive end dimensions

D	E	F	G	GD	EB	DH	ED
42	110	12	37	8	90	M16	15

Shipping Specification

Net Weight	107Kg
Gross Weight	114Kg
Cubage Volume	0.17m ³

Shaft drive end




ITEM 64P1-M



Performance Data	Value
Output (kW)	22
Pole	2
Full load speed (RPM)	2954
Full Load Torque (Nm)	71.1
Full load current @ 380V (A)	40
Full load current @ 400V (A)	38
Full load current @ 415V (A)	38
Efficiency Full load (%)	90.5
Efficency 3/4 load (%)	89.7
Efficiency 1/2 load (%)	87.3
Power Factor Full load	0.93
Power factor 3/4 load	0.87
Power Factor 1/2 load	0.8
Direct on line starting torque ratio	2.5
Direct on line starting current ratio	7.3
Direct on line Pull out torque ratio	3.3
Direct on line Pull up torque ratio	1.4
Rotor inertia (kgm²)	0.075
Mean sound pressure @1m on no load (dB(A))	81

ITEM 64P1-M





IM B3/IM 1001 Foot Dimensions

A	В	С	Н	К	L	AA	АВ	вв	НА	AC	HD	HD1	TBW	твн	кк
279	241	121	180	18 x 15	710	61	340	301	25	380	455	402	170	205	2 x M40


Shaft drive end dimensions

D			G	GD	ЕВ	DH	ED
48	110	14	42.5	9	90	M16	15

Shipping Specification

Net Weight	145Kg
Gross Weight	155Kg
Cubage Volume	0.23m ³

Shaft drive end





ITEM 65MX1-M

Performance Data


Performance Data	Value
Output (kW)	7.5
Pole	4
Full Load speed (RPM)	1445
Full Load Torque (Nm)	49.6
Full load current @ 380V (A)	15.4
Full load current @ 400V (A)	14.6
Full load current @ 415V (A)	14.6
Efficiency Full load (%)	87.1
Efficency 3/4 load (%)	87.4
Efficiency 1/2 load (%)	86.8
Power Factor Full load	0.85
Power factor 3/4 load	0.79
Power Factor 1/2 load	0.74
Direct on line starting torque ratio	2.4
Direct on line starting current ratio	7.1
Direct on line Pull out torque ratio	3
Direct on line Pull up torque ratio	2.3
Rotor inertia (kgm²)	0.0296
Mean sound pressure @1m on no load (dB(A))	58

Motor fitted with threephase forced ventiltion Volt 220-380 50 Hz Watt 95 Amp 0,52-0,30

PTC in Winding

BROOKCROMPTON

ITEM 65MX1-M



IM B3/IM 1001 Foot Dimensions

A	В	С	Н	К	L	AA	AB	вв	НА	AC	HD	HD1	TBW	твн	кк
216	178	89	132	15 x 12	515	50	260	230	15	275	327	289	122	122	2 x M32

IM B5/IM 3001 Flange dimensions

M	N	Р	S	Т	LA
265	230	300	14.5	4	13


Shaft drive end dimensions

D	E	F	G	GD	ЕВ	DH	ED
38	80	10	33	8	63	M12	12

Shipping Specification

Net Weight	67Kg
Gross Weight	74Kg
Cubage Volume	0.09m ³

Shaft drive end





ITEM 62CL1-M

Performance Data	Value
Output (kW)	5,5 / 2,7
Pole	4/8
Full Load speed (RPM)	1415/720
Full Load Torque (Nm)	49.6
Full load current @ 380V (A)	12/9
Full load current @	
Full load current @	
Efficiency Full load (%)	82/78
Efficency 3/4 load (%)	
Efficiency 1/2 load (%)	
Power Factor Full load	0.91 /0,67
Power factor 3/4 load	
Power Factor 1/2 load	
Direct on line starting torque ratio	2/2,5
Direct on line starting current ratio	7/5,7
Rotor inertia (kgm²)	0.0400
Mean sound pressure @1m on no load (dB(A))	55


ITEM 62CL1-M


BROOKCROMPTON


Face mounted IM B14/IM 3601


Flange mounted IM B5/IM 3001


Foot mounted IM B3/IM 1001














(1) 8 holes at 22.5° for flanges to suit 225 frames and above to European specification 8 holes at 0° for flanges to suit 225 frames and above to British specification

IM B3/IM 1001 Foot Dimensions

A	В	С	Н	K	L	AA	AB	вв	НА	AC	HD	HD1	TBW	твн	KK
216	178	89	132	15 x 12	515	50	260	230	15	275	327	289	122	122	2 x M32

IM B5/IM 3001 Flange dimensions

М	N	Р	s	Т	LA
265	230	300	14.5	4	13


Shaft drive end dimensions

D	E	F	G	GD	ЕВ	DH	ED
38	80	10	33	8	63	M12	12

Shipping Specification

Net Weight	67Kg
Gross Weight	74Kg
Cubage Volume	0.09m ³

Shaft drive end





ITEM 62CL2-M

Performance Data	Value
Output (kW)	5,5 / 2,7
Pole	4/8
Full Load speed (RPM)	1415/720
Full Load Torque (Nm)	49.6
Full load current @ 380V (A)	12/9
Full load current @	
Full load current @	
Efficiency Full load (%)	82/78
Efficency 3/4 load (%)	
Efficiency 1/2 load (%)	
Power Factor Full load	0.91 /0,67
Power factor 3/4 load	
Power Factor 1/2 load	
Direct on line starting torque ratio	2/2,5
Direct on line starting current ratio	7/5,7
Rotor inertia (kgm²)	0.0400
Mean sound pressure @1m on no load (dB(A))	55

BROOKCROMPTON

ITEM 62CL2-M

Flange mounted Face mounted Foot mounted IM B5/IM 3001 IM B14/IM 3601 IM B3/IM 1001 TBW EB ED Ø KK B CRS BB ØAC твн HOLES ØS ON M PCD (1) HOLES ØS ত ᅙ (() Ø A CRS

IM B3/IM 1001 Foot Dimensions

A	В	С	Н	К	L	AA	AB	вв	НА	AC	HD	HD1	TBW	твн	KK
216	178	89	132	15 x 12	515	50	260	230	15	275	327	289	122	122	2 x M32

(1) 8 holes at 22.5° for flanges to suit 225 frames and above to European specification

8 holes at 0° for flanges to suit 225 frames and above to British specification

IM B5/IM 3001 Flange dimensions

М	N	Р	S	Т	LA
265	230	300	14.5	4	13

Shaft drive end dimensions


D	E	F	G	GD	ЕВ	DH	ED
38	80	10	33	8	63	M12	12

Shipping Specification

Net Weight	67Kg
Gross Weight	74Kg
Cubage Volume	0.09m ³

Shaft drive end

AB





ITEM 62CL3-M

Performance Data	Value
Output (kW)	5,5 / 2,7
Pole	4/8
Full Load speed (RPM)	1415/720
Full Load Torque (Nm)	49.6
Full load current @ 380V (A)	12/9
Full load current @	
Full load current @	
Efficiency Full load (%)	82/78
Efficency 3/4 load (%)	
Efficiency 1/2 load (%)	
Power Factor Full load	0.91 /0,67
Power factor 3/4 load	
Power Factor 1/2 load	
Direct on line starting torque ratio	2/2,5
Direct on line starting current ratio	7/5,7
Rotor inertia (kgm²)	0.0400
Mean sound pressure @1m on no load (dB(A))	55

BROOKCROMPTON

ITEM 62CL3-M

Face mounted Flange mounted Foot mounted IM B5/IM 3001 IM B14/IM 3601 IM B3/IM 1001 TBW EB ED ØKK 0 B CRS BB ØAC TBH HOLES ØS ON M PCD (1) HOLES ØS ଫ Ø (**6**) A CRS

IM B3/IM 1001 Foot Dimensions

Α	В	С	Н	К	L	AA	AB	вв	НА	AC	HD	HD1	TBW	твн	кк
216	178	89	132	15 x 12	515	50	260	230	15	275	327	289	122	122	2 x M32

(1) 8 holes at 22.5° for flanges to suit 225 frames and above to European specification

8 holes at 0° for flanges to suit 225 frames and above to British specification

IM B5/IM 3001 Flange dimensions

М	N	Р	S	Т	LA
265	230	300	14.5	4	13

Shaft drive end dimensions


D	E	F	G	GD	ЕВ	DH	ED
38	80	10	33	8	63	M12	12

Shipping Specification

omponing opecimication							
Net Weight	67Kg						
Gross Weight	74Kg						
Cubage Volume	0.09m^3						

Shaft drive end

AB






ITEM 64K6-M

Performance Data	Value
Output (kW)	18.5
Pole	2
Full load speed (RPM)	2930
Full Load Torque (Nm)	60.3
Full load current @ 380V (A)	36
Full load current @ 400V (A)	34
Full load current @ 415V (A)	34
Efficiency Full load (%)	90.3
Efficency 3/4 load (%)	90.3
Efficiency 1/2 load (%)	89.1
Power Factor Full load	0.87
Power factor 3/4 load	0.84
Power Factor 1/2 load	0.81
Direct on line starting torque ratio	2.4
Direct on line starting current ratio	7.2
Direct on line Pull out torque ratio	3.2
Direct on line Pull up torque ratio	1.8
Rotor inertia (kgm²)	0.055
Mean sound pressure @1m on no load (dB(A))	79


BROOKCROMPTON


ITEM 64K6-M





Flange mounted IM B5/IM 3001


Foot mounted IM B3/IM 1001











(1) 8 holes at 22.5° for flanges to suit 225 frames and above to European specification 8 holes at 0° for flanges to suit 225 frames and above to British specification

IM B3/IM 1001 Foot Dimensions

A	В	С	Н	K	L	AA	AB	вв	НА	AC	HD	HD1	TBW	твн	KK
254	254	108	160	18 x 15	655	54	308	304	20	335	410	359	170	205	2 x M40


Shaft drive end dimensions

D	E	F	G	GD	EB	DH	ED
42	110	12	37	8	90	M16	15

Shipping Specification

Net Weight	122Kg
Gross Weight	129Kg
Cubage Volume	0.17m ³

Shaft drive end






ITEM 64K7-M

Performance Data	Value
Output (kW)	18.5
Pole	2
Full Load speed (RPM)	2930
Full Load Torque (Nm)	60.3
Full load current @ 380V (A)	36
Full load current @ 400V (A)	34
Full load current @ 415V (A)	34
Efficiency Full load (%)	90.3
Efficency 3/4 load (%)	90.3
Efficiency 1/2 load (%)	89.1
Power Factor Full load	0.87
Power factor 3/4 load	0.84
Power Factor 1/2 load	0.81
Direct on line starting torque ratio	2.4
Direct on line starting current ratio	7.2
Direct on line Pull out torque ratio	3.2
Direct on line Pull up torque ratio	1.8
Rotor inertia (kgm²)	0.055
Mean sound pressure @1m on no load (dB(A))	79


BROOKCROMPTON


ITEM 64K7-M





Flange mounted IM B5/IM 3001


Foot mounted IM B3/IM 1001














(1) 8 holes at 22.5° for flanges to suit 225 frames and above to European specification 8 holes at 0° for flanges to suit 225 frames and above to British specification

IM B3/IM 1001 Foot Dimensions

A	В	С	Н	K	L	AA	AB	вв	НА	AC	HD	HD1	TBW	твн	KK
254	254	108	160	18 x 15	655	54	308	304	20	335	410	359	170	205	2 x M40


Shaft drive end dimensions

D	E	F	G	GD	EB	DH	ED
42	110	12	37	8	90	M16	15

Shipping Specification

Net Weight	122Kg
Gross Weight	129Kg
Cubage Volume	0.17m ³

Shaft drive end






ITEM 64N1-M

Performance Data	Value
Output (kW)	3
Pole	4
Full Load speed (RPM)	1415
Full Load Torque (Nm)	20.2
Full load current @ 380V (A)	6.7
Full load current @ 400V (A)	6.4
Full load current @ 415V (A)	6.4
Efficiency Full load (%)	82.6
Efficency 3/4 load (%)	84.2
Efficiency 1/2 load (%)	84.2
Power Factor Full load	0.82
Power factor 3/4 load	0.75
Power Factor 1/2 load	0.64
Direct on line starting torque ratio	2.4
Direct on line starting current ratio	5.3
Direct on line Pull out torque ratio	3
Direct on line Pull up torque ratio	2.4
Rotor inertia (kgm²)	0.007
Mean sound pressure @1m on no load (dB(A))	54


BROOK CROMPTON


ITEM 64N1-M





Flange mounted IM B5/IM 3001


Foot mounted IM B3/IM 1001











(1) 8 holes at 22.5° for flanges to suit 225 frames and above to European specification 8 holes at 0° for flanges to suit 225 frames and above to British specification

IM B3/IM 1001 Foot Dimensions

Α	В	С	Н	К	L	AA	АВ	вв	НА	AC	HD	HD1	TBW	твн	KK
160	140	63	100	15 x 12	385	40	200	180	12	210	270	225	122	122	2 x M32

IM B5/IM 3001 Flange dimensions

М	N	Р	s	Т	LA
215	180	250	14.5	4	11


Shaft drive end


Shaft drive end dimensions

D	E	F	G	GD	ЕВ	DH	ED
28	60	8	24	7	45	M10	10

Shipping Specification

ompping opeomounem				
Net Weight	28Kg			
Gross Weight	29Kg			
Cubage Volume	0.04m ³			





DIRECT ON DELTA (△)
DÉMARRAGE DIRECT TRIANGLE
DIREKTE EINSCHALTUNG IN DREIECK
AVVIAMENTO CIDRETTO TRIANGOLO

STAR-DELTA STARTING (YA)

DÉMARRAGE ÉTOILE-TRIANGLE STERN-DREIECK-ANLAUF

AUVIAMENTO STELLA/TRIANGOLO


STAR-DELTA DÉMARRAGE -ETOILE STERN-DREIECK AUVIAMENTO STELLA

TO REVERSE DIRECTION OF ROTATION CHANGE OVER ANY TWO SUPPLY LINES

POUR INVERSER LE SENS DE ROTATION CROISEZ DEUX DES CABLES D'ALIMENTATION

ZUR UMKEHRUNG DER DREHRICHTUNG 2 BELIEBIGE NETZLEITUNGEN TAUSCHEN

PER CAMBIARE IL SENSO DI ROTAZIONE INVERTIRE DUE FILI DI LINEA



TO STAR-DELTA STARTER
DÉMARRAGE ÉTOILE-TRIANGLE
MIT STERN-DREIECK-SCHALTER VERBINDEN
AVVIAMENTO STELLA/TRIANGOLO

AUXILIARIES (WHEN FITTED) ARE MARKED AS SHOWN BELOW AUXILIAIRES (SI POURVUS) SONT MARQUÉS SELON LES DÉSIGNATIONS SUIVANTES HILFSEINRICHTUNGEN (FALLS VORHANDEN) WERDEN WIE UNTEN AUFGEFÜHRT MARKIERT LE APPARECCHIATURE AUSILIARE (QUANDO SONO INSTALLATE) VENDONO INDICATE COME SEGUE



HEATERS CONNECT TO SINGLE PHASE VOLTAGE

RECHAUFFEUR RELIER A L'ALIMENTION DE TENSION MONOPHASÉE

STILLSTANDS HEIZUNG VERBINDEN MIT EINPHASEN SPANNUNGSVERSORGUNG

RESISTENZA DI RISCALDAM COLLEGAMENTO AD UNA FASE DELLA LINEA DI ALIMENTAZIONE



THERMISTORS
CONNECT TO THERMISTOR CONTROL
UNIT

THERMISTANCES RELIER AU BLOC DE CONTRÔLE DES THERMISTANCES

KALTLEITER NACH DIN 44087/44082 MIT AUSLÖSEGARÄT VERBINDEN

TERMISTORI
COLLEGARE TERMISTORI ALLA UNITA
DI CONTROLLO



THERMOSTATS
CONNECT TO OVERLOAD PROTECTION
CIRCUIT

THERMOSTATS
RELIER AU CIRCUIT DE PROTECTION
CONTRE LES SURCHARGES

THERMOKONTAKT (MAX 240V AC) VERBINDEN MIT STEUERSTROMKREIS

TERMOSTATO
COLLEGARE TERMOSTATO CONTRO
SOVRACCARICHI ALLA
APPARECCHIATURA

EARLY WARNING AVERTISSEMENT ANTICIPÉ FRÜH WARNUNG PRE ALLARME



THERMISTORS
CONNECT TO THERMISTOR CONTROL
UNIT

KALTLEITER NACH DIN 44067/44062 MIT AUSLÜSEGARÄT VERBINDEN OVERLOAD SURCHARGE ÜBERLAST SOVRACCARICO



THERMISTANCES
RELIER AU BLOC DE CONTRÔLE DES
THERMISTANCES

TERMISTORI
COLLEGARE TERMISTORI ALLA UNITA
DI CONTROLLO

BROOKCROMPTON

DRG. No.

WB+AUX/0

REVISION:

DATE:

	NAME	DATE
DRAWN	DH	30-10-03
CHECKED	GES	30-10-03

DECLARACION OF CONFORMITY

phone: +48 14 632 11 00 fax: +48 14 621 96 64 E-mail: officetamel@tamel.pl Internet: www.tamel.pl

FACTORY OF ELECTRIC MOTORS

Elektryczna 6, 33-100 Tarnów, Poland

Date: 09-04-2010

We declare that AC induction machines manufactured by our group companies, having open or totally enclosed construction to all standard IP protection and IC cooling forms, with outputs up to 400 kW:

Are in conformance with the relevant sections of EN60034-1, having imperial or metric frame designations and dimensions, in the voltage range: 50 to 1000 volts ac and therefore follow the provisions of the Low Voltage Directive (2005/95/WE).

When installed in accordance with our customer safety and installation and maintenance instructions, they can be put into service only when the machinery into which they are being incorporated, has been declared to be in conformity with the machinery directive 2006/42/WE

When operated from a correctly applied AC (sinusoidal) supply, AC induction machines are in compliance with the essential requirements of the Electromagnetic Compatibility Directive (2008/108/WE), they comply with the essential requirements of this Directive, and that electromagnetic emission and immunity levels are within the limits defined in EN60034-1.

Variable speed motors, with integral frequency converters, conform with the essential requirements of this Directive and associated standards, provided that the product is used in accordance with our installation, filtering and maintenance instructions.


Rafal Halon
Chief Design Engineer






CONNECTION DIAGRAM FOR 3 PHASE INDUCTION MOTOR

NO. 14 TWO SPEED - TWO WINDING TYPE (Y/Y)



TO REVERSE DIRECTION OF ROTATION CHANGE OVER ANY 2 SUPPLY LEADS

AUXILIARIES (WHEN FITTED) ARE MARKED AS SHOWN BELOW



NOTES. REFER TO NAMEPLATE FOR SUPPLY VOLTAGE.
LETTER(S) FOLLOWING MAIN DIAGRAM No. DENOTE AUXILIARIES.

Spare parts, installation and maintenance of ac motors





Contents

Introduction

Pre-installation requirements

Warning

Receipt

Lifting

Eyebolt/lifting lug bolt torques

Motor weights

Storage

Environment

Drain holes

Bearings

Grease

Heaters

Insulation resistance

Wound rotors

Installation

General

Location

Mechanical installation

Drain holes

Alignment

Noise levels

Free rotation

Slide rails

Electrical connection

Cable terminations

Drying out procedures

Supply

Earthing

Heater/thermistor continuity

Auxilliary electrical items

Control gear

Connection diagrams

Rotation

Wound rotors

Starting/running

Motor modifications

Endshield/foot fixing torques

Maintenance

On-going maintenance

Periodic maintenance

Wound rotor

Hazardous area motors

Enquiry and policy

Spare parts, installation and maintenance

Appendices

Slide rail dimensions

TEFV relubrication or replacement

Installation and maintenance of ac electric induction motors

Introduction

Your Brook Crompton motor is designed for long life, and low running costs. Careful installation and maintenance will ensure that you achieve reliable operation and optimum efficiency.

Pre-installation requirements

MARNING

Handling and lifting of electric motors must only be undertaken by authorised personnel. Full product documentation and operating instructions must be available together with tools and equipment necessary for safe working practice.

Receipt

Before any motor is accepted on site it should be inspected carefully for damage or loss incurred during transit.

Packing materials may be damaged including sheeting and crate timbers.

Handling operations may have damaged fan cowls, terminal boxes or auxiliaries.

Where an instance of droppage or loss is evident or suspected, it may be necessary to unpack the goods to establish the full extent of the problem.

Wherever possible, damage should be recorded, photographed and witnessed.

Report any damage to the carriers and Brook Crompton as soon as possible, quoting the motor number and consignment note reference. The insurance company's agents shown on the insurance certificate should also be advised.

A Lifting

Eyebolts and/or lifting trunnions supplied with the motor are designed to support only the weight of the motor, not the weight of the motor and any ancillary equipment attached to it. Be absolutely sure that cranes, jacks, slings and lifting beams are capable of carrying the weight of equipment to be lifted.

Where an eyebolt is provided with the motor, this should be screwed down until its shoulder is firmly against the face of the stator frame to be lifted. Eyebolts are normally designed for a vertical lift. For eyebolt/lifting lug torques, see opposite.

Туре		Eyebolt dia	Cast ire	on frames
Metric	NEMA/ CSA	Lifting lug bolt dia*	To Nm	rque Lbf.FT
63	_	_	_	_
71	_	_	_	_
80	56	-	_	_
90S/L	143/145	_	_	_
100L	_	_	_	_
112M	182/184	M12 [†]	_	_
132S/M	213/215	M12 [†]	_	_
160M/L	254/256	M12 [†]	_	_
180M/L	284/286	M16 [†]	_	_
200L	324	M10*	52	38
225S	326	M10*	52	38
225M	364	M10*	52	38
250S	365	M10*	52	38
250M	404	M16*	220	162
280S	405	M16*	220	162
280M	444	M16*	220	162
315S	445	M16*	220	162
315M	504	M20*	400	295
315L	505	M20*	400	295
355M/L	585/6/7	M20*	400	295

- * W-DF design only. Lifting lugs secured with bolts and nuts. High tensile socket headed bolts and special square nuts must be used
- † The eyebolt should be firmly screwed down (without over tightening), to ensure that the collar is fully seated

Where two eyebolts/lifting lugs are used with inclined loading, the maximum safe working loads of BS 4278: 1984 should not be exceeded (ISO 3266).

Tables of approximate weights

Frames DF80-L			
Туре	•	Gross weigh	nt Cubage
	kg	kg	m ³
DF80M	15	16.5	0.02
DF90S	19	20.5	0.03
DF90L	22	23.5	0.03

Cast iron constru			
Туре	Net weight (Gross weigh kg	t Cubage m ³
W-DF100L	35.	38	.03
W-DF112M	45	48	0.05
W-DF132S/M	72.5	78.5	0.08
W-DF160M/L	133	145	0.15
W-DF180M/L	177.5	193.5	0.21
W-DF200L	255	270	0.30
W-DF225S	320	335	0.37
W-DF225M	375	390	0.37
W-DF250S	420	460	0.63
W-DF250M	570	610	0.70
W-DF280S	660	721	1.2
W-DF280M	800	871	1.2
W-DF315S	1000	1095	1.8
W-DF315M	1100	1195	1.8
W-DF315L	1300	1395	1.8
W-DF355S	2000	2120	2.3
W-DF355M	2300	2420	2.3

Туре	Net weight	Gross weigi	
	kg	kg	m ³
DA63	5	5.4	0.010
W-DA71	6	6.4	0.010
W-DA80	9	10	0.020
W-DA90S	12.5	13.5	0.030
W-DA90L	14.5	15.5	0.030
W-DA100L	19	21	0.038
W-DA112M	27	29	0.050
W-DA132S	38	41	0.071
W-DA132M	46	49	0.076
W-DA160M	80	95	0.125
W-DA160L	100	112	0.125
W-DA180M	140	165	0.253
W-DA180L	148	174	0.253

2500

2620

23

W-DF355L

Туре	Net weight	Gross weigh	
	kg	kg	m ³
K-CF225M	378	411	0.37
K-CF250S	391	446	0.63
K-CF250M	444	499	0.70
K-CF280S	536	602	1.2
K-CF280M	633	699	1.2
K-CF315S	801	885	1.8
K-CF315M	916	1000	2.3

Storage

If motors have to be stored before installation, precautions should be taken to prevent deterioration.

Environment

Depending on the site conditions it may be necessary to create a suitable stores area to hold the motor prior to installation. Packing cases are not waterproof.

Motors should be stored in a dry, vibration free and clean area at normal ambients (–20°C to 40°C), unless other arrangements have been agreed with Brook Crompton.

Where low temperature ambient storage is anticipated, special precautions should be taken with the type of grease, no plastic parts etc. to ensure trouble free start-up.

Motors must be stored away from corrosive or chemically damaging fumes.

Before placing motors into storage, machined components should be carefully inspected. Bearings and shafts are normally covered with a corrosion resistive barrier. If this coating is damaged it should be made good. The component should be cleaned and the protective coating reapplied.

Under no circumstances should rust be merely covered over.

Drain holes

Motors provided with drain holes have drain plugs provided loose in the terminal box up to frame size 180, and fitted on frames size 200 and above. Position the drain holes at the lowest point.

Bearings

To avoid static indentation the storage area should be vibration free. If this is not possible it is strongly recommended that the motors be stood on thick blocks of rubber or other soft material.

Shafts should be rotated by hand one quarter of a revolution weekly.

Where the exposure to some vibration is unavoidable the shaft should be locked in position to avoid static indentation of the bearings. Roller bearings may be fitted with a shaft locking device. This should be kept in place during storage.

Grease

Factory fitted bearings use a lithium based grease with a recommended shelf life of two years. If stored for a longer period, grease may need to be replaced.*

Shielded bearings have a storage life of five years and a further two years operational life following installation.

* Wash all bearing parts with a noncontaminating solvent. Lightly pack the bearings with grease applying a 33% fill by volume into the bearing and housings

Heaters

Where space heaters are fitted, and the storage environment has wide humidity and temperature variations, it is strongly recommended they be energised.

Warnings should be placed on the motors to make operatives aware of the live heaters

Supplies are normally 220-240 volt single phase, from a 380-415 volt three phase supply. See terminal box lid for details.

A low voltage DC supply could be used as an alternative (see page 14).

Insulation resistance

During extended storage a three monthly insulation test is recommended to avoid possible lengthy drying out periods when installing. Use a 500 volt d.c. Megger.

The insulation resistance between phases and between the windings and the frame should be checked.

The insulation resistance should be maintained above 10 megohm.

If a lower reading is measured, use one of the drying out methods recommended on page 14 until an acceptable reading is obtained. If heaters are fitted but not energised, they should be used in future. See also note on page 14.

Wound rotors

Ideally, wound rotor motor brushes should not be in contact with the slip-rings during storage as there is a risk of corrosion.

Brushes should either be lifted off the slip-rings or stored separately. This may not be possible with small motors (up to frame W-DF180).

Installation

Work on hazardous area motors should only be carried out by Brook Crompton trained personnel or those trained to an equivalent standard

Reference should be made to:

a constructional standards EN50014, EN50018 (EEx d), EN50019 (EEx e),

BS 5000 Part 16

b the approval certificate

c codes of practice (BS 5345, IEC 79 Part 14)

All warning instructions and labels must be observed and retained with the motor

Health & Safety at Work etc Act 1974

It is essential equipment is installed, earthed and guarded in accordance with current legislation

Location

Motors must be installed with adequate access for routine maintenance. A minimum of 0.75m of working space around the motor is recommended. Adequate space around the motor, particularly at the fan inlet (50mm), is also necessary to facilitate airflow.

Where several motors are installed in close proximity, care must be taken to ensure that there is no recirculation of exhausted warm air. Foundations must be solid, rigid and level.

Mechanical

Drain holes

Prior to installation remove drain plugs if fitted. If any water has accumulated, the integrity of all gaskets, sealants etc. should be checked. Drain plugs should be put back into place after draining.

Alignment

When the application calls for direct coupling, the shafts must be correctly aligned in all three planes. Bad alignment can be a major source of noise and vibration.

Allowance must be made for shaft end-float and thermal expansion in both axial and vertical planes. It is preferable to use flexible drive couplings.

Installation and maintenance of ac electric induction motors

Noise levels

The noise levels published in current Sales Specifications are equal to or less than the limiting values for rotating machines specified in European and International Standards BS EN 60034 and IEC 34-9.

In most cases noise levels also meet limiting values for exposure to noise in the work place i.e. Guidance on regulations for Noise at Work issued by HMSO.

It is the responsibility of the purchaser to ensure that other overriding lower noise levels if required, eg Machinery Directive, are specified at the time of order, or that the installation incorporates noise attenuating measures.

Free rotation

The rotor must be free to rotate within its housing. Where uneven or bumpy rotation occurs the bearings should be inspected to establish that they have not been damaged during transportation or storage.

Slide rails

Slide rails are available for all motors in the Brook Crompton product range to provide adjustable mounting. Fabricated steel rails are the standard as they are suitable for all mounting arrangements. Alternative aluminium slide rails are available for floor mounting.

Installation

- 1 slide rails must be installed on a flat
- 2 rails must have a secure location
- 3 drive and driven shafts must be parallel

A Electrical connection

The connection diagram is shown on the leaflet enclosed in the motor terminal box or the diagram inside the terminal box lid. The cables used should be capable of carrying the full load current of the motor (see motor name-plate) without overheating or undue voltage drop.

Cable terminations

All cable terminations should be tightly secured. Mains lead terminal lugs should be in face to face contact with the motor lead lugs and securing nuts and lockwashers screwed firmly over the connection. There should be no nuts or lockwashers fitted between the mains and motor lugs.

Wiring should be carried out or checked by a qualified electrician and equipment must be earthed in accordance with current

regulations. The equipment must be correctly fused and isolated. All covers must be in position prior to running.

↑ WARNING

Isolate power supply to motor before commencing any routine cleaning or maintenance work.

Drying out procedures

It is preferable to dismantle the motor to the point where the rotor is removed. This is not essential but the drying out process will take longer in the assembled state.

The temperature of the windings and the insulation resistance should be monitored at regular intervals. On initial application of heat the insulation resistance will drop quickly and then start to rise slowly until level. On discontinuation of the drying process, a further rise in resistance will occur.

There are several methods which can be

- 1 place the motor in a warm (typically 40°C), dry airstream (fan or convector heater) or in a warm oven with a temperature not exceeding 80°C. This method is preferred if the motor is dismantled
- 2 connect the motor to a low voltage* three phase supply and inject a current not exceeding 50% of the full load current into the stator winding (*approximately 10% of the line voltage). If this is carried out on an assembled motor, it is possible though unlikely that the motor will turn. If so the rotor should be locked in position
- 3 connect two phases in parallel, and the third in series. Apply a low voltage a.c. or d.c. supply up to a maximum of 50% of full load current. The stator winding temperature must not be allowed to exceed 80°C. In practice the frame should not be hot to the touch, to guard against internal overheating and consequent damage to the insulation
- **4** where heaters are fitted these can be energised

Supply

It is important that a motor is operated within the limits of its design voltage and frequency.

Standard motors for the UK will operate without damage on any voltage in the range 94% to 106% of the nameplate voltage.

The supply cables must be capable of carrying the full load current of the motor

(see motor nameplate) without overheating or excessive voltage drop under starting conditions.

Earthing

All motors are fitted with an earthing terminal, in or adjacent to the terminal box, to enable connection to an effective earthing bond. The terminal is designed for connecting the correct size of copper earth connector. If a different material is to be used please refer to Brook Crompton.

The motor must be earthed by connecting the shortest possible length of cable to the earth screws. The cable must have a capacity at least that of the main connections up to 16mm² phase conductors. Between 16 and 35mm² phase conductors, the earth should be a minimum of 16mm². Above 35mm² phase conductors, the earth conductor should be a minimum of half the phase conductor.

Earth conductor mm ²
at least equal
16 minimum
at least half

An earthing bond should not be terminated under the motor fixture bolts or terminal cover screws. The earth lead could be over-looked on reconnection after maintenance

Heater continuity

Heaters should be checked for continuity prior to connection to the control circuitry.

Thermistor continuity

If fitted, it is recommended that thermistors be connected to the control circuit. Thermistors provide good thermal overload protection.

Auxiliary electrical items

Where auxiliaries are fitted, the characteristics should be checked. Example: RTDs (Resistance Temperature Detectors) should have their resistances checked against manufacturer's figures.

Do not megger across the thermistor. Do not apply more than 6V across the thermistor for continuity check.

Control gear

Ensure all control gear and associated metering/protection circuits have been checked fully.

It is imperative that any overload trips and emergency shutdown circuits are working correctly before the motor is energised. All covers must be in position

Where a motor is fitted with a separately driven fan unit, the interlocks and thermal overload protection circuits must be operative.

Connection diagrams

Refer to the connection diagram supplied with the motor for supply details and the required winding connection.

Rotation

Before coupling the motor to the drive, run the motor briefly to check rotation.

All covers must be in place

Motors fitted with angular contact or duplex bearings must be run in the correct mounting position eg vertical.

To reverse rotation interchange any two supply leads.

Wound rotors

The stator of a wound rotor motor is similar to a cage motor but the rotor circuit is connected to a starting resistance. Take care to ensure that the brushes are in contact with the slip rings and that the rotor resistances are connected in the 'start' position.

Starting

Motors are rated by the output required, the number of starts per hour, the load curve/ inertia, and environmental considerations.

Operating outside the contractual parameters may thermally overload the motor eg too many starts per hour, or mechanically stress components eg overspeeding.

Refer to starter literature for method of start and safety precautions to be taken

Running

After one hour of running, check the general vibration levels. If these are excessive, check alignment (and belt tensioning if belt driven).

Some initial bearing noise may be present during the running in period. This is normal because the grease has to settle down within the bearing. The noise should disappear after a few hours of operation.

Check that the motor runs up smoothly and within the permitted run-up time. Note that repeated starting in quick succession may lead to a thermal overload of the motor.

Motor modifications

W series

Multimount modification Cast iron motors Frames (200-355)

SAFFTY WARNING

Do not work under suspended load and use correct lifting equipment.

Changing terminal box

- 1 lift motor, using two lifting lugs provided
- slacken the two vertical foot fixing bolts on one foot
- 3 remove the two horizontal foot fixing bolts
- 4 pull the foot away from the frame
- repeat stages 2 to 4 on the other foot
- lower the motor onto two pieces of timber
- 7 remove both lifting lugs
- rotate the motor until the terminal box is in the correct postion
- 9 refit the two lugs on the machined pads at the top of the motor on diagonally opposite corners. Ensure that lifting lugs are in contact with all machined faces and that the correct bolts and nuts are used. Tighten the bolts to the torque shown on page 12
- 10 remove fan cover
- 11 remove the endshield bolts at both ends of the motor
- 12 slacken drive end bearing cap or clamping screws to allow endshield spigot to disengage
- 13 disengage both endshield spigots and rotate the endshields through 90 degrees until the grease nipples are at the top
- 14 refit endshield bolts and tighten to torque given on page 17
- 15 retighten the bearing cap screws at the drive end, replacing the Nyltite washers under the bolt heads. Tighten screws to the torque given on page 17
- 16 lift motor, using hooks in the two lifting

- 17 strip paint from the pads where the feet are to be fitted and apply a thin film of grease for corrosion protection on bare surfaces
- 18 slide first foot into position, using vertical nuts and bolts for location purposes. Lightly tighten to prevent foot from falling out of the slots in the frame
- 19 insert horizontal bolts
- 20 ensure the feet are fully in contact with the machined faces. Tighten all bolts to the torque given on page 17
- 21 repeat stages 18 to 20 on the other foot
- 22 prime and paint all machined surfaces left exposed by the changes
- 23 refit fan cover with the greasing hole in the correct position

Bearings, grease, bearing change Grease

Bearings are prepacked with a lithium or lithium complex based grease.

Other lithium based greases of a similar consistency would be compatible. See Table 1 for some alternatives.

Table 1 Alternative lithium complex greases

Grease	Reference	Manufacturer
Energrease	LC2	BP
Castrol	LMX	Castrol
Luplex	M2	Century
Unirex	N2	Esso
Sovereign	LS	Gulf
Mobilgrease	HP	Mobil
Liplex	EP2	Shell
Hytex	EP2	Texaco
Retinax	LX	Shell
LGHT3	-	SKF

Where a special grease has been supplied this will be indicated on the motor nameplate.

Regreasing

Standard regreasing facilities, where provided, are situated on the periphery of the drive end and non drive endshields.

Grease relief is via a:

- a diaphragm relief valve
- b rotating grease relief flinger
- c plugged grease chute

Standard	regreasing	facilities

Туре	Regreasing facility
63/180*	on request
200/355	standard

* Bearings are double shielded and prepacked with grease for life

Installation and maintenance of ac electric induction motors

An overgreased bearing will cause overheating of the bearing with the possible escape of the grease, loss of lubrication qualities, leading to ultimate bearing failure.

Lubrication procedure

The following procedure should be adopted.

- 1 wipe clean the grease gun fitting and the regions around the motor grease fittings
- 2 remove the grease relief plug if fitted. Some motors will have one way grease valves which should be left in place
- 3 add a small quantity of grease, approximately 4 to 10 shots depending on frame size
- 4 allow motor to run for about ten minutes in order that excess grease may be expelled before refitting the relief plug. Bearings fitted with rotating grease relief or through grease valves will relieve automatically
- 5 on initial start up or after relubrication, 'bearing noise' may result from the new grease moving around the bearing. This noise is normal and will disappear after a few hours of running

Bearing change

When fitting new bearings the parts should be lightly lubricated with grease.

The bearing should be driven onto the shaft by pressure on the inner race only using a short length of tube placed over the motor shaft

On larger motors it is easier to raise the temperature of the bearing using an oil bath, oven, or induction heating. The temperature must be controlled to 120°C maximum.

The bearing should then be quickly slipped into place, ensuring that the bearing is in contact with the shaft shoulder.

When cool, ensure that the bearing is clean and charge the bearing with the recommended quantity of grease.

Bearings and housings should be one third full

Fitting Flange Adaptor

- 1 if required, remove foot as detailed in terminal box position change
- 2 if required, reposition terminal box and lifting lugs
- 3 clean paint off the drive end endshield spigot and remove all the plastic bolt-hole cover caps. Apply a film of Hylamar jointing compound on bare machined surfaces for sealing and corrosion protection

- 4 fit flange ring onto spigot, positioning fixing holes to provide either BS or DIN flange hole positions
- 5 bolt ring into position, using the same size socket head bolts as used on the feet. These are supplied with the flange ring kit
- 6 tighten the bolts to torque as given on page 17, ensuring a progressive tightening sequence

Change from ball/ball to roller/ball construction (refer to Brook Crompton for W-EF)

- 1 isolate motor before commencing work
- 2 remove fan cover and fan
- 3 remove bearing cap screws
- 4 remove endshield at both ends
- 5 remove bearing circlips at both ends
- 6 remove preload washer at non-drive-end
- 7 replace drive-end ball bearing with new roller bearing and refit circlip
- 8 remove non-drive-end ball bearing and inner bearing cap
- 9 fit new non-drive-end inner bearing cap with shallow recess (identical to existing drive-end inner bearing cap)
- 10 examine existing non-drive-end ball bearing and either refit or replace
- 11 refit non-drive-end bearing circlip
- 12 repack bearings with new grease in accordance with recommendations
- 13 ensure the lip, on both oilseals, is greased
- 14 refit both endshields and check that:
 - a spacer O/D is the same as the bearing O/D
 - b bearing spacer supplied is fitted into the non-drive-end endshield bearing recess
 - c slots in inner bearing caps are aligned with endshield grease chutes
 - d correct location for bearing cap by the use of a stud
 - e bolts are torqued up to recommended figures
- 15 refit bearing cap screws, ensuring correct torque to recommended figures
- 16 refit fan and fan cover
- 17 Turn shaft by hand to ensure free rotation

Maintenance

On-going maintenance

Induction motors by their very nature require very little maintenance. However a regular regime of inspection is recommended to ensure minor problems do not escalate to breakdowns. Typical intervals would be 2000 hours of operation or 3 months, whichever is the sooner.

Checklist

- no visible damage ie fans cracked, fan cowls bent, foot cracked etc
- no accumulation of dust or fibres on the frame or around the fan inlet
- no significant corrosion of the lifting lugs/ eyebolts
- · no excessive vibration
- no loose fasteners
- · cables and earths are sound
- sealing of the motor and gland plate in good condition
- insulation resistance adequate, imperative this is checked after a prolonged shutdown
- Note Fumex smoke extraction motors should be rewound after 5 years of operation. See specification sheet 2215E
- regrease required, particularly large output
 2 pole motors
- · bearing condition

Periodic maintenance

Remove the cover and the fan which is keyed, clamped, pinned or knurl located to the shaft extension. Loosen and remove bearing cover screws and endshield bolts/studs. The endshields should then be eased off their spigots.

The rotor can now be carefully withdrawn from the stator, taking care not to damage the stator bore and both stator and rotor windings.

Having dismantled the motor, maintenance can be carried out to remove all dirt. For this purpose, the use of an air line supplying dry compressed air under comparatively low pressure is best, as a high velocity air-stream can force dirt into the spaces between the windings and insulation, etc. Grease-removing solvents should only be used very sparingly to avoid damage to impregnating varnish or insulation.

Motors should be re-assembled in the reverse order from dismantling, remembering to ease endshields onto bearings and spigots. Do not use force.

Before starting, check that the rotor revolves freely. Ensure that the electrical connections are correct and terminal nuts tight (see section – Electrical Connection).

Endshield fixing bolt torques

Туре		Bolt dia	W-DA Aluminium frames		DF & W-DF Cast iron frames		K-CF	
Metric	NEMA/CSA		To: Nm	rque Lbf.FT	Tor Nm	que Lbf.FT	To: Nm	rque Lbf.FT
63	_	M4	1.5	1.1	_	_	_	_
71	-	M4	1.5	1.1	_	_	_	_
80	56	M5	5	3.7	5	3.7	-	-
90S/L	143/145	M5	5	3.7	5	3.7	_	_
100L	-	M6 (taptite)	8-10	5.9-7.4	20-24	14.7-17.7	-	-
112M	182/184	M6 (taptite)	8-10	5.9-7.4	20-24	14.7-17.7	-	-
132S/M	213/215	M6 (taptite)	8-10	5.9-7.4	28-32	20.5-23.6	-	-
160M/L	254/256	M8 (taptite)	29	21	28-32	20.5-23.6	_	_
180M/L	284/286	M10 (taptite)	52	38	38-42	27.8-30.7	-	-
200L	324	M10*	52	38	52	38	52	38
225S	326	M10*	52	38	52	38	52	38
225M	364	M10*	52	38	52	38	52	38
250S	365	M10*	52	38	52	38	52	38
250M	404	M16*	220	162	220	162	220	162
280S	405	M16*	220	162	220	162	220	162
280M	444	M16*	220	162	220	162	220	162
315S	445	M16*	220	162	220	162	220	162
315M	504	M20*	400	295	400	295	400	295
315L	505	M20*	400	295	400	295	400	295
355S/M/L	585/6/7	M20*	400	295	400	295	400	295

^{*} High tensile socket headed bolts and square nuts must be used

Foot fixing bolt torques

Туре		Bolt dia	W-DA		W-DF		
Metric	NEMA/CSA		Aluminium frames Torque Nm Lbf.FT		Cast iron frames Torque Nm Lbf.FT		
63	_	M5	6-7	4.5-5.2	_	_	
71	_	M5	6-7	4.5-5.2	_	_	
80	56	M8 (taptite)	24-25	17.7-18.4	_	_	
90S/L	143/145	M8 (taptite)	24-25	17.7-18.4	_	_	
100L	-	M8 (corflex)	32-35	23.6-25.8	_	_	
112M	182/184	M8 (corflex)	32-35	23.6-25.8	-	_	
132S/M	213/215	M8 (corflex)	32-35	23.6-25.8	-	-	
160M/L	254/256	M10	68-72	50-53	_	_	
180M/L	284/286	M10	68-72	50-53	_	_	
200L	324	M10*	_	_	52	38	
225S	326	M10*	_	_	52	38	
225M	364	M10*	-	_	52	38	
250S	365	M10*	-	_	52	38	
250M	404	M16*	-	-	220	162	
280M	405	M16*	-	-	220	162	
280L	444	M16*	-	-	220	162	
315S	445	M16*	-	-	220	162	
315M	504	M20*	-	-	400	295	
315L	505	M20*	-	-	400	295	
355S/M/L	585/6/7	M20*	-	_	400	295	

^{*} High tensile socket headed bolts and square nuts must be used

Wound rotor Inspection

Brushes should be inspected every 1000 running hours or at three monthly intervals if this is a shorter period of time.

The inspection should include checks for brush wear and tensioning. Build up of carbon dust should be removed using a suitable dust extraction unit. Replacement of brushes is recommended when the brush is approximately a quarter of the way down the brush holder. On calliper type designs the brushes should be replaced when 1/4" (5mm) of brush remains.

It is important that the correct grade of brush be used as this significantly affects operation. If in doubt please refer to Brook Crompton.

Hazardous area motors

In addition to the conditions referred to, special requirements apply to motor types Ex N, Ex nA, EEx e, EEx d, EEx de. Refer to the approval certificate and appropriate codes of practice eg BS 5435.

Spares and repairs

When ordering spares it is important to state the motor serial number to ensure that the correct spares will be supplied.

Notes

- a fixing bolts, nuts, studs, screws, spacers or washers are not included with these parts and, if required, should be clearly specified on the order in addition to the part description number. The fixing duty and part description reference number for which they are required should also be clearly stated
- b bearings ordered direct from bearing manufacturers must be specified as follows:

63-90 CN bearing 100-355 C3 bearing

Enquiries

Please contact Brook Crompton or its Agents for information on any aspects of the motor performance that need clarifying.

Contact must be made prior to any remedial action being taken under guarantee.


Please quote the motor number in all such cases with full details of the problem.

Policy

Our policy is one of continuous improvement and we reserve the right to alter any detail of our products at any time without giving notice.

Spare parts, installation & maintenance


Aluminium construction - frame sizes DA63, W-DA71 to W-DA180*



Ref	Part description
1	Aluminium flange endshield, frames 100-
	132, cast iron flange frames 160-180
2	Endshield fixing bolt
3	Drive end endshield
4	Rotor assembly
5	Flinger
6	Drive end oil seal
7	Preload washer
8	Drive end bearing
9	Stator assembly with or without feet
10	Eyebolt (when fitted)
11	Bearing retention circlip
12	Non-drive end bearing
13	Non-drive end endshield
14	Endshield fixing bolt
15	Bearing circlip
16	Non-drive end oil seal
17	Fan
18	Fan circlip
19	Fan cover
20	Fan cover screw and washer
21	Foot fixing bolts and washer
22	Detachable feet
23	Terminal board
24	Terminal box to frame gasket
25	Terminal box
26	Internal earth terminal
27	Terminal box lid gasket
28	Terminal box lid
29	Pad mounting bracket
30	Face endshield

Spare parts, installation & maintenance


Cast iron construction - frame sizes W-DF112 to W-DF180




Ref	Part description
1	Drive end endshield
2	Drive end oil seal
3	Drive end endshield fixing screws
4	Pre-load washer
5	Drive end bearing
6	Fan cover
7	Fan circlip
8	Rotor assembly
9	Flange endshield
10	Face endshield
11	Bolt on pad
12	Earth terminal
13	Eyebolt
14	Stator assembly with or without feet
15	Stator winding
16	Rating plate
17	Multi-mount foot
18	Terminal block
19	Terminal box gasket
20	Terminal box
21	Terminal box gasket
22	Terminal box lid
23	Terminal box lid fixing screw
24	Inner bearing cap
25	Non drive-end bearing
26	Circlip
27	Non-drive end oil seal
28	Non-drive end endshield
29	Non-drive end endshield fixing screws
30	Fan

Spare parts, installation & maintenance

Cast iron construction - frame sizes W-DF200 to W-DF355L



Alternative W-DF280M to W-DF355L terminal box arrangement



Ref	Part description
1	Flange adaptor (optional)
2	Flange adaptor fixing bolt (optional)
3	Endshield fixing bolt
4	Drive end oil seal
5	Drive end bearing cap fixing bolt and washe
6	Plug
7	Grease nipple
8	Drive end endshield
9	Stator frame assembly with or without feet
10	Stator core pack
11	Drive end bearing circlip
12	Drive end bearing
13	Drive end inner bearing cap
14	Rotor assembly
15	Non-drive end inner bearing cap
16	Non-drive end bearing
17	Non-drive end bearing circlip
18	Preload washer
19	Non-drive end endshield
20	Endshield fixing bolt
21	Non-drive end inner bearing cap fixing bolt
	and washer
22	Non-drive end oil seal
23	Fan
24	Fan locking screw
25	Fan cover fixing bolt and washer
26	Fan cover
27	Self adhesive nameplate
28	Multi-mount foot
29	Foot fixing bolt
30	Foot fixing nut
31	Lifting lug
32	Lifting lug fixing bolt and washer
33	Lifting lug nut
34(A)	
35(A)	Terminal box
36(A)	Gland plate gasket
	Gland plate
	Gland plate fixing bolt and washer
	Main terminal block
	Auxiliary terminal bracket
	Clip-in auxiliary terminal block
	Main terminal retaining plug
	Main terminal block fixing bolt and washer
	Mains terminal cover (optional)
	Terminal box lid gasket
	Terminal box lid
	Main terminal box lid fixing bolt and washer
48(A)	Terminal lock nuts, spring washer and plain
	washer
	Terminal link
50	Drain plug

Rotating Electrical Machines

Every care has been taken to ensure the accuracy of the information contained in this publication, but, due to a policy of continuous development and improvement the right is reserved to supply products which may differ slightly from those illustrated and described in this publication

For the most recent version of any Brook Crompton catalogue/leaflet, please refer to **www.brookcrompton.com**



Brook Crompton

St Thomas' Road Huddersfield
West Yorkshire HD1 3LJ UK
Tel: +44 (0) 1484 557200
Fax: +44 (0) 1484 557201
E-mail: csc@brookcrompton.com
Internet: www.brookcrompton.com