Konfigurimi i MikroTik me IP statike reale

(Konfigurimi me VLAN-e te ndryshme)

- 1. Lidhim PC ne porten 2 te MikroTik.
- 2. Konfigurojme NIC te PC me IP automatike.
- 3. Aksesojme MikroTik me MAC Address ose me IP nepermjet programit winbox
 - a. Aksesim me MAC Address:



b.Aksesim me IP:




4.Logohemi me **Login:admin Password**:

bosh>

dhe klikojme Connect

5.Hapet dritarja kryesore



Konfigurimi me VLAN-e te ndryshme:

Do te kemi vlan-et

VLAN_197- Internet (IP Statike reale:


80.78.79.84; SubnetMask: 255.255.255.192; Gateway: 80.78.79.65)

VLAN_ 370- Intranet


VLAN_208- Telefoni

{ Vlan-et dhe IP statike jane marre si shembull per test }


- 6. Vendosim emrat e portave.
- a)Interfaces => double click ether1 => vendosim Name:ether1-UPLINK => click Comment => vendosim koment "Porta ku vjen UPLINK"




b) Interfaces => double click ether2 => vendosim Name:ether2-LAN => click Comment => vendosim koment "Porta ku lidhet rrjeti i brendshem"



c) Interfaces => double click ether3=> vendosim Name:ether3-Intranet => click Comment => vendosim koment "Porta per komunikim ne Intranet"




d) Interfaces => double click ether5=> vendosim Name:ether5-VoIP => click Comment => vendosim koment "Porta ku lidhet pajisja e telefonise"




7.Shtojme VLAN-et


a) Interfaces => zgjedhim VLAN=> Add+=> vendosim Name:vlan197; VLAN ID:197; Interface:ether1-UPLINK => click Comment => vendosim koment "VLAN per Internet"




b) Interfaces => zgjedhim VLAN=> Add+=> vendosim Name:vlan370; VLAN ID:370; Interface:ether1-UPLINK => click Comment => vendosim koment "VLAN per Intranet"




c) Interfaces => zgjedhim VLAN=> Add+=> vendosim Name:vlan208; VLAN ID:208; Interface:ether1-UPLINK =>click Comment => vendosim koment "VLAN per Telefoni"



- 8.Caktojme portat me VLAN-et perkates (Krijojme Brigde)
 - 1.Krijojme bridge-t:
 - a)Bridge => Add+ => vendosim Name:bridge1





b)Bridge => Add+ => vendosim Name:bridge2




2.U vendosim portave Vlan-et perkates:


a) Bridge => Ports => Add+ => vendosim Interface:ether3-Intranet; Bridge:bridge1






b) Bridge => Ports => Add+ => vendosim Interface:ether5-VoIP; Bridge:bridge2






9.Konfigurojme IP Address per Internet:


IP => Adresses => Add+ => vendosim Address:80.78.79.84/26; Interface:vlan197




IP => Routes => Add+ => vendosim Destination:0.0.0.0/0; Gateway:80.78.79.65



10. Konfigurojme IP Address per rrjetin e brendshem LAN:







IP => DHCP Server => click DHCP Setup => DHCP Server Interface:ether2-LAN => DHCP Adress Space:192.168.1.0/24 => Gateway for DHCP Network:192.168.1.1 => Addresses to Give Out:192.168.1.20-192.168.1.100 => DNS Servers:80.78.66.66 => Lease Time:3d

11.Aktivizojme NAT-in

IP => Firewall => zgjedhim NAT => Add+ => Te General vendosim Chain:srcnat; Out.Interface:vlan197 => Te Action vendosim Action:masquerade





12. Vendosim identitetin se ku do te vendoset pajisja System => Identity => Vendosim emrin e klientit: TEST

