
WO107 - AutoSeq Interface routine - Add Cutout/Notch for Contour

PURPOSE:

The procedure adds a cutout/notch for the current contour.

DECLARATION:

```
void wo107( const int PlatePartNo,  
            const int ContourNo,  
            const int CutoutNo,  
            const int SegPartStart,  
            const double StartPoint[2],  
            const int SegPartEnd,  
            const double EndPoint[2]);
```

INPUT:

Parameters:

PlatePartNo	The identification number for the plate part
ContourNo	The contour number
CutoutNo	The cutout number
SegPartStart	Segment part number for the cutout/notch start
StartPoint	Interval starting point
SegPartEnd	Segment part number for the cutout/notch end
EndPoint	Interval ending point

RESULT:

None.

```
-----*/  
/*  
*   External declarations
```

```

    */
extern "C"
{

    #if !defined TBLSEQUENCEPLUGIN_API
    #define TBSEQUENCEPLUGIN_API
    #endif

    /*

    ****
    ****
    *
    * Main procedure - wo107
    *

    ****
    ****
    */

    #ifdef WIN32
    TBSEQUENCEPLUGIN_API
    #endif
    void wo107( const int /* PlatePartNo */,
                const int /* ContourNo */,
                const int /* CutoutNo */,
                const int /* SegPartStart */,
                const double [2] /* StartPoint */,
                const int /* SegPartEnd */,
                const double [2] /* EndPoint */)
    {
    }
}

```