Software Requirements Specification

Version 1.0 <<Distributed Theatre Sound System>>

Oct, 27 2015

Team 6
Jared Hutton
Eric Meldrum
Stephen Walmsley
Colton Prettyman

CSCD 488 Senior Project

Table of Contents

1. Introduction	3
1.1 Purpose	3
1.2 Scope of Project	3
1.3 Glossary	3
1.4 Overview of Document	4
2. The Overall Description	5
2.1 System Environment 2.1.1 Hardware 2.1.2 Software	5 5 5
2.2 Product Functions	5
2.3 User Characteristics	8
2.4 Constraints, Assumptions and Depende	encies 9
3. Specific Requirements	10
3.1 External Interfaces	10
3.2 Functions	10
3.3 Performance Requirements	19
3.4 Logical Hard Disk Requirements	19

1.0. Introduction

1.1. Purpose

The purpose of this SRS document is to present a detailed description of the Distributed Theatre Sound System. It will explain the purpose and features of the system, the various interfaces of the system, what the system will do, and the constraints under which the system must operate. This document is intended for the use of the development team and the client throughout the life if the project. While it is intended that this be a static document, it is also understood that changes to the original specifications may be necessary, and if changes are made, this document will be updated to match the updated specifications.

1.2. Scope of Project

This software system will be a Distributed Theatre Sound System for a local software development client. This system will be designed to create and execute theatre playlists. These playlists will be a collection of audio files used during a theatre production. The hardware for the system will include a dynamically acquired, wireless network of Raspberry Pi's. Utilizing the system, the user will be able to provide multiple audio sounds and effects in various locations of a theatre stage to affect all necessary sound events for a theatre performance.

1.3. Glossary

Term	Definition
	A user with elevated privileges. Presumably set as a
Administrator	safeguard to keep normal users from accidentally
Administrator	miss-configuring a function of the Distributed
	Theatre Sound System.
Cue	A sound file.
NI- J-	A Raspberry Pi running the Distributed Theatre
Node	Sound System software.

Production	A playlist of cues that is associated with a theatre performance.
Software Requirements Specification	A document intended to describe a software in its entirety prior to production. This document is a Software Requirements Specification, Abbreviated: SRS
User	The person initiated and operating the Distributed Theatre Sound system.

1.4. Overview of Document

The next chapter of this document, the Overall Description section, provides an broad description of the functionality of the system. It describes the informal requirements and is used to establish a context for the technical requirements specification in the next chapter.

The final chapter, Requirements Specification section, of this document is written primarily for the developers and describes in technical terms the details of the functionality of the product.

Both sections of the document describe the same software product in its entirety, but are intended for different audiences and thus use different language.

2. The Overall Description

2.1 System Environment

2.1.1 Hardware

Wireless media solution that runs on raspberry pi nodes

2.1.2 Software

Web app that allows users to interact with the software

2.2 Product Functions

Login Page

Login Page Use Case

Brief Description

Interface to allow user to enter login credentials for access to the Distributed Theatre Sound System.

Initial Step-By-Step Description

Before this use case can be initiated, the user must have a computer connected to the local network of the Distributed Theatre Sound System.

- 1. The user accesses a Node by entering the IP of the Node into a connected computers Internet Browser
- 2. The user enters the username and password to gain access.

Xref: Section 3.2.1, Load Production

Cue Controller Page

Load Production Use Case

Brief Description

An interface that allows users to control the sound set of a chosen production.

Initial Step-By-Step Description

Before this use case can be initiated, a production must be created in the Production Configuration Interface.

3. The User chooses to search by production name.

- 4. The system loads the chosen production.
- 5. If no production exists, they are redirected to the Production Configuration Interface.

Xref: Section 3.2.2, Load Production

Production Cue List Use Case

Brief Description

This section is a list of all cues assigned to the selected production.

Initial Step-By-Step Description

Before this use case can be initiated, a production must be loaded.

- 1. System displays all cues associated with the loaded production in chronological order.
- 2. The user can play any cue in the list by double clicking it or start the next highlighted cue by clicking the "next" button.
- 3. If necessary, the list will be scrollable.

Xref: Section 3.2.3, Production Cue

Active Cue List Use Case

Brief Description

This section is a list of all cues currently playing.

Initial Step-By-Step Description

Before this use case can be initiated, at least one cue must be in play.

- 1. System displays any currently running cues.
- 2. The user can resume/pause or cancel each cue.
- 3. The user can resume/pause or cancel all active cues.
- 4. As a cue ends, the system removes it from the list

Xref: Section 3.2.4, Active Cue List

Network Configuration Page

Manage/Configure Node Use Case

Brief Description

An interface to configure/manage nodes and network options for the nodes.

Initial Step-By-Step Description

Before this use case can be initiated, nodes are turned on and connected to the network.

- 1. System displays a list of active/inactive nodes discovered.
- 2. System displays which node the user is currently logged into.
- 3. The user can change the hostname of any node.
- 4. The user can forget nodes.
- 5. The user can send an audio test cue to locate/test each node.
- 6. The system will display a list of computers that can access the web app without a password.
- 7. The user can click a button to add the currently logged on computer to the list of acceptable computers.

Xref: Section 3.2.5, Manage/Configure Node

Production Configuration Page

Import Sound File Use Case

Brief Description

An interface to import .wav/.mp3 files for use in productions.

Initial Step-By-Step Description

- 1. User clicks import sound file.
- 2. System allows the user to browse and select a .wav or .mp3 file or multiple files at once.
- 3. The selected file is saved into a created sound file folder.

Xref: Section 3.2.6, Import Sound File

Open/Create/Delete Production Use Case

Brief Description

A menu option that allows the user to create or make changes to a production.

Initial Step-By-Step Description

- 1. User chooses to create a production from the file menu.
 - 1.1. User enters a name for the production.
 - 1.2. Option to set a password to edit or delete the production.
 - 1.3. The system creates the production interface for editing.
- 2. User chooses to open an existing production from the file menu.
 - 2.1. The user enters a password if required.
 - 2.2. The system opens the production interface for editing.

- 3. The user chooses to delete an existing production from the file menu.
 - 3.1. The user enters a password if required.
 - 3.2. The system deletes the production.

Xref: Section 3.2.7, Open/Create/Delete Production

Configure Production Use Case

Brief Description

An interface that allows a user to add and remove sound cues, configure sound effects, and assign nodes.

Initial Step-By-Step Description

- 1. User can add a sound cue to the production.
 - 1.1. User chooses a sound for the cue.
 - 1.2. User can add effects to the cue.
 - 1.3. User can add nodes to the cue.
- 2. User can delete a sound cue from the production.
- 3. User can edit a sound cue from the production.
 - 3.1. User can change the sound for the cue.
 - 3.2. User can change/remove/add effects for the cue.
 - 3.3. User can remove/add nodes for the cue.
- 4. User can reorder sound cues by clicking a reorder button that populates up and down arrows next to the cues.
 - 4.1. When the user is done they can click save to disable the ability to change the order of the cues.
- 5. User can click the save button to save a production and sync it with all other nodes.

Xref: Section 3.2.8, Configure Production

2.3 User Characteristics

The User is expected have their own sound files in .wav or .mp3 format and to know where they have stored them on their computer. The user needs to know how to open a browser and to put the Hostname in to log into the web app on the Raspberry Pi.

The person who sets the system of Raspberry Pi's should at least have a general knowledge of setting up a local network. They also need to be able to load the Distributed Theatre Sound System web app software onto the Raspberry Pi(s),

which will have a Linux OS on them. They also need to set, or know, the hostname on at least one of the Raspberry Pi's.

2.4 Constraints, Assumptions and Dependencies

Each Raspberry Pi will have a compatible Linux based OS installed.

Raspberry Pi's will be on a LAN and able to discover each other over the network. The Distributed Theatre Sound System web app software will be loaded onto each Raspberry Pi.

3. Specific Requirements

3.1 External Interfaces

The user needs a connection to the network and a working browser with valid credentials to log into the Distributed Theatre Sound System.

3.2 Functions

Login Page

3.2.1 Login Page

Use Case	Login
Name	6
XRef	Section 2.2.1, Login
	Section 2.2.2, Cue Controller
Trigger	The user accesses a Node by entering the IP of the Node
	into a connected computers Internet Browser.
Precondition	The user must have a computer connected to the local
	network of the Distributed Theatre Sound System.
	1. The user attempts to access a Node on the Distributed
Basic Path	Theatre Sound System.
and	2. The system presents an option to login as
Functionality	administrator or user.
Specifications	3. The user or administrator must enter credentials to
	login.
	4. The system logs the user into the Node and is
	presented with the Cue Controller Page.
	The computer was set to be remembered for future
Alternative	logins thus bypassing the login page.
Paths	
Postcondition	If successful credentials are presented the user should be
	logged onto the Distributed Theatre Sound System and
	presented the Cue Controller Window.
Exception	None.
Paths	

Cue Controller Page

3.2.2 Load Production

Use Case	Load Production
Name	
XRef	Section 2.2.2, Load Production
Trigger	The user has presented valid credentials and has
	successfully been logged onto the Distributed Theatre
	Sound System.
Precondition	The user must have a computer connected to the local
	network of the Distributed Theatre Sound System and
	presented valid logon credentials.
Basic Path	1. User is directed to browse for an existing
and	production.
Functionality	2. System has locked the path to a specific directory
Specifications	that holds all the productions.
	3. Once selected the system will load all the cues into
	the cue list and the first cue is highlighted.
Alternative	1. If no productions exist the options to load are greyed
Paths	out.
	2. The user can cancel to return to the cue controller
	page.
Postcondition	Once a valid production is selected all the cues are
	loaded into the cue list and the first cue is highlighted.
	The production is ready to launch.
Exception	If a user attempts to load a corrupted production the user
Paths	is notified and the production isn't loaded.

3.2.3 Production Cue List

Use Case	Production Cue List
Name	
XRef	Section 2.2.3, Production Cue List
Trigger	The user has presented valid credentials and has successfully been logged onto the Distributed Theatre
	Sound System or a production has been loaded.

Precondition	The user has presented valid credentials and has
Trecondition	successfully been logged onto the Distributed Theatre
	Sound System.
Basic Path	1. The cue list is populated with cues from the loaded
and	production in chronological order.
Functionality	2. The first cue is highlighted by default.
Specifications	3. The user can choose to highlight a different cue by
	single clicking on it. This will not start the cue.
	4. The user can double click on any cue to start that
	cue. If this cue is already playing it will be stopped and
	started from the beginning.
	5. The user can click a "NEXT" button that will play
	the highlighted cue.
	6. Every time a cue is started, the next cue in the list
	will then be highlighted.
	7. If necessary, the list will be scrollable.
	8. There is a color scheme that will be used to identify
	the state of cues in the list.
	8.1. Gray: Skipped or completed cues.
	8.2. Yellow: Currently playing cues.
	8.3. Green: Next (highlighted) cue.
	8.4. Black: Pending cues in the list.
	9. The cue can be seen in minimized mode, and
	expanded mode.
	9.1. In minimized mode the only things that are
	shown are the cue name and the time remaining, a plus
	sign to expand the options, a number depicting the
	chronological order, and a warning indicating if there
	are any issues with the cue.
	9.2. In expanded mode, everything that is in
	minimized mode is shown, except the plus sign is now
	a minus sign. In addition, all effects, assigned nodes,
	and the sound filename.
	10. The warning indicator mentioned in section 9
	would alert the user to any missing nodes, if no nodes
	are assigned, or missing sound file. When in expanded
	mode, the specific errors will be in red.
	11. There will be a global volume control from 0 to
	110 percent.
Alternative	If no production has been loaded, this area is empty.
Paths	
Postcondition	None.
Exception	1. Missing sound files: No sound will be played.
Paths	2. Missing nodes: System sends play request to all
	connected nodes assigned to the cue.
	3. If there is a corrupted sound file played, no sound is

1 1	1		1	41
nlaved an	d a warn	11no 19 (shown (on the cue.
prayed an	a a wan	11115 15 1		m the cac.

3.2.4 Active Cue List

Use Case Name	Active Cue List
XRef	Section 2.2.4, Active Cue List
Trigger	The user has presented valid credentials and has successfully been logged onto the Distributed Theatre Sound System or a production has been loaded.
Precondition	The user has presented valid credentials and has successfully been logged onto the Distributed Theatre Sound System.
Basic Path	1. When a sound cue is active, it is displayed in the
and	active cue list.
Functionality	2. If necessary, the list will be scrollable.
Specifications	3. Active cues can be paused or removed.
	4. The active cue has the name, pause/remove buttons,
	and the time remaining.
	5. There will be pause all and stop all buttons to pause and stop all active cues at the same time.
Alternative	1. If an active cue has been paused, the option changes to
Paths	resume.
	2. If the pause all button has been pushed, the option
	changes to a resume all.
Postcondition	When a cue ends, it will be removed from the list.
Exception	Nothing happens if the pause all or stop all buttons are
Paths	pushed when the active list is empty.

Network Configuration Page

3.2.5 Manage/Configure Node

Use Case Name	Manage/Configure Node
XRef	Section 2.2.5, Manage/Configure Node
Trigger	The user has selected to load the Network Configuration page.

Precondition	The user has presented valid credentials and has
	successfully been logged onto the Distributed Theatre
	Sound System. Then the user has selected the Network
	Configuration page and provided an administrator
	password if logged in as a user.
Basic Path	1. When the page loads, a list of discovered nodes are
and	displayed.
Functionality	1.1. Online nodes will be indicated by the name
Specifications	highlighted in green.
•	1.2. Offline nodes will be indicated by being greyed
	out.
	2. The administrator can right click on any discovered
	node. 2.1. The administrator can select to "forget" a node.
	2.1. The administrator can select to "forget" a node.2.2. The administrator can select to rename a node.
	2.3. The administrator can select to locate a node.
	2.4. The administrator can select to remotely reboot a
	node.
	3. The administrator can select an option from the drop
	down menu.
	3.1. The administrator can select to "forget" a node.
	3.2. The administrator can select to rename a node.
	3.3. The administrator can select to locate a node.
	3.4. The administrator can select to remotely reboot a
	node.
	4. The administrator can select a button to bring up a
	window that will show all the saved computers that can bypass the login page.
	4.1. The administrator can select to add the currently
	logged on computer to the list of remembered
	computers.
	4.2. The administrator can select one of the computers
	in the list and select to remove it from the list.
	5. The administrator can select to change passwords.
	5.1. The administrator will be asked if he wants to
	change the admin password or guest password.
	5.2. The administrator will type in a new password and
	to confirm it and the password of the chosen type will
	be changed.
Alternative	The user can cancel out of the saved computers window.
Paths	
Postcondition	None.
Exception	None.
Paths	
1	

Production Configuration Page

3.2.6 Import Sound File

Use Case	Import sound File
Name	
XRef	Section 2.2.6, Import Sound File
Trigger	The user has selected to load the Production Configuration page.
Precondition	The user has presented valid credentials and has successfully been logged onto the Distributed Theatre Sound System. Then the user has selected the Production Configuration page.
Basic Path and	 The user clicks on the import sound file button. The user browses to the directory on the local
Functionality	computer where the sound file is stored.
Specifications	3. The user is locked down to only see .wav and .mp3 files.4. The user selects a file and has the option to open or close.
Alternative	The user can cancel to return to the Production
Paths	Configuration Page.
Postcondition	The imported sound file is downloaded to the designated directory and synced with all connected nodes.
Exception Paths	None.

3.2.7 Open/Create/Delete Production

Use Case	Open/Create/Delete Production
Name	
XRef	Section 2.2.7, Open/Create/Delete Production
Trigger	The user has selected to load the Production
	Configuration page.
Precondition	The user has presented valid credentials and has
	successfully been logged onto the Distributed Theatre
	Sound System. Then the user has selected the Production
	Configuration page.
Basic Path	1. The user selects to open an existing production.

	1
and 1.1. The user selects from a list of existing productions	•
Functionality 2. The user selects to create a new production.	
Specifications 2.1. The user is asked to enter a name and has the	
option to assign a password for this production.	
3. The user selects to delete an existing production.	
3.1. The user selects from a list of existing productions	
3.2. A warning pops up asking to confirm if they want	
to delete this production.	
Alternative 1. When opening a production that has a password	
Paths associated with it, the user will be prompted for the	
password.	
2. If no productions currently exist, the open and delete	
production options will be greyed out.	
3. The user has the option to cancel when opening a	
production.	
4. The user has the option to cancel when deleting a	
production.	
5. The user has the option to cancel when creating a	
production.	
6. If an invalid password is entered the user is notified	
and they can try to reenter the password again.	
Postcondition 1. A production is loaded and ready for editing.	
2. A production is created and ready for editing.	
3. The production is deleted for all nodes.	
Exception If a user attempts to load a corrupted production the user	,
Paths is notified and the production isn't loaded.	

3.2.8 Configure Production

Use Case	Configure Production
Name	
XRef	Section 2.2.8, Configure Production
Trigger	The user has loaded a valid production.
Precondition	The user has presented valid credentials and has successfully been logged onto the Distributed Theatre Sound System. Then the user has selected the Production Configuration page.
Basic Path and	 The user selects to create a cue. The user is required to enter a name and add a
Functionality	sound.
Specifications	1.1.1. To select a sound, the user will be provided a list of imported sounds.

- 1.2. The user can optionally assign nodes and add effects.
- 1.2.1. To assign a node, the user will be provided a list of discovered nodes to choose from.
- 1.2.2. When a node is assigned, the user will be able to add effects for that node.
- 1.2.2.1. Fade in: If checked, the user enters the length (in milliseconds) of the fade in.
- 1.2.2.2. Fade out: If checked, the user enters the length (in milliseconds) of the fade out.
- 1.2.2.3. Volume: If checked, the user determines to increase or decrease the volume with a slider in relation to the global volume.
- 1.2.2.4. Adjust Pitch: If checked, the user determines to increase or decrease the pitch with a slider.
- 1.2.2.5. Delay: If checked, the user enters the length (in milliseconds) of the delay.
- 1.2.3. The user can listen to the cue as it stands by pressing the test button.
- 1.2.4. When the user is finished customizing effects, the user can save the node to the cue.
- 1.3. Once the user is done customizing nodes, the user can save the cue and it is added to the end of the production.
- 2. The user selects to delete a cue.
- 2.1. The user selects to delete cues and checkboxes appear next to the cues. The user selects which cues to delete by selecting the checkbox.
- 2.2. The user then selects a confirm button to delete all the checked cues.
- 3. The user selects to edit an existing cue.
- 3.1. The user can edit the effects of an assigned node.
- 3.2. The user can add a node and assign effects to it. See 1.2.2. for details on editing effects.
- 3.3. Once the user is done customizing nodes, the user can save the changes.
- 4. The user selects to reorder the cues.
- 4.1. Up and down arrows will appear next to each cue.
- 4.2. When the user clicks an arrow, the cues will be moved up or down the list respectively.
- 5. The user selects to save the production.
- 6. If the user navigates away from the Production Configuration page or closes the browser prior to saving, the user is prompted to save the production.
- 7. When opening a production that is currently being edited, an error message will be displayed and the user

	is given the option to force open the production by
	entering the program level password and the password
	to the production if required.
Alternative	1. When assigning a node to a cue, if at least one node
Paths	has been assigned already, the user can copy the effects
	from an already assigned node or can customize effects.
	2. The user can cancel when customizing effects to a
	node.
	3. The user can cancel when adding a node to a cue.
	4. The user can cancel when adding a cue.
	5. The user can cancel when deleting a cue.
Postcondition	The production is saved to all connected nodes.
Exception	When a sound is tested and it is corrupted or missing, the
Paths	user is notified and the sound is not played.

Miscellaneous

3.2.9 Network Structure

Use Case	Network Structure
Name	
XRef	None.
Trigger	The Raspberry Pi is booted up.
Precondition	None.
Basic Path	1. When the Raspberry Pi is booted up, a listener is
and	started.
Functionality	1.1. The listener listens for commands from other
Specifications	nodes.
	2. Network discovery.
	2.1. When a node comes online, the node sends out a
	"hello" and the listeners hear it.
	2.2. The discovered node will be placed in each nodes
	network configuration page, see 3.2.5.
Alternative	None.
Paths	
Postcondition	Listener is running.
Exception	None.
Paths	

3.3 Performance Requirements

- 3.3.1. The Raspberry Pi's need to be running a Linux distribution (Raspian, ArchARM, etc.) to function properly.
- 3.3.2. Since the software will be running on Raspberry Pi's the program cannot be intensely resource heavy.
- 3.3.3. We will tailor our software to fit the resources available on a Raspberry Pi, not tailor the computer to our software (has to work on Raspberry Pi's before any other medium).

3.4 Logical Hard Disk Requirements

- 3.4.1. The hard disk must have enough space to fit a flavor of Linux that works on the Raspberry Pi, our software, and any sounds that the user will want to import.
- 3.4.2. Both the operating system and our software will be static in the amount of memory they take up. There should be no variance amongst all the nodes when they are bare-bones.