



General Setup Instructions


- Read entire setup instruction manual prior to unpacking parts and pieces.
- The setup instructions are created specifically for this configuration.
- Setup instructions are laid out sequentially in steps, including exploded views with detailed explanation for assembly.




- For Cleaning Metal, Plex, & Laminate Parts: Use a MILD NON-ABRASIVE cleanser and soft cloth/paper towel to clean all surfaces.
- Keep exhibit components away from heat and prolonged sun exposure. Heat and UV exposure will warp and fade components.
- Retain all provided Packing Materials. All provided packing materials are for ease of repacking & component protection.

Disassembly

- For loss prevention, tighten all setscrews and locks during disassembly




Hex Tool - Essential for Assembly



Part Identification - Numbering




WARNING





Spline Connection

Extrusion & Lock Connection



Base Plate & Extrusion Connection





Engaged Lock



DO NOT USE POWER TOOLS



LADDERS OR LIFTS MAY BE REQUIRED




ALL CONNECTIONS MUST BE TIGHTLY SECURED








SEG Graphic Installation

- 1) Locate channels along the edges of extrusions
- 2) Insert graphic corners first into channels then center point of graphic into channels. Allows for proportional fit around the perimeter of the extrusion.
- 3) Working from center to corner, slide silicon edge on graphic into channel.
- 4) After all edges of graphic have been inserted into channels, step back and assess graphic fit, make adjustments where needed.












Top View of Each Level






Order #XXXXX Backwall Assembly


Item	Qty.	Description
1	1	47.9975"h Lower Curved Extrusion
1A	1	38.5"h Upper Curved Extrusion
2	1	47.9975"h Lower Curved Extrusion
2A	1	38.5"h Upper Curved Extrusion
3	1	47.9975"h Lower Curved Extrusion
3A	1	38.5"h Upper Curved Extrusion
4	2	36.1425"h Backwall Support Extrusion
5/5A	1/1	44"w Lower Horizontal Extrusion
6/6A	1/1	44"w Upper Horizontal Extrusion
7/7A	1/1	23"w Upper Horizontal Extrusion

Steps:

- 1) Connect backwall upper and lower verticals together [1] to [1A], [2] to [2A] and [3] to [3A]. See Knobs on Backside detail.
- 2) Connect horizontal extrusions together [5] to [5A] and [6] to [6A]. See Knobs on Backside detail.
- 3) Attach horizontal assemblies [5/5A and 6/6A] between vertical assemblies [1/1A] and [2/2A]. See Connection Lock with Knob detail.
- 4) Attach horizontal extrusions [7 and 7A] between vertical assemblies [2/2A and 3/3A].
- 5) Attach support leg extrusions [4] to back of verticals [1] and [3], see leg attachment detail.
- 6) Attach graphics to backwall where indicated. See Graphic Installation page.











Order #XXXXX Header Assembly

Item Qty. Description
12/12A 1/1 6.0257"h Vertical Extrusion
13/13A 1/1 35.74"w Curved Horizontal

Steps:

- 1) Connect upper curved horizontals [13] & [13A] together.
- 2) Attach verticals [12] & [12A] to each end of horiozntals.
- 3) Attach header to upper backwall horizontals.





Completed Assembly