




Part Number	Description		866.652.2100
1	Left Leg Assembly w/ A10 Clamps Attached		
2 3A	Middle Leg Assembly Upper Curved Vertical w/ A10 Clamps Attached		NOTE: When assembling horizontals they should
3	Upper Curved Vertical	Step 1	be placed approximately one inch from TOP and BOTTOM.
upright or upright A) Connect vertifaces toward B) Connect vertifar as shown C) Connect uppinch down fro	assembled either face down on floor then lifted as shown in drawings. ical leg assemblies [1 and 2] together by connecting horizontal extrusions assemblies tightening BLACK knobs on backside of extrusion making sure Velcro BACK and placing it about one inch up from bottom and tightening. ical extrusions [3 and 3A] to leg assemblies [1 and 2] using vertical connection in. er horizontal extrusion [4] between verticals [3 and 3A] placing it about one	3A Vertical Connection Bar 2	Slide Connection Bar into lower leg assembly. Slide upper vertical over bar and secure both. Step stool may be required for assembly.




WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING


to Tighten Lock


















866.652.2100

Part Number Description

A Left Leg Assembly

B Right Leg Assembly


C Horizontal Extrusion


D Horiontal Extrusion w/ Door Stopper

Step 1:

- A) Connect lower horizontal extrusion [C] between bottom of leg assemblies [A and B] as shown.
- B) Insert Laminated infill into grooves of leg assemblies [A and B].
- C) Attach extrusion door between leg assemblies [A and B] and atop laminated infill.
- D) Attach upper horizontal extrusion w/ door stopper [D] between leg assemblies [A and B], and set flush with top of legs [A and B].

NOTE: Make sure the lock is flush with extrusion before tightening. If lock will not fully engage, gently rock lock and extrusion back and forth while turning knob until lock fully opens.










866.652.2100


Step 2: **REPEAT steps for both Pedestals

- A) Attach laminated front panel to assembled pedestal using standoff caps as shown below.
- B) Place internal shelf into assembled pedestal atop pins...
- C) Set Counter atop assembled pedestal and secure with Velcro straps attached to underside of top.










Case #1 - Backwall Components

Vertical Connection Bar Vertical Connection Bar Horizontal Extrusion 5 A10's Attached Leg Assembly Leg Assembly **Horizontal Extrusions** Leg Assembly 3 Blade Wing Horizontal Extrusion 5 A10's Attached Wing Attachment Level 1 Level 2 Level 4 Level 3 Cutout for A10 Clamp Vertical Connection Bar


Top View of each Level

Case #2 - Backwall Components




Top View of each Level Vertical Connection Bar Horizontal Extrusions #6 Blade Wing


Level 2



Case #3 - Backwall Components


Top View of each Level







Case #4 - Backwall Components


Top View of each Level






Case #5 - Workstation Components







Top View of each Level Monitor Mount Vertical Extrusion G w/ A10's Attached Door


Level 3





Case #6 - Workstation Components





Top View of each Level Monitor Mount Vertical Extrusion G w/ A10's Attached Door

Level 3

