

TECHNO TURING GROOVEBOX

TTG Beta 5 - Online/Offline Manual

Status: BETA 5 **Version:** 0.5.0-beta.5-b93-parameter-labels **Build:** B93

Techno Turing Groovebox is a performance-oriented generative techno instrument for Android. Beta 5 centers the instrument around five Turing lanes, dual Plaits-based Macro voices, a Rings-style Resonator, 909 percussion, live mixing, modular BREAK processing, MIDI and Ableton Link.

Primary platform: Android 8.0+ (API 26+). Target SDK: Android 16 / API 36.

QUICK START

1. SOUND	Set BPM and shuffle, then shape Kick+Tom, Hats, Macro A, Macro B and Resonator.
2. TURING	Use the five independent lanes to generate rhythm and pitch. Route Turing CV to selected parameters when desired.
3. MIXER	Balance the six buses and use global macros, sidechain, Mackity, delay/reverb, 909 performance parts and temporary states.
4. BREAK	Use Slice or Texture mode and route any TTG bus through the BREAK chain and its dual-filter/output stage.

TTG is designed for live interaction. Per-voice RND uses a confirmation step and preserves safety-critical routing and Turing CV destination choices.

01 / SOUND

Tempo

BPM sets the master tempo. Use minus/plus or TAP. SHUF controls swing.

Kick + Tom

The kick remains TTG's dedicated kick engine. DRIVE, BF, separate Kick/Tom decay, pitch and PITCH ENV shape the voice. K TUR enables dedicated Turing behavior. The 909 button switches the Tom layer to the 909-style engine; it does not replace the kick.

Hat / Perc

HH 4/4 and 16TH are independent fixed hat layers. DECAY, DRIVE, FILTER, MORPH, DELAY and TIME SYNC shape the hat engine.

Macro A + Macro B - Plaits

Macro A and Macro B are two independent instances of the Mutable Instruments Plaits core. Each provides FREE/STEP pitch, SYNTH/PERC bank selection, model choice, PITCH, HARMONICS, TIMBRE, MORPH, DECAY and VCA.

Resonator - Rings

The Resonator uses a Rings-style resonator core. Select model and VOICES, then control PITCH, STRUCTURE, BRIGHTNESS, DAMPING, POSITION and VCA. T5 supplies the generative trigger/strum stream.

RND + Drone

Each Sound voice includes RND with confirmation. It randomizes musical parameters and that voice's dedicated Turing pattern while preserving routing and CV target choices. DRONE enables continuous/drone-oriented behavior where supported.

02 / MIXER

Six buses

K+T, HAT, MAC A, MAC B, RES and BRK each have level and mute. Hat, Macro A, Macro B, Resonator and Break have independent FX sends. Macro A/B and Resonator also expose bipolar mixer-filter controls.

Global macros

PITCH globally transposes musical voices. CRUSH applies global bit reduction. SYNC quantizes supported performance switching to musical boundaries.

FX / Temp Performance

DELAY, TIME, FDBK, RVB, DECAY and DROP FX form the performance FX section. Delay supports SYNC or FREE timing. MACKITY adds the Airwindows-style master character stage. SIDECHAIN controls kick-triggered ducking. TMP stores/restores a temporary performance state. HARD RESET requires confirmation.

909 performance row

HAT LEVARE, HAT 16TH and RIDE are independent 909-style performance parts. K+T TUR mirrors the Kick+Tom Turing enable. DECAY activates the performance decay macro.

03 / TURING

Five lanes

T1 Kick+Tom, T2 Hats, T3 Macro A, T4 Macro B and T5 Resonator. Each lane has DENS, VAR, division, scale, accent, step length, erase, freeze and regeneration.

Turing CV

Each lane can route its current Turing value to a selected destination. Pitch remains automatic/musical and is intentionally not a Turing CV destination.

CV destinations

K+T: Decay, BF, Drive, VCA. Hat: Decay, Filter, Drive, Morph, VCA. Macro A/B: Decay, Timbre, Harmonics, Morph, VCA. Resonator: Damping, Brightness, Structure, Position, VCA.

Randomization rule

Turing CV destinations are performer-controlled and excluded from global and per-voice randomization.

Four LFOs

Four synchronized LFOs provide waveform, rate, destination and amount. LFO modulation and selected Turing CV share the relevant performance modulation buses. Pitch and pan remain available to LFO modulation where applicable.

Global generative controls

The lower section includes root/tuning controls, GEN rate/amount and REC for stereo master WAV recording.

04 / BREAK

Slice mode

ENGINE enables BREAK; BUS MUTE mutes its output. NEW, FREEZE, density, variation, step length and division control the sequence. Performance macros are PITCH, ROLL, REV and CHOP with shared AMT.

Texture mode

Texture mode provides POS, SIZE, DENS, PITCH and GRAIN plus HOLD and SYNC/FREE.

909 / BUS

The integrated 909 section provides CLOSED HAT, OPEN HAT, CRASH and RIDE. Hats share one level control; Crash/Ride use another.

Bus sources

Route BRK, K+T, HAT, MAC A, MAC B and RES independently into the processor. LEVEL IN sets input gain.

Dual filters + output

Filter A and B each provide cutoff, resonance and HP/LP operation. LINK couples them. BF controls groove/body filtering. Output provides LEVEL, DELAY and RVB.

05 / SYNC + CLOCKING

Performance SYNC

Mixer SYNC quantizes supported performance changes so they occur at musical boundaries.

Sync sources

TTG can use internal timing, external MIDI clock or Ableton Link as the synchronization source.

Ableton Link

Enable LINK in MIDI / OPTIONS to join a Link session. TTG shows session status and peer count. START/STOP optionally follows shared Link transport state in addition to tempo and phase.

06 / MIDI + OPTIONS

MIDI I/O

Independent MIDI IN/OUT, CLOCK IN/OUT, NOTES and CC. Test Note and Test CC assist setup. Device, channel and CC base are selectable. CLOCK OFFSET provides timing correction.

Project Save / Load

SAVE stores the current TTG project; LOAD opens a project via the Android file browser.

Audio output

Choose Android system audio or USB DIRECT 1/2 where supported. TTG reports direct-USB status.

Master split

Each of the six buses can be routed independently to CH1 and/or CH2. CH1 is physical left and CH2 physical right, supporting stereo or dual-mono routing.

Control behavior

CURVE: NORMAL / SOFT END changes touch response. VALUES ON/OFF controls parameter-value overlays. LAT cycles latency profiles.

Remote control

REMOTE CTRL enables the companion remote-controller workflow and displays connection state.

Recording

REC captures the stereo master as WAV.

07 / CURRENT RELEASE

TTG Beta 5 B93 is the current stable release. It includes the dual Plaits-based Macro A/B engines, Rings-style Resonator, expanded 909 percussion, Turing CV routing, improved MIDI and Ableton Link synchronization, project save/load, USB Direct and master split routing, remote-control support, and the latest parameter-label corrections.

The online manual remains the primary documentation and should be considered authoritative when it is newer than this PDF copy.

Project: Techno Turing Groovebox / Exsiderurgica