



XIQ API – Permission Requirements and User Roles



Revisions History

Rev	Revision Summary	By Whom	Publish Date
1.0	Initial Draft	Tim	Feb 1, 2023
1.5	23r6 updates	Tim	October 31, 2023
24r2	24r2 updates	Tim	March 22, 2024



Table of Contents

Authentication	14
POST /login	14
POST /logout	14
Authorization	14
POST /auth/apitoken	
POST /auth/apitoken/:validate	
GET /auth/apitoken/info	
GET /auth/permissions	
POST /auth/permissions/:check	
GET /operations/{operationId}	
DELETE /operations/{operationId}	
POST /operations/{operationId}/:cancel	
Account	16
POST /account/:switch	
GET /account/external	
GET /account/home	
GET /account/vig	
POST /account/viq/:backup	
GET /account/vig/default-device-password	
PUT /account/viq/default-device-password	
Users	10
GET /users	
POST /users	
GET /users/{id}	
DELETE /users/{id}	
PATCH /users/{id}	
GET /users/external	
POST /users/external	
GET /users/external/{id}	
DELETE /users/external/{id}	
PATCH /users/external/{id}	
GET /users/me	
HIQ	20
GET /hig/context	
PUT /hiq/context	
GET /hig/context/creating	
PUT /hiq/context/creating	
GET /hiq/context/reading	
PUT /hiq/context/reading	
GET /hiq/organizations	
POST /hiq/organizations	
DELETE /hig/organizations/{id}	
POST /hiq/organizations/{id}/:rename	
GET /big/status	23



Location	24
POST /locations	24
POST /locations/:init	24
PUT /locations/{id}	24
DELETE /locations/{id}	24
GET /locations/building	25
POST /locations/building	25
PUT /locations/building/{id}	25
DELETE /locations/building/{id}	26
GET /locations/floor	26
POST /locations/floor	26
PUT /locations/floor/{id}	27
DELETE /locations/floor/{id}	27
POST /locations/floorplan	27
GET /locations/site	27
POST /locations/site	28
PUT /locations/site/{id}	28
DELETE /locations/site/{id}	28
GET /locations/tree	28
GET /locations/tree/devices	29
GET /locations/tree/maps	29
De la	20
Device	
GET /devices	
POST /devices/:cli	
POST /devices/:delete	
POST /devices/:manage	
POST /devices/:onboard	
POST /devices/:reboot	
POST /devices/:unmanage	
GET /devices/{id}	
DELETE /devices/{id}	
POST /devices/{id}/:cli	
POST /devices/{id}/:manage	
POST /devices/{id}/:reboot	
POST /devices/{id}/:reset	
POST /devices/{id}/:unmanage	
GET /devices/{id}/alarms	
POST /devices/{id}/bounce-port	
PUT /devices/{id}/description	
GET /devices/{id}/history/cpu-mem	
PUT /devices/{id}/hostname	
GET /devices/{id}/ibeacon	
GET /devices/{id}/installation-report	
GET /devices/{id}/interfaces/wifi	
GET /devices/{id}/location	
PUT /devices/{id}/location	
DELETE /devices/{id}/location	
GET /devices/{id}/network-policy	
PUT /devices/{id}/network-policy	40



	DELETE /devices/{id}/network-policy	
	POST /devices/{id}/ssid/:override	
	GET /devices/{id}/ssid/status	41
	POST /devices/{id}/ssid/status/:change	41
	POST /devices/{id}/thread/commissioner/:start	41
	POST /devices/{id}/thread/commissioner/:stop	42
	POST /devices/country-code/:assign	42
	GET /devices/{id}/digital-twin	42
	PUT /devices/ibeacon	42
	POST /devices/location/:assign	43
	POST /devices/location/:query	43
	POST /devices/location/:revoke	43
	POST /devices/network-policy/:assign	43
	POST /devices/network-policy/:query	43
	POST /devices/network-policy/:revoke	44
	GET /devices/network-policy/{policyId}	44
	POST /devices/os/:change	44
	PUT /devices/radius-proxy/:assign	45
	DELETE /devices/radius-proxy/:revoke	45
	GET /devices/stats	45
۷e	twork Policy	45
	GET /network-policies	46
	POST /network-policies	
	GET /network-policies/{id}	46
	PUT /network-policies/{id}	46
	DELETE /network-policies/{id}	46
	GET /network-policies/{id}/ssids	47
	POST /network-policies/{id}/ssids/:add	47
	POST /network-policies/{id}/ssids/:remove	47
Cli	ent	47
	GET /clients/{id}	47
	GET /clients/active	48
	PUT /clients/alias	48
	GET /clients/active/count	48
	GET /clients/byMac/{client_mac}	48
	DELETE /clients/byMac/{client_mac}	49
	GET /clients/summary	49
	GET /clients/usage	49
4 <i>p</i>	plication	49
	GET /applications	50
	GET /applications/{id}/clients/top{n}	50
	GET /applications/top{n}	50
4 <i>le</i>	ert	50
	GET /alerts	52
	GET /alerts/count-by-{group}	56
loc	g	57



	GET /logs/accounting	
	GET /logs/audit	57
	POST /logs/audit/reports	57
	GET /logs/audit/reports/{id}	58
	GET /logs/auth	58
	GET /logs/credential	58
	GET /logs/email	58
	GET /logs/sms	59
N	otification	59
	GET /subscriptions/webhook	59
	POST /subscriptions/webhook	59
	DELETE /subscriptions/webhook/{id}	60
Ca	onfiguration - Deployment	60
	POST /deployments	60
	GET /deployments/overview	60
	GET /deployments/status	60
Ca	onfiguration - Basic	61
	GET /vlan-profiles	
	POST /vlan-profiles	
	POST /vlan-profiles/:delete	
	GET /vlan-profiles/{id}	
	DELETE /vlan-profiles/{id}	
	5 2 2 2 7 7 1011 promes/ (10)	······································
	PATCH /vlan-profiles/{id}	62
<u> </u>	PATCH /vlan-profiles/{id}	
Ca	onfiguration - User Management	62
Co	onfiguration - User Management GET /email-templates	62
Ca	Onfiguration - User Management	62
Ca	GET /email-templates	
Co	Onfiguration - User Management GET /email-templates GET /endusers POST /endusers PUT /endusers/{id}	
Co	Onfiguration - User Management GET /email-templates GET /endusers POST /endusers PUT /endusers/{id} DELETE /endusers/{id}	
Co	GET /email-templates GET /endusers POST /endusers PUT /endusers/{id} DELETE /endusers/{id} POST /endusers/{id} POST /endusers/{id}	
Co	Onfiguration - User Management GET /email-templates GET /endusers POST /endusers PUT /endusers/{id} DELETE /endusers/{id} POST /endusers/{id}/:regenerate-password GET /pcgs/key-based	
Co	Onfiguration - User Management GET /email-templates GET /endusers POST /endusers PUT /endusers/{id} DELETE /endusers/{id}. POST /endusers/{id}/:regenerate-password GET /pcgs/key-based POST /pcgs/key-based	
Ca	Onfiguration - User Management GET /email-templates GET /endusers POST /endusers PUT /endusers/{id} DELETE /endusers/{id}. POST /endusers/{id}/:regenerate-password GET /pcgs/key-based POST /pcgs/key-based DELETE /pcgs/key-based/network-policy-{policyId}	
Co	Onfiguration - User Management GET /email-templates GET /endusers POST /endusers PUT /endusers/{id} DELETE /endusers/{id}. POST /endusers/{id}/:regenerate-password GET /pcgs/key-based POST /pcgs/key-based DELETE /pcgs/key-based/network-policy-{policyId}/:onboard	
Co	GET /email-templates GET /endusers POST /endusers PUT /endusers/{id} DELETE /endusers/{id} POST /endusers/{id}/:regenerate-password GET /pcgs/key-based POST /pcgs/key-based DELETE /pcgs/key-based/network-policy-{policyId}/:onboard POST /pcgs/key-based/network-policy-{policyId}/keys/:email	
Ca	GET /email-templates GET /endusers POST /endusers PUT /endusers/{id} DELETE /endusers/{id}/:regenerate-password GET /pcgs/key-based POST /pcgs/key-based DELETE /pcgs/key-based/network-policy-{policyId}/:onboard POST /pcgs/key-based/network-policy-{policyId}/keys/:email POST /pcgs/key-based/network-policy-{policyId}/keys/:generate	
Co	GET /email-templates GET /endusers POST /endusers PUT /endusers/{id} DELETE /endusers/{id}. POST /endusers/{id}/:regenerate-password GET /pcgs/key-based POST /pcgs/key-based DELETE /pcgs/key-based/network-policy-{policyId}/:onboard POST /pcgs/key-based/network-policy-{policyId}/:email POST /pcgs/key-based/network-policy-{policyId}/keys/:generate GET /pcgs/key-based/network-policy-{policyId}/keys/:generate GET /pcgs/key-based/network-policy-{policyId}/port-assignments	
Co	GET /email-templates GET /endusers POST /endusers PUT /endusers/{id} DELETE /endusers/{id} POST /endusers/{id}/:regenerate-password GET /pcgs/key-based POST /pcgs/key-based/network-policy-{policyId}/:onboard POST /pcgs/key-based/network-policy-{policyId}/keys/:generate POST /pcgs/key-based/network-policy-{policyId}/keys/:generate GET /pcgs/key-based/network-policy-{policyId}/port-assignments POST /pcgs/key-based/network-policy-{policyId}/port-assignments	
Co	GET /email-templates GET /endusers POST /endusers PUT /endusers/{id} DELETE /endusers/{id} POST /endusers/{id}/:regenerate-password GET /pcgs/key-based POST /pcgs/key-based/network-policy-{policyld}/:onboard POST /pcgs/key-based/network-policy-{policyld}/keys/:email POST /pcgs/key-based/network-policy-{policyld}/keys/:generate GET /pcgs/key-based/network-policy-{policyld}/port-assignments POST /pcgs/key-based/network-policy-{policyld}/port-assignments POST /pcgs/key-based/network-policy-{policyld}/port-assignments POST /pcgs/key-based/network-policy-{policyld}/port-assignments POST /pcgs/key-based/network-policy-{policyld}/port-assignments POST /pcgs/key-based/network-policy-{policyld}/port-assignments GET /pcgs/key-based/network-policy-{policyld}/users	
Co	GET /email-templates GET /endusers POST /endusers PUT /endusers/{id} DELETE /endusers/{id}/:regenerate-password GET /pcgs/key-based POST /pcgs/key-based DELETE /pcgs/key-based/network-policy-{policyld}/:onboard POST /pcgs/key-based/network-policy-{policyld}//eps/:email POST /pcgs/key-based/network-policy-{policyld}//eps/:generate GET /pcgs/key-based/network-policy-{policyld}/port-assignments POST /pcgs/key-based/network-policy-{policyld}/port-assignments POST /pcgs/key-based/network-policy-{policyld}/port-assignments POST /pcgs/key-based/network-policy-{policyld}/port-assignments POST /pcgs/key-based/network-policy-{policyld}/port-assignments POST /pcgs/key-based/network-policy-{policyld}/port-assignments GET /pcgs/key-based/network-policy-{policyld}/users PUT /pcgs/key-based/network-policy-{policyld}/users	
Co	GET /email-templates GET /endusers POST /endusers PUT /endusers/{id} DELETE /endusers/{id}/:regenerate-password GET /pcgs/key-based POST /pcgs/key-based/network-policy-{policyId}/:onboard POST /pcgs/key-based/network-policy-{policyId}/keys/:email POST /pcgs/key-based/network-policy-{policyId}/port-assignments GET /pcgs/key-based/network-policy-{policyId}/port-assignments POST /pcgs/key-based/network-policy-{policyId}/port-assignments POST /pcgs/key-based/network-policy-{policyId}/port-assignments POST /pcgs/key-based/network-policy-{policyId}/users PUT /pcgs/key-based/network-policy-{policyId}/users PUT /pcgs/key-based/network-policy-{policyId}/users POST /pcgs/key-based/network-policy-{policyId}/users POST /pcgs/key-based/network-policy-{policyId}/users	
Co	GET /email-templates GET /endusers POST /endusers PUT /endusers/{id} DELETE /endusers/{id}/:regenerate-password GET /pcgs/key-based POST /pcgs/key-based/network-policy-{policyId}/:onboard POST /pcgs/key-based/network-policy-{policyId}/keys/:email POST /pcgs/key-based/network-policy-{policyId}/keys/:generate GET /pcgs/key-based/network-policy-{policyId}/port-assignments POST /pcgs/key-based/network-policy-{policyId}/port-assignments POST /pcgs/key-based/network-policy-{policyId}/port-assignments POST /pcgs/key-based/network-policy-{policyId}/port-assignments POST /pcgs/key-based/network-policy-{policyId}/users PUT /pcgs/key-based/network-policy-{policyId}/users POST /pcgs/key-based/network-policy-{policyId}/users POST /pcgs/key-based/network-policy-{policyId}/users POST /pcgs/key-based/network-policy-{policyId}/users POST /pcgs/key-based/network-policy-{policyId}/users	
Co	GET /email-templates GET /endusers POST /endusers PUT /endusers/{id} DELETE /endusers/{id} POST /endusers/{id}/:regenerate-password GET /pcgs/key-based POST /pcgs/key-based POST /pcgs/key-based/network-policy-{policyId}/:onboard POST /pcgs/key-based/network-policy-{policyId}/:epsizenerate POST /pcgs/key-based/network-policy-{policyId}//seys/:email POST /pcgs/key-based/network-policy-{policyId}/keys/:generate GET /pcgs/key-based/network-policy-{policyId}/port-assignments POST /pcgs/key-based/network-policy-{policyId}/port-assignments POST /pcgs/key-based/network-policy-{policyId}/users PUT /pcgs/key-based/network-policy-{policyId}/users PUT /pcgs/key-based/network-policy-{policyId}/users POST /pcgs/key-based/network-policy-{policyId}/users POST /pcgs/key-based/network-policy-{policyId}/users DELETE /pcgs/key-based/network-policy-{policyId}/users DELETE /pcgs/key-based/network-policy-{policyId}/users GET /sms-templates	
Co	GET /email-templates GET /endusers POST /endusers PUT /endusers/{id} DELETE /endusers/{id} POST /endusers/{id}/:regenerate-password GET /pcgs/key-based POST /pcgs/key-based POST /pcgs/key-based/network-policy-{policyId}/:onboard POST /pcgs/key-based/network-policy-{policyId}/keys/:email POST /pcgs/key-based/network-policy-{policyId}/keys/:generate GET /pcgs/key-based/network-policy-{policyId}/port-assignments POST /pcgs/key-based/network-policy-{policyId}/port-assignments GET /pcgs/key-based/network-policy-{policyId}/port-assignments POST /pcgs/key-based/network-policy-{policyId}/users PUT /pcgs/key-based/network-policy-{policyId}/users PUT /pcgs/key-based/network-policy-{policyId}/users POST /pcgs/key-based/network-policy-{policyId}/users DELETE /pcgs/key-based/network-policy-{policyId}/users DELETE /pcgs/key-based/network-policy-{policyId}/users GET /sms-templates GET /usergroups	
Co	GET /email-templates GET /endusers POST /endusers PUT /endusers/{id} DELETE /endusers/{id}/:regenerate-password GET /pcgs/key-based POST /pcgs/key-based/network-policy-{policyId}/:onboard POST /pcgs/key-based/network-policy-{policyId}/keys/:email POST /pcgs/key-based/network-policy-{policyId}/keys/:email POST /pcgs/key-based/network-policy-{policyId}/keys/:generate GET /pcgs/key-based/network-policy-{policyId}/port-assignments POST /pcgs/key-based/network-policy-{policyId}/port-assignments POST /pcgs/key-based/network-policy-{policyId}/port-assignments POST /pcgs/key-based/network-policy-{policyId}/users PUT /pcgs/key-based/network-policy-{policyId}/users PUT /pcgs/key-based/network-policy-{policyId}/users DELETE /pcgs/key-based/network-policy-{policyId}/users DELETE /pcgs/key-based/network-policy-{policyId}/users DELETE /pcgs/key-based/network-policy-{policyId}/users GET /sms-templates GET /usergroups POST /usergroups	
Cu	GET /email-templates GET /endusers POST /endusers PUT /endusers/{id} DELETE /endusers/{id} POST /endusers/{id}/:regenerate-password GET /pcgs/key-based POST /pcgs/key-based POST /pcgs/key-based/network-policy-{policyId}/:onboard POST /pcgs/key-based/network-policy-{policyId}/keys/:email POST /pcgs/key-based/network-policy-{policyId}/keys/:generate GET /pcgs/key-based/network-policy-{policyId}/port-assignments POST /pcgs/key-based/network-policy-{policyId}/port-assignments GET /pcgs/key-based/network-policy-{policyId}/port-assignments POST /pcgs/key-based/network-policy-{policyId}/users PUT /pcgs/key-based/network-policy-{policyId}/users PUT /pcgs/key-based/network-policy-{policyId}/users POST /pcgs/key-based/network-policy-{policyId}/users DELETE /pcgs/key-based/network-policy-{policyId}/users DELETE /pcgs/key-based/network-policy-{policyId}/users GET /sms-templates GET /usergroups	



figuration - Policy	
GET /ccgs	
POST /ccgs	
GET /ccgs/{id}	
PUT /ccgs/{id}	
DELETE /ccgs/{id}	
GET /classification-rules	
POST /classification-rules	
GET /classification-rules/{id}	
PUT /classification-rules/{id}	
DELETE /classification-rules/{id}	
GET /iot-profiles	
POST /iot-profiles	
GET /iot-profiles/{id}	
PUT /iot-profiles/{id}	
DELETE /iot-profiles/{id}	
GET /l3-address-profiles	
GET /radio-profiles	
POST /radio-profiles	
GET /radio-profiles/{id}	
PUT /radio-profiles/{id}	
DELETE /radio-profiles/{id}	
GET /radio-profiles/channel-selection/{channel-selection-id}	
PUT /radio-profiles/channel-selection/{channel-selection-id}	
GET /radio-profiles/mac-ouis	
POST /radio-profiles/mac-ouis	
GET /radio-profiles/mac-ouis/{mac-oui-id}	
PUT /radio-profiles/mac-ouis/{mac-oui-id}	
DELETE /radio-profiles/mac-ouis/{mac-oui-id}	
GET /radio-profiles/miscellaneous/{radio-misc-id}	
PUT /radio-profiles/miscellaneous/{radio-misc-id}	
GET /radio-profiles/neighborhood-analysis/{neigh-analysis-id}	
PUT /radio-profiles/neighborhood-analysis/{neigh-analysis-id}	
GET /radio-profiles/radio-usage-opt/{radio-usage-opt-id}	
PUT /radio-profiles/radio-usage-opt/{radio-usage-opt-id}	
GET /radio-profiles/sensor-scan/{sensor-scan-id}	
PUT /radio-profiles/sensor-scan/{sensor-scan-id}	
GET /radio-profiles/wmm-qos/{radio-qos-id}	
PUT /radio-profiles/wmm-qos/{radio-qos-id}	
GET /ssids	
POST /ssids/{id}/:rename	
POST /ssids/{id}/cwp/:attach	
POST /ssids/{id}/cwp/:disable	
POST /ssids/{id}/cwp/:enable	
PUT /ssids/{id}/mode/dot1x	
PUT /ssids/{id}/mode/open	
PUT /ssids/{id}/mode/ppsk	
PUT /ssids/{id}/mode/psk	
PUT /ssids/{id}/mode/wep	77



	PUT /ssids/{id}/psk/password	
	POST /ssids/{id}/radius-server-group/:attach	78
	POST /ssids/{id}/user-profile/:attach	78
	GET /user-profiles	79
	POST /user-profiles	79
	GET /user-profiles/{id}	79
	PUT /user-profiles/{id}	79
	DELETE /user-profiles/{id}	80
Coi	nfiguration - Authentication	21
COI	GET /ad-servers	
	GET / cwps	
	GET / Idap-servers	
	POST /Idap-servers	
	GET /ldap-servers/{id}	
	PUT /ldap-servers/{id}	
	DELETE /ldap-servers/{id}	
	GET /radius-client-objects	
	POST /radius-client-objects	
	GET /radius-client-objects/{id}	
	PUT /radius-client-objects/{id}	
	·	
	DELETE /radius-client-objects/{id}	
	GET /radius-proxies POST /radius-proxies	
	GET /radius-proxies/{id}	
	PUT /radius-proxies/{id}	
	DELETE /radius-proxies/{id}	
	GET /radius-proxies/devices	
	GET /radius-servers/external	
	POST /radius-servers/external	
	GET /radius-servers/external/{id}	
	PUT /radius-servers/external/{id}	
	DELETE /radius-servers/external/{id}	
	GET /radius-servers/internal	
	POST /radius-servers/internal	
	DELETE /radius-servers/internal	
	GET /radius-servers/internal/{id}	
	PUT /radius-servers/internal/{id}	
	DELETE /radius-servers/internal/{id}	
	GET /radius-servers/internal/devices	8/
Cor	nfiguration - Certificate	<i>88</i>
	GET /certificates	88
Cor	pilot – Connectivity Experience	88
	GET /copilot/connectivity/wired/events	
	GET /copilot/connectivity/wired/everies	
	GET /copilot/connectivity/wired/experience	
	GET /copilot/connectivity/wired/nardware	
	GET /copilot/connectivity/wired/quality-index	
	GET /copilot/connectivity/wireless/appsGET /copilot/connectivity/wireless/events	
	GET/Copilot/Collifectivity/wireless/events	90



GET /copilot/connectivity/wireless/experience	90
GET /copilot/connectivity/wireless/performance	91
GET /copilot/connectivity/wireless/quality-index	92
GET /copilot/connectivity/wireless/time-to-connect	92
GET /copilot/connectivity/wireless/views	92
Copilot – Anomalies	92
GET /copilot/anomalies/adverse-traffic/device-stats	93
GET / copilot/anomalies/adverse-traffic/packet-counts	
GET /copilot/anomalies/anomalies-by-category	
GET /copilot/anomalies/device-by-location	
GET /copilot/anomalies/device-with-locations	
PUT /copilot/anomalies/devices/feedback	
PUT /copilot/anomalies/devices/update-action	
GET /copilot/anomalies/dfs-recurrence/channel-stats	
GET /copilot/anomalies/dfs-recurrence/count-stats	
GET /copilot/anomalies/locations	
GET /copilot/anomalies/poeflapping/stats	
GET /copilot/anomalies/notifications	
GET /copilot/anomalies/port-efficiency/speed-duplex-stats	
GET /copilot/anomalies/port-efficiency/stats	
GET /copilot/anomalies/wifi-capacity/client-list	
GET /copilot/anomalies/wifi-capacity/stats	
GET /copilot/anomalies/report	
PUT /copilot/anomalies/update-action	
PUT / copilot/anomalies/update-device-action	
GET /copilot/anomalies/wifi-efficiency/client-list	
GET /copilot/anomalies/wifi-efficiency/stats	
GET /copilot/assurance-scans/overview	
Packet Capture	
GET /packetcaptures	
POST /packetcaptures	
GET /packetcaptures/{id}	
Delete /packetcaptures/{id}	
POST /packetcaptures/{id}/:stop	
POST /packetcaptures/{id}/:upload	
GET /packetcaptures/files	99
Essentials - ExtremeLocation	
GET /essentials/eloc/clients/{client-mac}/last-known-location	100
APPENDIX – A	104
API call list based on Roles	104
Administrator	
Operator	
Monitor	
Installer	
Observer	
Help Desk	



Application Operator	
PENDIX – B	
PI call list based on Permission	
logout	
auth	
auth:r	
token:new	
perm:check	
lro	
lro:r	
account	99
account:switch	99
account:r	99
viq:backup	99
user	99
user-me:r	99
user:r	
hiq	
hiq:r	
org	
org:new	
org:del	
org:rename	
hiq.ctx	
hiq.ctx:r	
hig.ctx:w	
device	
device:r	
device:list	
device:view	
device:new	
device:del	
device:cli	
device:deploy	
device:manage	
device:unmanage	
device:reboot	
device:reset	
device:thread-commissioner	
client	
client:r	
locations	
locations:r	
network-policy	
policy:ssid	
network-policy:r	
ssid	
JJIU	



ssid:r	
pcg:key	
pcg:key:r	106
subscriptions-webhook	107
subscriptions-webhook:r	107
CCg	107
ccg:r	
log	
log:r	
СМЪ	
CWp:r	
sms-tmpl	
sms-tmpl:r	
class-rule	
class-rule:r	
user-profile	
user-profile:r	
radius-proxy	
radius-proxy:r	
radius-server	
radius-server:r	
usergroup	
usergroup:r	
deployment	
deployment:r	
ad-server	110
ad-server:r	110
alert	110
alert:r	110
app	110
application:r	111
l3-address-profile	111
l3-address-profile:r	111
vlan-profile	
vlan-profile:r	
enduser	
enduser:r	
radius-client-object	
radius-client-object:r	
ldap-server	
ldap-server:r	
email-template	
email-template:remail-template:r	
certificate	
certificate:r	
radio-profile	
radio-profile:r	
iot-profile	
iot-profile:r	
copilot-connectivity-wired:r	114



copilot-connectivity-wireless:r	
copilot-anomalies:r	
copilot-assurance-scans:r	
packet-capture	11
packet-capture:r	11!



Introduction

This document will list each category of XIQ APIs and all the API calls under those categories. Laid out as it is laid out on the api.extremecloudiq.com Swagger page. Under each category, the document will list the category permissions that can be used for the API calls in that category. Most categories have two permissions for the category. The first permission will match or be similar to the category's name. Example - **device** for the devices category. This permission will give access to all the GET, POST, PUT, PATCH, and DELETE API calls in that category. The second permission will be named the same as the first but followed with a :r. Example - **device**:r for the devices category. This permission will give access to only the GET API calls in that category.

This document will also list any additional permissions available for a particular API call. This would allow for a token to be created only to be able to perform a specific API call without having permission to do all API calls within the category. Example – **device:list** under the <u>GET /devices</u> API call. This would allow the token only to be able to view the list of devices using that API call but not be able to perform any of the other GET API calls in the devices category.

This document also notes which Roles have access to each of the API call.

In addition, there is $\underline{\text{Appendix - A}}$ that lists the different roles with a list of the API calls available to those roles by default as well as $\underline{\text{Appendix - B}}$ that lists the different permissions with a list of the API calls available with that permission.



Authentication

No default permissions for this category

POST /login

No permissions needed – This call uses basic auth to generate a token. This token will have access to APIs based on the user's role.

POST /logout Permissions:

"logout" – revokes currently used token

```
Roles:
"Operator",
"Help Desk",
"Monitor",
"Administrator",
"Installer",
"Observer",
"Guest Management"
```

Authorization

Permissions:

"auth" – Permission for all API calls in the Authorization Section

"auth:r" – Permission for all GET API calls in the Authorization Section

POST /auth/apitoken

Permissions:

"token:new" – Permission to generate a new token.

NOTE: new tokens can only be granted permissions that the currently used token has.

Also included with "auth"

Roles:

"Operator",
"Administrator",

"Monitor",
"Installer"

POST /auth/apitoken/:validate

Permissions:



No Specific permission - included with "auth" Roles: "Operator", "Administrator" GET /auth/apitoken/info Permissions: No Specific permission - included with "auth" and "auth:r" Roles: "Operator", "Administrator", "Monitor", "Observer" GET /auth/permissions Permissions: No Specific permission - included with "auth" and "auth:r" Roles: "Operator", "Administrator", "Monitor", "Observer" POST /auth/permissions/:check Permissions: "perm:check" – Allows token to check permissions needed for any API call Also included with "auth" Roles "Operator", "Administrator" Operation Permissions: "Iro" – Permission for all API calls in the Operation Section "lor:r" – Permission for all GET API calls in the Operation Section GET /operations/{operationId} Permissions:



No Specific permission - included with "lro" and "lro:r" Roles: "Operator", "Administrator" DELETE /operations/{operationId} Permissions: No Specific permission - included with "lro" Roles: "Operator", "Administrator" POST /operations/{operationId}/:cancel Permissions: No Specific permission - included with "lro" Roles: "Operator", "Administrator" Account "account" - Permission for all API calls in the Account Section "account:r" - Permission for all GET API calls in the Account Section POST /account/:switch Permissions: "account:switch" - Allows user to switch to external account Also included with "account" Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer", "Observer", "Guest Management" GET /account/external

Permissions:

Page 16 of 139



No Specific permission - included with "account" and "account:r" Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer", "Observer", "Guest Management" GET /account/home Permissions: No Specific permission - included with "account" and "account:r" Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer", "Observer", "Guest Management" GET /account/viq Permissions: No Specific permission - included with "account" and "account:r" Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer", "Observer", "Guest Management" POST /account/viq/:backup Permissions: "viq:backup" – Permission to backup the viq. Also included with "account" Roles:



```
"Operator",
"Administrator"
GET /account/vig/default-device-password
Permissions:
No Specific permission - included with "account" and "account:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer",
"Guest Management"
PUT /account/viq/default-device-password
Permissions:
No Specific permission - included with "account"
Roles:
"Operator",
"Administrator"
Users
Permissions:
"user" - Permission for all API calls in the User Section
"user:r" - Permission for all GET API calls in the User Section
GET /users
Permissions:
No Specific permission - included with "user" and "user:r"
Roles:
"Operator",
"Administrator",
"Monitor"
POST /users
Permissions:
No Specific permission - included with "user"
```



```
Roles:
"Administrator"
GET /users/{id}
Permissions:
No Specific permission - included with "user" and "user:r"
Roles:
"Operator",
"Administrator",
"Monitor"
DELETE /users/{id}
Permissions:
No Specific permission - included with "user"
Roles:
"Administrator"
PATCH /users/{id}
Permissions:
No Specific permission - included with "user"
Roles:
"Administrator"
GET /users/external
Permissions:
No Specific permission - included with "user" and "user:r"
Roles:
"Operator",
"Administrator",
"Monitor"
POST /users/external
Permissions:
No Specific permission - included with "user"
Roles:
"Administrator"
```



Permissions: No Specific permission - included with "user" and "user:r" Roles: "Operator", "Administrator", "Monitor" DELETE /users/external/{id} Permissions: No Specific permission - included with "user" Roles: "Administrator" PATCH /users/external/{id} Permissions: No Specific permission - included with "user" Roles: "Administrator" GET /users/me Permissions: "user-me:r" – Permission to view details on yourself Roles: "Operator", "Administrator", "Monitor" HIQ Permissions: "hig" – Permission for all API calls in the HIQ Section "hig:r" – Permission for all GET API calls in the HIQ Section GET /hiq/context Permissions: "hig.ctx" – Permission for control HIQ Context (HIQ account only). "hiq.ctx:r" – Permission to read HIQ Context (HIQ account only).

GET /users/external/{id}



```
Also included with "hiq" and "hiq:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /hiq/context
Permissions:
"hiq.ctx" – Permission for control HIQ Context (HIQ account only).
"hiq.ctx:w" – Permission to switch HIQ Context (HIQ account only).
Also included with "hiq"
Roles:
"Operator",
"Administrator",
"Installer"
GET /hiq/context/creating
Permissions:
"hiq.ctx" – Permission for control HIQ Context (HIQ account only).
"hig.ctx:r" – Permission to read HIQ Context (HIQ account only).
Also included with "hiq" and "hiq:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /hiq/context/creating
Permissions:
"hiq.ctx" – Permission for full control HIQ Context (HIQ account only).
"hig.ctx:w" – Permission to switch HIQ Context (HIQ account only).
Also included with "hiq"
```



```
Roles:
"Operator",
"Administrator",
"Installer"
GET /hiq/context/reading
Permissions:
"hiq.ctx" – Permission for control HIQ Context (HIQ account only).
"hiq.ctx:r" – Permission to read HIQ Context (HIQ account only).
Also included with "hiq" and "hiq:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /hiq/context/reading
Permissions:
"hiq.ctx" – Permission for control HIQ Context (HIQ account only).
"hiq.ctx:w" – Permission to switch HIQ Context (HIQ account only).
Also included with "hiq"
Roles:
"Operator",
"Administrator",
"Installer"
GET /hiq/organizations
Permissions:
"org" – Permission for full control HIQ organizations (HIQ account only).
Also included with "hiq" and "hiq:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
```



```
"Installer",
"Observer"
POST /hiq/organizations
Permissions:
"org" – Permission for full control HIQ organizations (HIQ account only).
"org:new" – Permission to create HIQ organization (HIQ account only).
Also included with "hiq"
Roles:
"Operator",
"Administrator"
DELETE /hiq/organizations/{id}
Permissions:
"org" – Permission for full control HIQ organizations (HIQ account only).
"org:del" – Permission to delete HIQ organization (HIQ account only).
Also included with "hiq"
Roles:
"Operator",
"Administrator"
POST /hiq/organizations/{id}/:rename
Permissions:
"org" – Permission for full control HIQ organizations (HIQ account only).
"org:rename" – Permission to rename HIQ organization (HIQ account only).
Also included with "hiq"
Roles:
"Operator",
"Administrator"
GET /hig/status
Permissions:
No Specific permission - included with "hiq" and "hiq:r"
Roles:
"Operator",
```



```
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
```

Location

Permissions:

"locations" – Permission for all API calls in the Location Section

"locations:r" – Permission for all GET API calls in the Location Section

POST /locations

Permissions:

No Specific permission - included with "locations"

Roles:

"Operator",

"Administrator"

"Installer"

POST /locations/:init

Permissions:

No Specific permission - included with "locations"

Roles:

"Operator",

"Administrator"

"Installer"

PUT /locations/{id}

Permissions:

No Specific permission - included with "locations"

Roles:

"Operator",

"Administrator"

"Installer"

DELETE /locations/{id}

Permissions:

No Specific permission - included with "locations"



```
Roles:
"Operator",
"Administrator"
"Installer"
GET /locations/building
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /locations/building
Permissions:
No Specific permission - included with "locations"
Roles:
"Operator",
"Administrator"
"Installer"
GET /locations/building/{id}
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /locations/building/{id}
Permissions:
No Specific permission - included with "locations"
```



```
Roles:
"Operator",
"Administrator"
"Installer"
DELETE /locations/building/{id}
Permissions:
No Specific permission - included with "locations"
Roles:
"Operator",
"Administrator"
"Installer"
GET /locations/floor
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /locations/floor
Permissions:
No Specific permission - included with "locations"
Roles:
"Operator",
"Administrator"
"Installer"
GET /locations/floor/{id}
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
```



```
"Installer",
"Observer"
PUT /locations/floor/{id}
Permissions:
No Specific permission - included with "locations"
Roles:
"Operator",
"Administrator"
"Installer"
DELETE /locations/floor/{id}
Permissions:
No Specific permission - included with "locations"
Roles:
"Operator",
"Administrator"
"Installer"
POST /locations/floorplan
Permissions:
No Specific permission - included with "locations"
Roles:
"Operator",
"Administrator"
"Installer"
GET /locations/site
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
```



POST /locations/site Permissions: No Specific permission - included with "locations" Roles: "Operator", "Administrator" "Installer" GET /locations/site/{id} Permissions: No Specific permission - included with "locations" and "locations:r" Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer", "Observer" PUT /locations/site/{id} Permissions: No Specific permission - included with "locations" Roles: "Operator", "Administrator" "Installer" DELETE /locations/site/{id} Permissions: No Specific permission - included with "locations" Roles: "Operator", "Administrator" "Installer" **GET /locations/tree** Permissions: No Specific permission - included with "locations" and "locations:r"



```
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /locations/tree/devices
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /locations/tree/maps
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
```

Device

Permissions:

"device" - Permission for all API calls in the Device Section

"device:r" - Permission for all GET API calls in the Device Section

GET /devices

Permissions:

"device:list" – Permission to get the list of devices



```
Also included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /devices/:cli
Permissions:
"device:cli" – Permission to send cli commands to device(s)
Also included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/:delete
Permissions:
"device:del" – Permission to delete device(s)
Also included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/:manage
Permissions:
"device:mange" – Permission to change management on device(s) to MANAGED
Also included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
```



```
POST /devices/:onboard
Permissions:
"device:new" – Permission to onboard device(s)
Also included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/:reboot
Permissions:
"device:reboot" – Permission to reboot device(s)
Also included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/:unmanage
Permissions:
"device:mange" – Permission to change management on device(s) to UNMANAGED
Also included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/{id}
Permissions:
"device:view" – Permission to view details of a device
Also included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
```



```
"Installer",
"Observer"
DELETE /devices/{id}
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/{id}/:cli
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/{id}/:manage
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/{id}/:reboot
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/{id}/:reset
Permissions:
"device:reset" – Permission to reset a device to factory default
```



Also included with "device" Roles: "Operator", "Administrator", "Installer" POST /devices/{id}/:unmanage Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" GET /devices/{id}/alarms Permissions: No Specific permission - included with "device" and "device:r" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" POST /devices/{id}/bounce-port Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" GET /devices/{id}/config/vlan-attributes Permissions: No Specific permission - included with "device" and "device:r" Roles: "Operator", "Administrator", "Monitor",



```
"Installer",
"Observer"
POST /devices/{id}/config/vlan-attributes
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
DELETE /devices/{id}/config/vlan-attributes
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
PATCH /devices/{id}/config/vlan-attributes/{vlan_id}
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/{id}/config/vlan-ipv4-intf
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /devices/{id}/config/vlan-ipv4-intf
Permissions:
```



No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" DELETE /devices/{id}/config/vlan-ipv4-intf Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" PATCH /devices/{id}/config/vlan-ipv4-intf/{ipv4IntId} Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" GET /devices/{id}/config/vlan-ipv4-static Permissions: No Specific permission - included with "device" and "device:r" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" POST /devices/{id}/config/vlan-ipv4-static Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer"



```
DELETE /devices/{id}/config/vlan-ipv4-static
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
PATCH /devices/{id}/config/vlan-ipv4-static/{ipv4StaticRouteId}
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
PUT /devices/{id}/description
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/{id}/ftm-settings
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /devices/{id}/config/ftm-settings
Permissions:
No Specific permission - included with "device"
```



```
Roles:
"Operator",
"Administrator",
"Installer"
DELETE /devices/{id}/config/ftm-settings
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/{id}/gallery-image
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /devices/{id}/history/cpu-mem
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /devices/{id}/hostname
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
```



```
GET /devices/{id}/ibeacon
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /devices/{id}/installation-report
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /devices/{id}/interfaces/wifi
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /devices/{id}/location
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
```



```
PUT /devices/{id}/location
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
DELETE /devices/{id}/location
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/{id}/monitor/ipv4-routing
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /devices/{id}/monitor/ipv4-routing-timeline
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
```



GET /devices/{id}/monitor/vlan-attr Permissions: No Specific permission - included with "device" and "device:r" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" GET /devices/{id}/monitor/vlan-ipv4-intf Permissions: No Specific permission - included with "device" and "device:r" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" GET /devices/{id}/network-policy Permissions: No Specific permission - included with "device" and "device:r" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" PUT /devices/{id}/network-policy Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer"



DELETE /devices/{id}/network-policy Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" POST /devices/{id}/ssid/:override Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" GET /devices/{id}/ssid/status Permissions: No Specific permission - included with "device" and "device:r" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" POST /devices/{id}/ssid/status/:change Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" POST /devices/{id}/thread/commissioner/:start Permissions: "device:thread-commissioner" – Permission to change thread commissioner to device(s) Also included with "device"



```
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/{id}/thread/commissioner/:stop
Permissions:
"device:thread-commissioner" – Permission to change thread commissioner to device(s)
Also included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/country-code/:assign
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/{id}/digital-twin
Permissions:
"device:view" – Permission to view details of a device
Also included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /devices/ibeacon
Permissions:
No Specific permission - included with "device"
```



```
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/location/:assign
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/location/:query
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/location/:revoke
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/network-policy/:assign
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/network-policy/:query
Permissions:
```



No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" POST /devices/network-policy/:revoke Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" GET /devices/network-policy/{policyId} Permissions: No Specific permission - included with "device" and "device:r" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" POST /devices/os/:change Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" GET /devices/radio-information Permissions: "device:list" – Permission to get the list of devices Also included with "device" and "device:r"



```
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /devices/radius-proxy/:assign
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
DELETE /devices/radius-proxy/:revoke
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/stats
Permissions:
"device:view" – Permission to view details of a device
Also included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
```

Network Policy

Permissions:

"network-policy" – Permission for all API calls in the Network Policy Section "network-policy:" – Permission for all GET API calls in the Network Policy Section



GET /network-policies Permissions: No Specific permission - included with "network-policy" and "network-policy:r" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" POST /network-policies Permissions: No Specific permission - included with "network-policy" Roles: "Operator", "Administrator" GET /network-policies/{id} Permissions: No Specific permission - included with "network-policy" and "network-policy:r" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" PUT /network-policies/{id} Permissions: No Specific permission - included with "network-policy" Roles: "Operator", "Administrator" DELETE /network-policies/{id} Permissions: No Specific permission - included with "network-policy" Roles:



```
"Operator",
"Administrator"
GET /network-policies/{id}/ssids
Permissions:
No Specific permission - included with "network-policy" and "network-policy:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /network-policies/{id}/ssids/:add
Permissions:
"policy:ssid" – SSID management on network-policy
Also included with "network-policy"
Roles:
"Operator",
"Administrator"
POST /network-policies/{id}/ssids/:remove
Permissions:
"policy:ssid" – SSID management on network-policy
Also included with "network-policy"
Roles:
"Operator",
"Administrator"
Client
Permissions:
"client" – Permission for all API calls in the Client Section
"client:r" - Permission for all GET API calls in the Client Section
GET /clients/{id}
Permissions:
No Specific permission - included with "client" and "client:r"
```

Page 47 of 139



```
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /clients/active
Permissions:
No Specific permission - included with "client" and "client:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /clients/alias
Permissions:
No Specific permission - included with "client"
Roles:
"Operator",
"Administrator"
GET /clients/active/count
Permissions:
No Specific permission - included with "client" and "client:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /clients/byMac/{client_mac}
Permissions:
No Specific permission - included with "client" and "client:r"
```



```
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
DELETE /clients/byMac/{client_mac}
Permissions:
No Specific permission - included with "client"
Roles:
"Operator",
"Administrator"
GET /clients/summary
Permissions:
No Specific permission - included with "client" and "client:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /clients/usage
Permissions:
No Specific permission - included with "client" and "client:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
```

Application

Permissions:

"app" – Permission for all API calls in the Application Section

[&]quot;application:r" – Permission for all GET API calls in the Application Section



GET /applications Permissions: No Specific permission - included with "app" and "application:r" Roles: "Operator", "Administrator", "Monitor", "Observer" GET /applications/{id}/clients/top{n} Permissions: No Specific permission - included with "app" and "application:r" Roles: "Operator", "Administrator", "Monitor", "Observer" GET /applications/top{n} Permissions: No Specific permission - included with "app" and "application:r" Roles: "Operator", "Administrator", "Monitor", "Observer" **Alert** No default permissions for this category **GET /alert-policies** Permissions: "alert-policies" – Permission for full control of alert polices. "alert-policies:r" – Permission to read alert polices. Roles: "Operator",



```
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /alert-policies
Permissions:
"alert-policies" – Permission for full control of alert polices.
Roles:
"Operator",
"Administrator"
GET /alert-policies/{id}
Permissions:
"alert-policies" – Permission for full control of alert polices.
"alert-policies:r" – Permission to read alert polices.
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /alert-policies/{id}
Permissions:
"alert-policies" – Permission for full control of alert polices.
Roles:
"Operator",
"Administrator"
DELETE /alert-policies/{id}
Permissions:
"alert-policies" – Permission for full control of alert polices.
Roles:
"Operator",
"Administrator"
```



```
GET /alert-policies/{id}/rules/{alert_rule_id}
Permissions:
"alert-policies" – Permission for full control of alert polices.
"alert-policies:r" – Permission to read alert polices.
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /alert-policies/{id}}/rules/{alert_rule_id}
Permissions:
"alert-policies" – Permission for full control of alert polices.
Roles:
"Operator",
"Administrator"
POST /alert-policies/{id}}/rules/{alert_rule_id}/:disable
Permissions:
"alert-policies" – Permission for full control of alert polices.
Roles:
"Operator",
"Administrator"
PUT /alert-policies/{id}}/rules/{alert_rule_id}/:enable
Permissions:
"alert-policies" – Permission for full control of alert polices.
Roles:
"Operator",
"Administrator"
GET /alert-policies/available-sites
Permissions:
"alert-policies" – Permission for full control of alert polices.
"alert-policies:r" – Permission to read alert polices.
```



```
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /alert-subscriptions/emails
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
"alert-subscriptions:r" – Permission to read alert subscriptions.
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer
POST /alert-subscriptions/emails
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
POST /alert-subscriptions/emails/:delete
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
GET /alert-subscriptions/emails/{id}
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
"alert-subscriptions:r" – Permission to read alert subscriptions.
Roles:
"Operator",
"Administrator",
```



```
"Monitor",
"Installer",
"Observer
PUT /alert-subscriptions/emails/{id}
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
DELETE /alert-subscriptions/emails/{id}
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
POST /alert-subscriptions/emails/{id}/:verify
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
GET /alert-subscriptions/webhooks
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
"alert-subscriptions:r" – Permission to read alert subscriptions.
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer
POST /alert-subscriptions/webhooks
Permissions:
```

"alert-subscriptions" – Permission for full control of alert subscriptions.



```
Roles:
"Operator",
"Administrator"
POST /alert-subscriptions/webhooks/:delete
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
GET /alert-subscriptions/webhooks /{id}
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
"alert-subscriptions:r" – Permission to read alert subscriptions.
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer
PUT /alert-subscriptions/webhooks /{id}
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
DELETE /alert-subscriptions/webhooks /{id}
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
GET /alerts
Permissions:
```



```
"alert" – Permission for full control of alerts.
"alert:r" – Permission to read alerts.
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /alerts/:acknowledge
Permissions:
"alert" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
GET /alerts/count-by-{group}
Permissions:
"alert" – Permission for full control of alerts.
"alert:r" – Permission to read alerts.
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /alerts/report
Permissions:
"alert" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
GET /alerts/reports/{id}
Permissions:
"alert" – Permission for full control of alerts.
```



```
"alert:r" – Permission to read alerts.
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
Log
Permissions:
"log" – Permission for all API calls in the Log Section
"log:r" – Permission for all GET API calls in the Log Section
GET /logs/accounting
Permissions:
No Specific permission - included with "log" and "log:r"
Roles:
"Operator",
"Administrator",
"Monitor",
'Installer',
"Observer",
"Application Operator"
GET /logs/audit
Permissions:
No Specific permission - included with "log" and "log:r"
Roles:
"Operator",
"Administrator",
"Monitor",
'Installer',
"Observer",
"Application Operator"
POST /logs/audit/reports
Permissions:
No Specific permission - included with "log"
```



```
Roles:
"Operator",
"Administrator
GET /logs/audit/reports/{id}
Permissions:
No Specific permission - included with "log" and "log:r"
"Operator",
"Administrator",
"Monitor",
'Installer',
"Observer",
"Application Operator"
GET /logs/auth
Permissions:
No Specific permission - included with "log" and "log:r"
Roles:
"Operator",
"Administrator",
"Monitor",
'Installer',
"Observer",
"Application Operator"
GET /logs/credential
Permissions:
No Specific permission - included with "log" and "log:r"
Roles:
"Operator",
"Administrator",
"Monitor",
'Installer',
"Observer",
"Application Operator"
GET /logs/email
Permissions:
No Specific permission - included with "log" and "log:r"
```



```
Roles:
"Operator",
"Administrator",
"Monitor",
'Installer',
"Observer",
"Application Operator"
GET /logs/sms
Permissions:
No Specific permission - included with "log" and "log:r"
Roles:
"Operator",
"Administrator",
"Monitor",
'Installer',
"Observer",
"Application Operator"
Notification
Permissions:
" subscriptions-webhook" – Permission for all API calls in the Notification Section
" subscriptions-webhook:r" – Permission for all GET API calls in the Notification Section
GET /subscriptions/webhook
Permissions:
No Specific permission - included with "subscriptions-webhook" and "subscriptions-
webhook:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
POST /subscriptions/webhook
Permissions:
No Specific permission - included with "subscriptions-webhook"
Roles:
```

"Operator",



"Administrator"

DELETE /subscriptions/webhook/{id}

Permissions:

No Specific permission - included with "subscriptions-webhook"

Roles:

"Operator",

"Administrator"

Configuration - Deployment

Permissions:

- "deployment" Permission for all API calls in the Configuration Deployment Section
- "deployment:r" Permission for all GET API calls in the Configuration Deployment Section

POST /deployments

Permissions:

No Specific permission - included with "deployment"

Roles:

"Operator",

"Administrator"

GET /deployments/overview

Permissions:

No Specific permission - included with "deployment" and "deployment:r"

Roles:

"Operator",

"Help Desk",

"Administrator",

"Monitor",

"Installer",

"Observer",

"Guest Management"

GET /deployments/status

Permissions:

No Specific permission - included with "deployment" and "deployment:r"

Roles:



```
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer",
"Guest Management"
Configuration - Basic
Permissions:
"vlan-profile" – Permission for all API calls in the Configuration - Basic Section
"vlan-profile:r" – Permission for all GET API calls in the Configuration – Basic Section
GET /vlan-profiles
Permissions:
No Specific permission - included with "vlan-profile" and "vlan-profile:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
POST /vlan-profiles
Permissions:
No Specific permission - included with "vlan-profile"
Roles:
"Operator",
"Administrator"
POST /vlan-profiles/:delete
Permissions:
No Specific permission - included with "vlan-profile"
Roles:
"Operator",
"Administrator"
GET /vlan-profiles/{id}
Permissions:
No Specific permission - included with "vlan-profile" and "vlan-profile:r"
```

Page 61 of 139



```
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
DELETE /vlan-profiles/{id}
Permissions:
No Specific permission - included with "vlan-profile"
Roles:
"Operator",
"Administrator"
PATCH /vlan-profiles/{id}
Permissions:
No Specific permission - included with "vlan-profile"
Roles:
"Operator",
"Administrator"
Configuration - User Management
No default permissions for this category
GET /email-templates
Permissions:
"email-template" – Permission for full of email template.
"email-template:r" – Permission to read email templates
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
GET /endusers
Permissions:
"enduser" – Permission for full control of end users.
"enduser:r" - Permission to read end users
```

Roles:

Page 62 of 139



```
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Observer",
"Guest Management"
POST /endusers
Permissions:
"enduser" – Permission for full control of end users.
Roles:
"Operator",
"Administrator"
PUT /endusers/{id}
Permissions:
"enduser" – Permission for full control of end users.
Roles:
"Operator",
"Administrator"
DELETE /endusers/{id}
Permissions:
"enduser" – Permission for full control of end users.
Roles:
"Operator",
"Administrator"
POST /endusers/{id}/:regenerate-password
Permissions:
"enduser" – Permission for full control of end users.
Roles:
"Operator",
"Administrator"
GET /pcgs/key-based
Permissions:
"pcg:key" – Permission for full control of PCG key based.
"pcg:key:r" – Permission to read PCG key based
```



```
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
POST /pcgs/key-based
Permissions:
"pcg:key" – Permission for full control of PCG key based.
Roles:
"Operator",
"Administrator"
DELETE /pcgs/key-based/network-policy-{policyId}
Permissions:
"pcg:key" – Permission for full control of PCG key based.
Roles:
"Operator",
"Administrator"
POST /pcgs/key-based/network-policy-{policyId}/:onboard
Permissions:
"pcg:key" – Permission for full control of PCG key based.
Roles:
"Operator",
"Administrator"
POST /pcgs/key-based/network-policy-{policyId}/keys/:email
Permissions:
"pcg:key" – Permission for full control of PCG key based.
Roles:
"Operator",
"Administrator"
POST /pcgs/key-based/network-policy-{policyId}/keys/:generate
Permissions:
"pcg:key" – Permission for full control of PCG key based.
```



```
Roles:
"Operator",
"Administrator"
GET /pcgs/key-based/network-policy-{policyId}/port-assignments
Permissions:
"pcg:key" – Permission for full control of PCG key based.
"pcg:key:r" – Permission to read PCG key based
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
POST /pcgs/key-based/network-policy-{policyId}/port-assignments
Permissions:
"pcg:key" – Permission for full control of PCG key based.
Roles:
"Operator",
"Administrator"
GET /pcgs/key-based/network-policy-{policyId}/users
Permissions:
"pcg:key" – Permission for full control of PCG key based.
"pcg:key:r" - Permission to read PCG key based
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
PUT /pcgs/key-based/network-policy-{policyId}/users
Permissions:
"pcg:key" – Permission for full control of PCG key based.
Roles:
"Operator",
"Administrator"
```



POST /pcgs/key-based/network-policy-{policyId}/users Permissions: "pcg:key" – Permission for full control of PCG key based. Roles: "Operator", "Administrator" DELETE /pcgs/key-based/network-policy-{policyId}/users Permissions: "pcg:key" – Permission for full control of PCG key based. Roles: "Operator", "Administrator" **GET /sms-templates** Permissions: "sms-tmpl" – Permission for full control of SMS template. "sms-tmpl:r" – Permission to read SMS template Roles: "Operator", "Administrator", "Monitor", "Observer" **GET /usergroups** Permissions: "usergroup" – Permission for full control of user groups. "usergroup:r" – Permission to read user groups Roles: "Operator", "Administrator", "Monitor", "Observer" POST /usergroups Permissions: "usergroup" – Permission for full control of user groups. Roles:



```
"Operator",
"Administrator"
PUT /usergroups/{id}
Permissions:
"usergroup" – Permission for full control of user groups.
Roles:
"Operator",
"Administrator"
DELETE /usergroups/{id}
Permissions:
"usergroup" – Permission for full control of user groups.
Roles:
"Operator",
"Administrator"
Configuration - Policy
No default permissions for this category
GET /ccgs
Permissions:
"ccg" – Permission for full control of CCG.
"ccg:r" - Permission to read CCG
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
POST /ccgs
Permissions:
"ccg" – Permission for full control of CCG.
Roles:
"Operator",
"Administrator"
```



```
GET /ccgs/{id}
Permissions:
"ccg" – Permission for full control of CCG.
"ccg:r" - Permission to read CCG
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
PUT /ccgs/{id}
Permissions:
"ccg" – Permission for full control of CCG.
Roles:
"Operator",
"Administrator"
DELETE /ccgs/{id}
Permissions:
"ccg" – Permission for full control of CCG.
Roles:
"Operator",
"Administrator"
GET /classification-rules
Permissions:
"class-rule" – Permission for full control of classification rule.
"class-rule:r" – Permission to read classification rule
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
POST /classification-rules
Permissions:
"class-rule" – Permission for full control of classification rule.
Roles:
"Operator",
```



"Administrator" GET /classification-rules/{id} Permissions: "class-rule" – Permission for full control of classification rule. "class-rule:r" – Permission to read classification rule Roles: "Operator", "Administrator", "Monitor", "Observer" PUT /classification-rules/{id} Permissions: "class-rule" – Permission for full control of classification rule. Roles: "Operator", "Administrator" DELETE /classification-rules/{id} Permissions: "class-rule" – Permission for full control of classification rule. Roles: "Operator", "Administrator" **GET /iot-profiles** Permissions: "iot-profile" – Permission for full control of iot-profiles. "iot-profile:r" – Permission to read iot-profiles. Roles: "Operator", "Administrator", "Monitor", "Installer",

"Observer"



POST /iot-profiles Permissions: "iot-profile" – Permission for full control of iot-profiles. Roles: "Operator", "Administrator" GET /iot-profiles/{id} Permissions: "iot-profile" – Permission for full control of iot-profiles. "iot-profile:r" – Permission to read iot-profiles. Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" PUT /iot-profiles/{id} Permissions: "iot-profile" – Permission for full control of iot-profiles. Roles: "Operator", "Administrator" DELETE /iot-profiles/{id} Permissions: "iot-profile" – Permission for full control of iot-profiles. Roles: "Operator", "Administrator" GET /I3-address-profiles Permissions: "I3-address-profile" – Permission for full control of L3 address profile. "I3-address-profile:r" – Permission to read L3 address profile Roles: "Operator",



```
"Administrator",
"Monitor",
"Observer"
GET /radio-profiles
Permissions:
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /radio-profiles
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/{id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radio-profiles/{id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator",
```



```
DELETE /radio-profiles/{id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/channel-selection/{channel-selection-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer".
"Observer"
PUT /radio-profiles/channel-selection/{channel-selection-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/mac-ouis
Permissions:
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /radio-profiles/mac-ouis
Permissions:
```



```
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/mac-ouis/{mac-oui-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radio-profiles/mac-ouis/{mac-oui-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
DELETE /radio-profiles/mac-ouis/{mac-oui-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/miscellaneous/{radio-misc-id}
Permissions:
"radio-profile" - Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
Roles:
"Operator",
```



```
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radio-profiles/miscellaneous/{radio-misc-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/neighborhood-analysis/{neigh-analysis-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radio-profiles/neighborhood-analysis/{neigh-analysis-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/radio-usage-opt/{radio-usage-opt-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
```



```
PUT /radio-profiles/radio-usage-opt/{radio-usage-opt-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/sensor-scan/{sensor-scan-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radio-profiles/sensor-scan/{sensor-scan-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/wmm-qos/{radio-qos-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radio-profiles/wmm-qos/{radio-qos-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
```



```
Roles:
"Operator",
"Administrator"
GET /ssids
Permissions:
"ssid" – Permission for full control of SSID
"ssid:r" - Permission to read SSID
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /ssids/{id}/:rename
Permissions:
"ssid" – Permission for full control of SSID
Roles:
"Operator",
"Administrator"
POST /ssids/{id}/cwp/:attach
Permissions:
"ssid" – Permission for full control of SSID
Roles:
"Operator",
"Administrator"
POST /ssids/{id}/cwp/:disable
Permissions:
"ssid" - Permission for full control of SSID
Roles:
"Operator",
"Administrator"
POST /ssids/{id}/cwp/:enable
Permissions:
"ssid" – Permission for full control of SSID
```



```
Roles:
"Operator",
"Administrator"
PUT /ssids/{id}/mode/dot1x
Permissions:
"ssid" – Permission for full control of SSID
Roles:
"Operator",
"Administrator"
PUT /ssids/{id}/mode/open
Permissions:
"ssid" – Permission for full control of SSID
Roles:
"Operator",
"Administrator"
PUT /ssids/{id}/mode/ppsk
Permissions:
"ssid" – Permission for full control of SSID
Roles:
"Operator",
"Administrator"
PUT /ssids/{id}/mode/psk
Permissions:
"ssid" – Permission for full control of SSID
Roles:
"Operator",
"Administrator"
PUT /ssids/{id}/mode/wep
Permissions:
"ssid" – Permission for full control of SSID
Roles:
"Operator",
```



"Administrator" PUT /ssids/{id}/psk/password Permissions: "ssid" - Permission for full control of SSID Roles: "Operator", "Administrator" POST /ssids/{id}/radius-server-group/:attach Attach radius server group to an SSID Permissions: "ssid" – Permission for full control of SSID Roles: "Operator", "Administrator" POST /ssids/{id}/user-profile/:attach Permissions: "ssid" – Permission for full control of SSID Roles: "Operator", "Administrator" GET /ssids/advanced-settings/{id} Permissions: "ssid" - Permission for full control of SSID "ssid:r" - Permission to read SSID Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" PUT /ssids/advanced-settings/{id} Permissions:

"ssid" – Permission for full control of SSID



```
Roles:
"Operator",
"Administrator"
GET /user-profiles
Permissions:
"user-profile" – Permission for full control of user profile
"user-profile:r" – Permission to read user profile
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /user-profiles
Permissions:
"user-profile" – Permission for full control of user profile
Roles:
"Operator",
"Administrator"
GET /user-profiles/{id}
Permissions:
"user-profile" – Permission for full control of user profile
"user-profile:r" – Permission to read user profile
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /user-profiles/{id}
Permissions:
"user-profile" – Permission for full control of user profile
Roles:
"Operator",
```



"Administrator"

DELETE /user-profiles/{id}

Permissions:

"user-profile" – Permission for full control of user profile

Roles:

"Operator",

"Administrator"

Configuration - Network

No default permissions for this category

GET /tunnel-concentrators

Permissions: NOT SET!

Roles:

NOT SET!

POST /tunnel-concentrators

Permissions: NOT SET!

Roles:

NOT SET!

GET /tunnel-concentrators/{id}

Permissions: NOT SET!

Roles:

NOT SET!

PUT /tunnel-concentrators/{id}

Permissions: NOT SET!

Roles:

NOT SET!



DELETE /tunnel-concentrators/{id}

Permissions: NOT SET!

Roles:

NOT SET!

Configuration - Authentication

No default permissions for this category

```
GET /ad-servers
Permissions:
"ad-server" – Permission for full control of AD server
"ad-server:r" – Permission to read AD server
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
GET /cwps
Permissions:
"cwp" – Permission for full control of captive web portals
"cwp:r" – Permission to read captive web portals
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
GET /Idap-servers
Permissions:
"ldap-server" – Permission for full control of LDAP server
"Idap-server:r" – Permission to read LDAP server
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
```



```
POST /Idap-servers
Permissions:
"Idap-server" - Permission for full control of LDAP server
Roles:
"Operator",
"Administrator"
GET /ldap-servers/{id}
Permissions:
"ldap-server" – Permission for full control of LDAP server
"Idap-server:r" – Permission to read LDAP server
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
PUT /ldap-servers/{id}
Permissions:
"Idap-server" - Permission for full control of LDAP server
Roles:
"Operator",
"Administrator"
DELETE /Idap-servers/{id}
Permissions:
"Idap-server" – Permission for full control of LDAP server
Roles:
"Operator",
"Administrator"
GET /radius-client-objects
Permissions:
"radius-client-object" - Permission for full control of RADIUS client object
"radius-client-object:r" - Permission to read RADIUS client object
Roles:
"Operator",
```



```
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /radius-client-objects
Permissions:
"radius-client-object" – Permission for full control of RADIUS client object
Roles:
"Operator",
"Administrator"
GET /radius-client-objects/{id}
Permissions:
"radius-client-object" – Permission for full control of RADIUS client object
"radius-client-object:r" - Permission to read RADIUS client object
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radius-client-objects/{id}
Permissions:
"radius-client-object" – Permission for full control of RADIUS client object
Roles:
"Operator",
"Administrator"
DELETE /radius-client-objects/{id}
Permissions:
"radius-client-object" – Permission for full control of RADIUS client object
Roles:
"Operator",
"Administrator"
GET /radius-proxies
Permissions:
```



```
"radius-proxy" – Permission for full control of RADIUS proxy
"radius-proxy:r" – Permission to read RADIUS proxy
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
POST /radius-proxies
Permissions:
"radius-proxy" – Permission for full control of RADIUS proxy
"Operator",
"Administrator"
GET /radius-proxies/{id}
Permissions:
"radius-proxy" – Permission for full control of RADIUS proxy
"radius-proxy:r" – Permission to read RADIUS proxy
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
PUT /radius-proxies/{id}
Permissions:
"radius-proxy" – Permission for full control of RADIUS proxy
Roles:
"Operator",
"Administrator"
DELETE /radius-proxies/{id}
Permissions:
"radius-proxy" – Permission for full control of RADIUS proxy
Roles:
"Operator",
"Administrator"
```



GET /radius-proxies/devices Permissions: "radius-proxy" – Permission for full control of RADIUS proxy "radius-proxy:r" – Permission to read RADIUS proxy Roles: "Operator", "Administrator", "Monitor", "Observer" GET /radius-servers/external Permissions: "radius-server" – Permission for full control of RADIUS server "radius-server:r" - Permission to read RADIUS server Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" POST /radius-servers/external Permissions: "radius-server" – Permission for full control of RADIUS server Roles: "Operator", "Administrator" GET /radius-servers/external/{id} Permissions: "radius-server" – Permission for full control of RADIUS server "radius-server:r" - Permission to read RADIUS server Roles: "Operator", "Administrator", "Monitor", "Installer",

"Observer"



PUT /radius-servers/external/{id} Permissions: "radius-server" – Permission for full control of RADIUS server Roles: "Operator", "Administrator" DELETE /radius-servers/external/{id} Permissions: "radius-server" – Permission for full control of RADIUS server Roles: "Operator", "Administrator" **GET /radius-servers/internal** Permissions: "radius-server" – Permission for full control of RADIUS server "radius-server:r" – Permission to read RADIUS server Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" POST /radius-servers/internal Permissions: "radius-server" – Permission for full control of RADIUS server Roles: "Operator", "Administrator" DELETE /radius-servers/internal Permissions: "radius-server" – Permission for full control of RADIUS server Roles: "Operator", "Administrator"



```
GET /radius-servers/internal/{id}
Permissions:
"radius-server" – Permission for full control of RADIUS server
"radius-server:r" - Permission to read RADIUS server
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radius-servers/internal/{id}
Permissions:
"radius-server" – Permission for full control of RADIUS server
Roles:
"Operator",
"Administrator"
DELETE /radius-servers/internal/{id}
Permissions:
"radius-server" – Permission for full control of RADIUS server
Roles:
"Operator",
"Administrator"
GET /radius-servers/internal/devices
Permissions:
"radius-server" – Permission for full control of RADIUS server
"radius-server:r" - Permission to read RADIUS server
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
```



Configuration - Certificate

Permissions:

"certificate" – Permission for all API calls in the Configuration - Certificate Section

"certificate:r" – Permission for all GET API calls in the Configuration – Certificate Section

GET /certificates

Permissions:

No Specific permission - included with "certificate" and "certificate:r"

Roles:

"Operator",

"Administrator",

"Monitor",

"Installer",

"Observer"

Copilot – Connectivity Experience

No default permissions for this category

GET /copilot/connectivity/client-type

Permissions:

NOT SET!

Roles:

NOT SET!

GET /copilot/connectivity/locations

Permissions:

NOT SET!

Roles:

NOT SET!

GET /copilot/connectivity/wired/events

Permissions:

"copilot-connectivity-wired:r" – Permission to read copilot wired connectivity

Roles:

"Operator",

"Monitor",

"Administrator",



```
"Observer",
"Guest Management"
GET /copilot/connectivity/wired/experience
Permissions:
"copilot-connectivity-wired:r" – Permission to read copilot wired connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wired/hardware
Permissions:
"copilot-connectivity-wired:r" – Permission to read copilot wired connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wired/locations/hardware
Permissions:
"copilot-connectivity-wired:r" – Permission to read copilot wired connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wired/quality-index
Permissions:
"copilot-connectivity-wired:r" – Permission to read copilot wired connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
```



```
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/apps
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/events
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/experience
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/locations/events
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
```



```
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/locations/performance
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/locations/quality-index
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/locations/time-to-connect
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/performance
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
```



```
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/quality-index
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/time-to-connect
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/views
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
```

Copilot – Anomalies

Permissions:

"copilot-anomalies:r" – Permission for all GET API calls in the Copilot Anomalies Section



```
GET /copilot/anomalies/adverse-traffic/device-stats
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET / copilot/anomalies/adverse-traffic/packet-counts
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/anomalies-by-category
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/device-by-location
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
```



GET /copilot/anomalies/device-with-locations Permissions: No Specific permission - included with "copilot-anomalies:r" Roles: "Operator", "Monitor", "Administrator", "Observer", "Guest Management" PUT /copilot/anomalies/devices/feedback Permissions: NOT SET! Roles: NOT SET! PUT /copilot/anomalies/devices/update-action Permissions: NOT SET! Roles: NOT SET! GET /copilot/anomalies/dfs-recurrence/channel-stats Permissions: No Specific permission - included with "copilot-anomalies:r" Roles: "Operator", "Monitor", "Administrator", "Observer", "Guest Management" GET /copilot/anomalies/dfs-recurrence/count-stats Permissions: No Specific permission - included with "copilot-anomalies:r" Roles: "Operator",



```
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/locations
Permissions:
"copilot-anomalies:r" – Permission to read copilot anomalies
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/poeflapping/stats
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/notifications
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/port-efficiency/speed-duplex-stats
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
```



```
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/port-efficiency/stats
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/wifi-capacity/client-list
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/wifi-capacity/stats
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/report
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
```



```
"Monitor",
"Administrator",
"Observer",
"Guest Management"
PUT /copilot/anomalies/update-action
Permissions:
NOT SET!
Roles:
NOT SET!
PUT / copilot/anomalies/update-device-action
Permissions:
NOT SET!
Roles:
NOT SET!
GET /copilot/anomalies/wifi-efficiency/client-list
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/wifi-efficiency/stats
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/assurance-scans/overview
```

Permissions:



"copilot-assurance-scans:r" – Permission to read access to Copilot Assurance scan

```
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
Packet Capture
Permissions:
"packet-capture" – Permission for all API calls in the Packet Capture Section
"packet-capture:r" – Permission for all GET API calls in the Packet Capture Section
GET /packetcaptures
Permissions:
No Specific permission - included with "packet-capture" and "packet-capture:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer"
"Observer"
POST /packetcaptures
Permissions:
No Specific permission - included with "packet-capture"
Roles:
"Operator",
"Help Desk",
"Administrator"
GET /packetcaptures/{id}
Permissions:
No Specific permission - included with "packet-capture" and "packet-capture:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
```



```
"Monitor",
"Installer"
"Observer"
Delete /packetcaptures/{id}
Permissions:
No Specific permission - included with "packet-capture"
"Operator",
"Help Desk",
"Administrator"
POST /packetcaptures/{id}/:stop
Permissions:
No Specific permission - included with "packet-capture"
Roles:
"Operator",
"Help Desk",
"Administrator"
POST /packetcaptures/{id}/:upload
Permissions:
No Specific permission - included with "packet-capture"
Roles:
"Operator",
"Help Desk",
"Administrator"
GET /packetcaptures/files
Permissions:
No Specific permission - included with "packet-capture" and "packet-capture:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer"
"Observer"
```



Essentials - ExtremeLocation

No default permissions for this category

GET /essentials/eloc/clients/{client-mac}/last-known-location Permissions:
NOT SET!

Roles: NOT SET!

Misc - Metadata - Country

Permissions:

"country" – Permission for all API calls in the Metadata-Country Section
"country:r" – Permission for all GET API calls in the Metadata-Country Section

GET /countries

Permissions:

No Specific permission - included with "country" and "country:r"

Roles:

```
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer"
"Observer"
```

GET /countries/{id}/:validate

Permissions:

No Specific permission - included with "country" and "country:r"

Roles:

```
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer"
"Observer"
```

License

Permissions:



```
"licenses" – Permission for all API calls in the License Section
"licenses:r" – Permission for all GET API calls in the License Section
GET /licenses
Permissions:
No Specific permission - included with "licenses" and "licenses:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer"
"Observer"
POST /license/:syncronize
Permissions:
NOT SET!
Roles:
NOT SET!
GET /licenses/{licenseType}
Permissions:
No Specific permission - included with "licenses" and "licenses:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer"
"Observer"
GET /licenses/application-filter
Permissions:
No Specific permission - included with "licenses" and "licenses:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer"
```



"Observer"

Roles:

```
GET /licenses/extreme-portal-link-param
Permissions:
No Specific permission - included with "licenses" and "licenses:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer"
"Observer"
POST /licenses/extreme-portal/:unlink
Permissions:
No Specific permission - included with "licenses"
Roles:
"Operator",
"Administrator"
POST /licenses/legacy-license
Permissions:
No Specific permission - included with "licenses"
Roles:
"Operator",
"Administrator"
DELETE /licenses/legacy-license/{id}
Permissions:
No Specific permission - included with "licenses"
Roles:
"Operator",
"Administrator"
GET /licenses/nac-entitlement-allocation
Permissions:
No Specific permission - included with "licenses" and "licenses:r"
```



```
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer"
"Observer"
PUT /licenses/nac-entitlement-allocation
Permissions:
No Specific permission - included with "licenses"
Roles:
"Operator",
"Administrator"
GET /licenses/summary
Permissions:
No Specific permission - included with "licenses" and "licenses:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer"
"Observer"
GET /licenses/viq-cuid-info
Permissions:
No Specific permission - included with "licenses" and "licenses:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer"
"Observer"
```



APPENDIX - A

API call list based on Roles

Administrator

All available API calls

Operator

All available API calls except for the following:

POST /users

DELETE /users/{id}

PATCH /users/{id}

POST /users/external

DELETE /users/external/{id}

PATCH /users/external/{id}

Monitor

POST /logout

POST /auth/apitoken

GET /auth/apitoken/info

GET /auth/permissions

POST /auth/permissions/:check

GET /operations/{operationId}

POST /account/:switch

GET /account/external

GET /account/home

GET /account/viq

GET /account/viq/default-device-password

GET /users

GET /users/{id}

GET /users/external

GET /users/external/{id}

GET /users/me

GET /hiq/context

GET /hiq/context/creating

GET /hiq/context/reading

GET /hiq/organizations

GET /hiq/status

GET /locations/building

GET /locations/building/{id}

GET /locations/floor

GET /locations/floor/{id}



- GET /locations/site
- GET /locations/site/{id}
- GET /locations/tree
- GET /locations/tree/devices
- GET /locations/tree/maps
- GET /devices
- GET /devices/{id}
- GET /devices/{id}/alarms
- GET /devices/{id}/config/vlan-attributes
- GET /devices/{id}/config/vlan-ipv4-intf
- GET /devices/{id}/config/vlan-ipv4-static
- GET /devices/{id}/ftm-settings
- GET /devices/{id}/gallery-image
- GET /devices/{id}/history/cpu-mem
- GET /devices/{id}/ibeacon
- GET /devices/{id}/installation-report
- GET /devices/{id}/interfaces/wifi
- GET /devices/{id}/location
- GET /devices/{id}/monitor/ipv4-routing
- GET /devices/{id}/monitor/ipv4-routing-timeline
- GET /devices/{id}/monitor/vlan-attr
- GET /devices/{id}/monitor/vlan-ipv4-intf
- GET /devices/{id}/network-policy
- GET /devices/{id}/ssid/status
- GET /devices/digital-twin
- GET /devices/network-policy/{policyId}
- GET /devices/radio-information
- GET /devices/stats
- GET /network-policies
- GET /network-policies/{id}
- GET /network-policies/{id}/ssids
- GET /clients/{id}
- GET /clients/active
- GET /clients/active/count
- GET /clients/byMac/{clientMac}
- GET /clients/summary
- GET /clients/usage
- GET /applications
- GET /applications/{id}/clients/top{n}
- GET /applications/top{n}
- GET /alert-policies
- GET /alert-policies/{id}
- GET /alert-policies/{policyId}/rules/{ruleId}
- GET /alert-policies/available-sites



- GET /alert-subscriptions/emails
- GET /alert-subscriptions/emails/{id}
- GET /alert-subscriptions/webhooks
- GET /alert-subscriptions/webhooks/{id}
- GET /alerts
- GET /alerts/count-by-{group}
- GET /alerts/reports/{id}
- GET /logs/accounting
- GET /logs/audit
- GET /logs/audit/reports/{id}
- GET /logs/auth
- GET /logs/credential
- GET /logs/email
- GET /logs/sms
- GET /subscriptions/webhook
- GET /deployments/overview
- GET /deployments/status
- GET /vlan-profiles
- GET /vlan-profiles/{id}
- GET /email-templates
- GET /endusers
- GET /pcgs/key-based
- GET /pcgs/key-based/network-policy-{policyId}/port-assignments
- GET /pcgs/key-based/network-policy-{policyId}/users
- GET /sms-templates
- GET /usergroups
- GET /ccgs
- GET /ccgs/{id}
- GET /classification-rules
- GET /classification-rules/{id}
- GET /iot-profiles
- GET /iot-profiles/{id}
- GET /13-address-profiles
- GET /radio-profiles
- GET /radio-profiles/{id}
- GET /radio-profiles/channel-selection/{id}
- GET /radio-profiles/mac-ouis
- GET /radio-profiles/mac-ouis/{id}
- GET /radio-profiles/miscellaneous/{id}
- GET /radio-profiles/neighborhood-analysis/{id}
- GET /radio-profiles/radio-usage-opt/{id}
- GET /radio-profiles/sensor-scan/{id}
- GET /radio-profiles/wmm-qos/{id}
- **GET** /ssids



- GET /ssids/advanced-settings/{id}
- GET /user-profiles
- GET /user-profiles/{id}
- GET /ad-servers
- GET /cwps
- GET /ldap-servers
- GET /ldap-servers/{id}
- GET /radius-client-objects
- GET /radius-client-objects/{id}
- GET /radius-proxies
- GET /radius-proxies/{id}
- GET /radius-proxies/devices
- GET /radius-servers/external
- GET /radius-servers/external/{id}
- GET /radius-servers/internal
- GET /radius-servers/internal/{id}
- GET /radius-servers/internal/devices
- GET /certificates
- GET /copilot/connectivity/wired/events
- GET /copilot/connectivity/wired/experience
- GET /copilot/connectivity/wired/hardware
- GET /copilot/connectivity/wired/locations/hardware
- GET /copilot/connectivity/wired/quality-index
- GET /copilot/connectivity/wireless/apps
- GET /copilot/connectivity/wireless/events
- GET /copilot/connectivity/wireless/experience
- GET /copilot/connectivity/wireless/locations/events
- GET /copilot/connectivity/wireless/locations/performance
- GET /copilot/connectivity/wireless/locations/quality-index
- GET /copilot/connectivity/wireless/locations/time-to-connect
- GET /copilot/connectivity/wireless/performance
- GET /copilot/connectivity/wireless/quality-index
- GET /copilot/connectivity/wireless/time-to-connect
- GET /copilot/connectivity/wireless/views
- GET /copilot/anomalies/adverse-traffic/device-stats
- GET /copilot/anomalies/adverse-traffic/packet-counts
- GET /copilot/anomalies/anomalies-by-category
- GET /copilot/anomalies/devices-by-location
- GET /copilot/anomalies/devices-with-locations
- GET /copilot/anomalies/dfs-recurrence/channel-stats
- GET /copilot/anomalies/dfs-recurrence/count-stats
- GET /copilot/anomalies/locations
- GET /copilot/anomalies/notifications
- GET /copilot/anomalies/poeflapping/stats



GET /copilot/anomalies/port-efficiency/speed-duplex-stats

GET /copilot/anomalies/port-efficiency/stats

GET /copilot/anomalies/report

GET /copilot/anomalies/wifi-capacity/client-list

GET /copilot/anomalies/wifi-capacity/stats

GET /copilot/anomalies/wifi-efficiency/client-list

GET /copilot/anomalies/wifi-efficiency/stats

GET /copilot/assurance-scans/overview

GET /packetcaptures

GET /packetcaptures/{id}

GET /packetcaptures/files

GET /countries

GET /countries/{countryCode}/:validate

GET /licenses

GET /licenses/{licenseType}

GET /licenses/application-filter

GET /licenses/extreme-portal-link-param

GET /licenses/nac-entitlement-allocation

GET /licenses/summary

GET /licenses/viq-cuid-info

Installer

POST /logout

POST /auth/apitoken

POST /auth/permissions/:check

GET /operations/{operationId}

POST /account/:switch

GET /account/external

GET /account/home

GET /account/viq

GET /account/viq/default-device-password

GET /users/me

GET /hiq/context

PUT /hiq/context

GET /hiq/context/creating

PUT /hiq/context/creating

GET /hiq/context/reading

PUT /hiq/context/reading

GET /hiq/organizations

GET /hiq/status

POST /locations

POST /locations/:init

PUT /locations/{id}

DELETE /locations/{id}



GET /locations/building

POST /locations/building

GET /locations/building/{id}

PUT /locations/building/{id}

DELETE /locations/building/{id}

GET /locations/floor

POST /locations/floor

GET /locations/floor/{id}

PUT /locations/floor/{id}

DELETE /locations/floor/{id}

POST /locations/floorplan

GET /locations/site

POST /locations/site

GET /locations/site/{id}

PUT /locations/site/{id}

DELETE /locations/site/{id}

GET /locations/tree

GET /locations/tree/devices

GET /locations/tree/maps

GET /devices

POST /devices/:advanced-onboard

POST /devices/:cli

POST /devices/:delete

POST /devices/:manage

POST /devices/:onboard

POST /devices/:reboot

POST /devices/:unmanage

GET /devices/{id}

DELETE /devices/{id}

POST /devices/{id}/:cli

POST /devices/{id}/:manage

POST /devices/{id}/:reboot

POST /devices/{id}/:reset

POST /devices/{id}/:unmanage

GET /devices/{id}/alarms

POST /devices/{id}/bounce-port

GET /devices/{id}/config/vlan-attributes

POST /devices/{id}/config/vlan-attributes

DELETE /devices/{id}/config/vlan-attributes

PATCH /devices/{id}/config/vlan-attributes/{vlanId}

GET /devices/{id}/config/vlan-ipv4-intf

POST /devices/{id}/config/vlan-ipv4-intf

DELETE /devices/{id}/config/vlan-ipv4-intf

PATCH /devices/{id}/config/vlan-ipv4-intf/{ipv4InterfaceId}



GET /devices/{id}/config/vlan-ipv4-static

POST /devices/{id}/config/vlan-ipv4-static

DELETE /devices/{id}/config/vlan-ipv4-static

PATCH /devices/{id}/config/vlan-ipv4-static/{ipv4StaticRouteId}

PUT /devices/{id}/description

GET /devices/{id}/ftm-settings

PUT /devices/{id}/ftm-settings

DELETE /devices/{id}/ftm-settings

GET /devices/{id}/gallery-image

GET /devices/{id}/history/cpu-mem

PUT /devices/{id}/hostname

GET /devices/{id}/ibeacon

GET /devices/{id}/installation-report

GET /devices/{id}/interfaces/wifi

GET /devices/{id}/location

PUT /devices/{id}/location

DELETE /devices/{id}/location

GET /devices/{id}/monitor/ipv4-routing

GET /devices/{id}/monitor/ipv4-routing-timeline

GET /devices/{id}/monitor/vlan-attr

GET /devices/{id}/monitor/vlan-ipv4-intf

GET /devices/{id}/network-policy

PUT /devices/{id}/network-policy

DELETE /devices/{id}/network-policy

POST /devices/{id}/ssid/:override

GET /devices/{id}/ssid/status

POST /devices/{id}/ssid/status/:change

POST /devices/{id}/thread/commissioner/:start

POST /devices/{id}/thread/commissioner/:stop

POST /devices/country-code/:assign

GET /devices/digital-twin

PUT /devices/ibeacon

POST /devices/location/:assign

POST /devices/location/:query

POST /devices/location/:revoke

POST /devices/network-policy/:assign

POST /devices/network-policy/:query

POST /devices/network-policy/:revoke

GET /devices/network-policy/{policyId}

POST /devices/os/:change

GET /devices/radio-information

PUT /devices/radius-proxy/:assign

DELETE /devices/radius-proxy/:revoke

GET /devices/stats



- GET /network-policies
- GET /network-policies/{id}
- GET /network-policies/{id}/ssids
- GET /clients/{id}
- GET /clients/active
- GET /clients/active/count
- GET /clients/byMac/{clientMac}
- GET /clients/summary
- GET /clients/usage
- GET /alert-policies
- GET /alert-policies/{id}
- GET /alert-policies/{policyId}/rules/{ruleId}
- GET /alert-policies/available-sites
- GET /alert-subscriptions/emails
- GET /alert-subscriptions/emails/{id}
- GET /alert-subscriptions/webhooks
- GET /alert-subscriptions/webhooks/{id}
- GET /alerts
- GET /alerts/count-by-{group}
- GET /alerts/reports/{id}
- GET /logs/accounting
- GET /logs/audit
- GET /logs/audit/reports/{id}
- GET /logs/auth
- GET /logs/credential
- GET /logs/email
- GET /logs/sms
- GET /deployments/overview
- GET /deployments/status
- GET /iot-profiles
- GET /iot-profiles/{id}
- GET /radio-profiles
- GET /radio-profiles/{id}
- GET /radio-profiles/channel-selection/{id}
- GET /radio-profiles/mac-ouis
- GET /radio-profiles/mac-ouis/{id}
- GET /radio-profiles/miscellaneous/{id}
- GET /radio-profiles/neighborhood-analysis/{id}
- GET /radio-profiles/radio-usage-opt/{id}
- GET /radio-profiles/sensor-scan/{id}
- GET /radio-profiles/wmm-qos/{id}
- GET /ssids
- GET /ssids/advanced-settings/{id}
- GET /user-profiles



GET /user-profiles/{id}

GET /radius-client-objects

GET /radius-client-objects/{id}

GET /radius-servers/external

GET /radius-servers/external/{id}

GET /radius-servers/internal

GET /radius-servers/internal/{id}

GET /radius-servers/internal/devices

GET /certificates

GET /packetcaptures

GET /packetcaptures/{id}

GET /packetcaptures/files

GET /countries

GET /countries/{countryCode}/:validate

GET /licenses

GET /licenses/{licenseType}

GET /licenses/application-filter

GET /licenses/extreme-portal-link-param

GET /licenses/nac-entitlement-allocation

GET /licenses/summary

GET /licenses/viq-cuid-info

Observer

POST /logout

GET /auth/apitoken/info

GET /auth/permissions

POST /auth/permissions/:check

GET /operations/{operationId}

POST /account/:switch

GET /account/external

GET /account/home

GET /account/viq

GET /account/viq/default-device-password

GET /users/me

GET /hiq/context

GET /hiq/context/creating

GET /hiq/context/reading

GET /hiq/organizations

GET /hiq/status

GET /locations/building

GET /locations/building/{id}

GET /locations/floor

GET /locations/floor/{id}

GET /locations/site



- GET /locations/site/{id}
- GET /locations/tree
- GET /locations/tree/devices
- GET /locations/tree/maps
- GET /devices
- GET /devices/{id}
- GET /devices/{id}/alarms
- GET /devices/{id}/config/vlan-attributes
- GET /devices/{id}/config/vlan-ipv4-intf
- GET /devices/{id}/config/vlan-ipv4-static
- GET /devices/{id}/ftm-settings
- GET /devices/{id}/gallery-image
- GET /devices/{id}/history/cpu-mem
- GET /devices/{id}/ibeacon
- GET /devices/{id}/installation-report
- GET /devices/{id}/interfaces/wifi
- GET /devices/{id}/location
- GET /devices/{id}/monitor/ipv4-routing
- GET /devices/{id}/monitor/ipv4-routing-timeline
- GET /devices/{id}/monitor/vlan-attr
- GET /devices/{id}/monitor/vlan-ipv4-intf
- GET /devices/{id}/network-policy
- GET /devices/{id}/ssid/status
- GET /devices/digital-twin
- GET /devices/network-policy/{policyId}
- GET /devices/radio-information
- GET /devices/stats
- GET /network-policies
- GET /network-policies/{id}
- GET /network-policies/{id}/ssids
- GET /clients/{id}
- GET /clients/active
- GET /clients/active/count
- GET /clients/byMac/{clientMac}
- GET /clients/summary
- GET /clients/usage
- GET /applications
- GET /applications/{id}/clients/top{n}
- GET /applications/top{n}
- GET /alert-policies
- GET /alert-policies/{id}
- GET /alert-policies/{policyId}/rules/{ruleId}
- GET /alert-policies/available-sites
- GET /alert-subscriptions/emails



- GET /alert-subscriptions/emails/{id}
- GET /alert-subscriptions/webhooks
- GET /alert-subscriptions/webhooks/{id}
- GET /alerts
- GET /alerts/count-by-{group}
- GET /alerts/reports/{id}
- GET /logs/accounting
- GET /logs/audit
- GET /logs/audit/reports/{id}
- GET /logs/auth
- GET /logs/credential
- GET /logs/email
- GET /logs/sms
- GET /subscriptions/webhook
- GET /deployments/overview
- GET /deployments/status
- GET /vlan-profiles
- GET /vlan-profiles/{id}
- GET /email-templates
- GET /endusers
- GET /pcgs/key-based
- GET /pcgs/key-based/network-policy-{policyId}/port-assignments
- GET /pcgs/key-based/network-policy-{policyId}/users
- GET /sms-templates
- GET /usergroups
- GET /ccgs
- GET /ccgs/{id}
- GET /classification-rules
- GET /classification-rules/{id}
- GET /iot-profiles
- GET /iot-profiles/{id}
- GET /13-address-profiles
- GET /radio-profiles
- GET /radio-profiles/{id}
- GET /radio-profiles/channel-selection/{id}
- GET /radio-profiles/mac-ouis
- GET /radio-profiles/mac-ouis/{id}
- GET /radio-profiles/miscellaneous/{id}
- GET /radio-profiles/neighborhood-analysis/{id}
- GET /radio-profiles/radio-usage-opt/{id}
- GET /radio-profiles/sensor-scan/{id}
- GET /radio-profiles/wmm-qos/{id}
- GET /ssids
- GET /ssids/advanced-settings/{id}



- GET /user-profiles
- GET /user-profiles/{id}
- GET /ad-servers
- GET /cwps
- GET /ldap-servers
- GET /ldap-servers/{id}
- GET /radius-client-objects
- GET /radius-client-objects/{id}
- GET /radius-proxies
- GET /radius-proxies/{id}
- GET /radius-proxies/devices
- GET /radius-servers/external
- GET /radius-servers/external/{id}
- GET /radius-servers/internal
- GET /radius-servers/internal/{id}
- GET /radius-servers/internal/devices
- GET /certificates
- GET /copilot/connectivity/wired/events
- GET /copilot/connectivity/wired/experience
- GET /copilot/connectivity/wired/hardware
- GET /copilot/connectivity/wired/locations/hardware
- GET /copilot/connectivity/wired/quality-index
- GET /copilot/connectivity/wireless/apps
- GET /copilot/connectivity/wireless/events
- GET /copilot/connectivity/wireless/experience
- GET /copilot/connectivity/wireless/locations/events
- GET /copilot/connectivity/wireless/locations/performance
- GET /copilot/connectivity/wireless/locations/quality-index
- GET /copilot/connectivity/wireless/locations/time-to-connect
- GET /copilot/connectivity/wireless/performance
- GET /copilot/connectivity/wireless/quality-index
- GET /copilot/connectivity/wireless/time-to-connect
- GET /copilot/connectivity/wireless/views
- GET /copilot/anomalies/adverse-traffic/device-stats
- GET /copilot/anomalies/adverse-traffic/packet-counts
- GET /copilot/anomalies/anomalies-by-category
- GET /copilot/anomalies/devices-by-location
- GET /copilot/anomalies/devices-with-locations
- GET /copilot/anomalies/dfs-recurrence/channel-stats
- GET /copilot/anomalies/dfs-recurrence/count-stats
- GET /copilot/anomalies/locations
- GET /copilot/anomalies/notifications
- GET /copilot/anomalies/poeflapping/stats
- GET /copilot/anomalies/port-efficiency/speed-duplex-stats



- GET /copilot/anomalies/port-efficiency/stats
- GET /copilot/anomalies/report
- GET /copilot/anomalies/wifi-capacity/client-list
- GET /copilot/anomalies/wifi-capacity/stats
- GET /copilot/anomalies/wifi-efficiency/client-list
- GET /copilot/anomalies/wifi-efficiency/stats
- GET /copilot/assurance-scans/overview
- GET /packetcaptures
- GET /packetcaptures/{id}
- GET /packetcaptures/files
- GET /countries
- GET /countries/{countryCode}/:validate
- GET /licenses
- GET /licenses/{licenseType}
- GET /licenses/application-filter
- GET /licenses/extreme-portal-link-param
- GET /licenses/nac-entitlement-allocation
- GET /licenses/summary
- GET /licenses/viq-cuid-info

Help Desk

- POST /logout
- POST /auth/permissions/:check
- GET /operations/{operationId}
- POST /account/:switch
- GET /account/external
- GET /account/home
- GET /account/viq
- GET /account/viq/default-device-password
- GET /users/me
- GET /hiq/context
- GET /hiq/context/creating
- GET /hiq/context/reading
- GET /hiq/organizations
- GET /hiq/status
- GET /locations/building
- GET /locations/building/{id}
- GET /locations/floor
- GET /locations/floor/{id}
- GET /locations/site
- GET /locations/site/{id}
- GET /locations/tree
- GET /locations/tree/devices
- GET /locations/tree/maps



GET /clients/{id}

GET /clients/active

GET /clients/active/count

GET /clients/byMac/{clientMac}

GET /clients/summary

GET /clients/usage

GET /alerts

GET /alerts/count-by-{group}

GET /alerts/reports/{id}

GET /deployments/overview

GET /deployments/status

GET /endusers

GET /packetcaptures

POST /packetcaptures

GET /packetcaptures/{id}

DELETE /packetcaptures/{id}

POST /packetcaptures/{id}/:stop

POST /packetcaptures/{id}/:upload

GET /packetcaptures/files

GET /countries

GET /countries/{countryCode}/:validate

GET /licenses

GET /licenses/{licenseType}

GET /licenses/application-filter

GET /licenses/extreme-portal-link-param

GET /licenses/nac-entitlement-allocation

GET /licenses/summary

GET /licenses/viq-cuid-info

Application Operator

GET /logs/accounting

GET /logs/audit

GET /logs/audit/reports/{id}

GET /logs/auth

GET /logs/credential

GET /logs/email

GET /logs/sms

Guest Management

POST /logout

POST /auth/permissions/:check

GET /operations/{operationId}

POST /account/:switch



- GET /account/external
- GET /account/home
- GET /account/viq
- GET /account/viq/default-device-password
- GET /deployments/overview
- GET /deployments/status
- GET /endusers
- GET /usergroups
- GET /copilot/connectivity/wired/events
- GET /copilot/connectivity/wired/experience
- GET /copilot/connectivity/wired/hardware
- GET /copilot/connectivity/wired/locations/hardware
- GET /copilot/connectivity/wired/quality-index
- GET /copilot/connectivity/wireless/apps
- GET /copilot/connectivity/wireless/events
- GET /copilot/connectivity/wireless/experience
- GET /copilot/connectivity/wireless/locations/events
- GET /copilot/connectivity/wireless/locations/performance
- GET /copilot/connectivity/wireless/locations/quality-index
- GET /copilot/connectivity/wireless/locations/time-to-connect
- GET /copilot/connectivity/wireless/performance
- GET /copilot/connectivity/wireless/quality-index
- GET /copilot/connectivity/wireless/time-to-connect
- GET /copilot/connectivity/wireless/views
- GET /copilot/anomalies/adverse-traffic/device-stats
- GET /copilot/anomalies/adverse-traffic/packet-counts
- GET /copilot/anomalies/anomalies-by-category
- GET /copilot/anomalies/devices-by-location
- GET /copilot/anomalies/devices-with-locations
- GET /copilot/anomalies/dfs-recurrence/channel-stats
- GET /copilot/anomalies/dfs-recurrence/count-stats
- GET /copilot/anomalies/locations
- GET /copilot/anomalies/notifications
- GET /copilot/anomalies/poeflapping/stats
- GET /copilot/anomalies/port-efficiency/speed-duplex-stats
- GET /copilot/anomalies/port-efficiency/stats
- GET /copilot/anomalies/report
- GET /copilot/anomalies/wifi-capacity/client-list
- GET /copilot/anomalies/wifi-capacity/stats
- GET /copilot/anomalies/wifi-efficiency/client-list
- GET /copilot/anomalies/wifi-efficiency/stats
- GET /copilot/assurance-scans/overview



APPENDIX - B

API call list based on Permission

logout

POST /logout

auth

POST /auth/permissions/:check POST /auth/apitoken POST /auth/apitoken/:validate GET /auth/permissions GET /auth/apitoken/info

auth:r

GET /auth/permissions GET /auth/apitoken/info

token:new

POST /auth/apitoken

perm:check

POST /auth/permissions/:check

Iro

POST /operations/{operationId}/:cancel GET /operations/{operationId}
DELETE /operations/{operationId}

lro:r

GET /operations/{operationId}



account

GET /account/viq/default-device-password PUT /account/viq/default-device-password POST /account/viq/:backup POST /account/:switch GET /account/viq GET /account/home GET /account/external

account:switch

POST /account/:switch

account:r

GET /account/viq/default-device-password GET /account/viq GET /account/home GET /account/external

viq:backup

POST /account/viq/:backup

user

GET /users
POST /users
GET /users/external
POST /users/external
GET /users/{id}
DELETE /users/{id}
PATCH /users/{id}
GET /users/external/{id}
DELETE /users/external/{id}
DELETE /users/external/{id}
PATCH /users/external/{id}
GET /users/external/{id}
GET /users/me

user-me:r

GET /users/me



user:r

GET /users

GET /users/external

GET /users/{id}

GET /users/external/{id}

GET /users/me

hiq

GET /hiq/context

PUT /hiq/context

GET /hiq/context/reading

PUT /hiq/context/reading

GET /hiq/context/creating

PUT /hiq/context/creating

GET /hiq/organizations

POST /hiq/organizations

POST /hiq/organizations/{id}/:rename

GET /hiq/status

DELETE /hiq/organizations/{id}

hig:r

GET /hiq/context

GET /hiq/context/reading

GET /hiq/context/creating

GET /hiq/organizations

GET /hiq/status

org

GET /hiq/organizations

POST /hiq/organizations

POST /hiq/organizations/{id}/:rename

DELETE /hiq/organizations/{id}

org:new

POST /hiq/organizations



org:del

DELETE /hiq/organizations/{id}

org:rename

POST /hiq/organizations/{id}/:rename

hiq.ctx

GET /hiq/context

PUT /hiq/context

GET /hiq/context/reading

PUT /hiq/context/reading

GET /hiq/context/creating

PUT /hiq/context/creating

hiq.ctx:r

GET /hiq/context

GET /hiq/context/reading

GET /hiq/context/creating

hiq.ctx:w

PUT /hiq/context

PUT /hiq/context/reading

PUT /hiq/context/creating

device

GET /devices/{id}/network-policy

PUT /devices/{id}/network-policy

DELETE /devices/{id}/network-policy

GET /devices/{id}/location

PUT /devices/{id}/location

DELETE /devices/{id}/location

PUT /devices/{id}/hostname

GET /devices/{id}/ftm-settings

PUT /devices/{id}/ftm-settings

DELETE /devices/{id}/ftm-settings

PUT /devices/{id}/description

PUT /devices/radius-proxy/:assign



PUT /devices/ibeacon

POST /devices/{id}/thread/commissioner/:stop

POST /devices/{id}/thread/commissioner/:start

POST /devices/{id}/ssid/status/:change

POST /devices/{id}/ssid/:override

GET /devices/{id}/config/vlan-ipv4-static

POST /devices/{id}/config/vlan-ipv4-static

DELETE /devices/{id}/config/vlan-ipv4-static

GET /devices/{id}/config/vlan-ipv4-intf

POST /devices/{id}/config/vlan-ipv4-intf

DELETE /devices/{id}/config/vlan-ipv4-intf

GET /devices/{id}/config/vlan-attributes

POST /devices/{id}/config/vlan-attributes

DELETE /devices/{id}/config/vlan-attributes

POST /devices/{id}/bounce-port

POST /devices/{id}/:unmanage

POST /devices/{id}/:reset

POST /devices/{id}/:reboot

POST /devices/{id}/:manage

POST /devices/{id}/:cli

POST /devices/os/:change

POST /devices/network-policy/:revoke

POST /devices/network-policy/:query

POST /devices/network-policy/:assign

POST /devices/location/:revoke

POST /devices/location/:query

POST /devices/location/:assign

POST /devices/country-code/:assign

POST /devices/:unmanage

POST /devices/:reboot

POST /devices/:onboard

POST /devices/:manage

POST /devices/:delete

POST /devices/:cli

POST /devices/:advanced-onboard

PATCH /devices/{id}/config/vlan-ipv4-static/{ipv4StaticRouteId}

PATCH /devices/{id}/config/vlan-ipv4-intf/{ipv4InterfaceId}

PATCH /devices/{id}/config/vlan-attributes/{vlanId}

GET /devices

GET /devices/{id}

DELETE /devices/{id}

GET /devices/{id}/ssid/status

GET /devices/{id}/monitor/vlan-ipv4-intf

GET /devices/{id}/monitor/vlan-attr



GET /devices/{id}/monitor/ipv4-routing

GET /devices/{id}/monitor/ipv4-routing-timeline

GET /devices/{id}/interfaces/wifi

GET /devices/{id}/installation-report

GET /devices/{id}/ibeacon

GET /devices/{id}/history/cpu-mem

GET /devices/{id}/gallery-image

GET /devices/{id}/alarms

GET /devices/stats

GET /devices/radio-information

GET /devices/network-policy/{policyId}

GET /devices/digital-twin

DELETE /devices/radius-proxy/:revoke

device:r

GET /devices/{id}/network-policy

GET /devices/{id}/location

GET /devices/{id}/ftm-settings

GET /devices/{id}/config/vlan-ipv4-static

GET /devices/{id}/config/vlan-ipv4-intf

GET /devices/{id}/config/vlan-attributes

GET /devices

GET /devices/{id}

GET /devices/{id}/ssid/status

GET /devices/{id}/monitor/vlan-ipv4-intf

GET /devices/{id}/monitor/vlan-attr

GET /devices/{id}/monitor/ipv4-routing

GET /devices/{id}/monitor/ipv4-routing-timeline

GET /devices/{id}/interfaces/wifi

GET /devices/{id}/installation-report

GET /devices/{id}/ibeacon

GET /devices/{id}/history/cpu-mem

GET /devices/{id}/gallery-image

GET /devices/{id}/alarms

GET /devices/stats

GET /devices/radio-information

GET /devices/network-policy/{policyId}

GET /devices/digital-twin

device:list

GET /devices



device:view

GET /devices/{id}
GET /devices/stats
GET /devices/radio-information
GET /devices/digital-twin

device:new

POST /devices/:onboard

device:del

POST /devices/:delete

device:cli

POST /devices/:cli

device:deploy

Permission not used

device:manage

POST /devices/:manage

device:unmanage

POST /devices/:unmanage

device:reboot

POST /devices/:reboot

device:reset

POST /devices/{id}/:reset



device:thread-commissioner

POST /devices/{id}/thread/commissioner/:stop POST /devices/{id}/thread/commissioner/:start

client

PUT /clients/alias

GET /clients/{id}

GET /clients/usage

GET /clients/summary

GET /clients/byMac/{clientMac}

DELETE /clients/byMac/{clientMac}

GET /clients/active

GET /clients/active/count

client:r

GET /clients/{id}

GET /clients/usage

GET /clients/summary

GET /clients/byMac/{clientMac}

GET /clients/active

GET /clients/active/count

locations

PUT /locations/{id}

DELETE /locations/{id}

GET /locations/site/{id}

PUT /locations/site/{id}

DELETE /locations/site/{id}

GET /locations/floor/{id}

PUT /locations/floor/{id}

DELETE /locations/floor/{id}

GET /locations/building/{id}

PUT /locations/building/{id}

DELETE /locations/building/{id}

POST /locations

GET /locations/site

POST /locations/site

GET /locations/floor



POST /locations/floor

POST /locations/floorplan

GET /locations/building

POST /locations/building

POST /locations/:init

GET /locations/tree

GET /locations/tree/maps

GET /locations/tree/devices

locations:r

GET /locations/site/{id}

GET /locations/floor/{id}

GET /locations/building/{id}

GET /locations/site

GET /locations/floor

GET /locations/building

GET /locations/tree

GET /locations/tree/maps

GET /locations/tree/devices

network-policy

GET /network-policies/{id}

PUT /network-policies/{id}

DELETE /network-policies/{id}

GET /network-policies

POST /network-policies

POST /network-policies/{id}/ssids/:remove

POST /network-policies/{id}/ssids/:add

GET /network-policies/{id}/ssids

policy:ssid

POST /network-policies/{id}/ssids/:remove

POST /network-policies/{id}/ssids/:add

network-policy:r

GET /network-policies/{id}

GET /network-policies

GET /network-policies/{id}/ssids



ssid

PUT /ssids/{id}/psk/password PUT /ssids/{id}/mode/wep PUT /ssids/{id}/mode/psk PUT /ssids/{id}/mode/ppsk PUT /ssids/{id}/mode/open PUT /ssids/{id}/mode/dot1x GET /ssids/advanced-settings/{id} PUT /ssids/advanced-settings/{id} POST /ssids/{id}/user-profile/:attach POST /ssids/{id}/radius-server-group/:attach POST /ssids/{id}/cwp/:enable POST /ssids/{id}/cwp/:disable POST /ssids/{id}/cwp/:attach POST /ssids/{id}/:rename **GET** /ssids ssid:r

GET /ssids/advanced-settings/{id}
GET /ssids

pcg:key

PUT /pcgs/key-based/network-policy-{policyId}/users
POST /pcgs/key-based/network-policy-{policyId}/users
DELETE /pcgs/key-based/network-policy-{policyId}/users
GET /pcgs/key-based
POST /pcgs/key-based
GET /pcgs/key-based/network-policy-{policyId}/port-assignments
POST /pcgs/key-based/network-policy-{policyId}/port-assignments
POST /pcgs/key-based/network-policy-{policyId}/keys/:generate
POST /pcgs/key-based/network-policy-{policyId}/keys/:email
POST /pcgs/key-based/network-policy-{policyId}/:onboard
DELETE /pcgs/key-based/network-policy-{policyId}

GET /pcgs/key-based/network-policy-{policyId}/users

pcg:key:r

GET /pcgs/key-based/network-policy-{policyId}/users GET /pcgs/key-based GET /pcgs/key-based/network-policy-{policyId}/port-assignments



subscriptions-webhook

GET /subscriptions/webhook POST /subscriptions/webhook DELETE /subscriptions/webhook/{id}

subscriptions-webhook:r

GET /subscriptions/webhook

ccg

GET /ccgs/{id}
PUT /ccgs/{id}
DELETE /ccgs/{id}
GET /ccgs
POST /ccgs

ccg:r

GET /ccgs/{id} GET /ccgs

log

POST /logs/audit/reports

GET /logs/sms

GET /logs/email

GET /logs/credential

GET /logs/auth

GET /logs/audit

GET /logs/audit/reports/{id}

GET /logs/accounting

log:r

GET /logs/sms

GET /logs/email

GET /logs/credential

GET /logs/auth

GET /logs/audit

GET /logs/audit/reports/{id}



GET /logs/accounting cwp GET /cwps cwp:r GET /cwps sms-tmpl GET /sms-templates sms-tmpl:r GET /sms-templates class-rule GET /classification-rules/{id} PUT /classification-rules/{id} DELETE /classification-rules/{id} GET /classification-rules POST /classification-rules class-rule:r GET /classification-rules/{id} GET /classification-rules user-profile GET /user-profiles/{id} PUT /user-profiles/{id} DELETE /user-profiles/{id} GET /user-profiles POST /user-profiles user-profile:r GET /user-profiles/{id}



GET /user-profiles

radius-proxy

GET /radius-proxies/{id} PUT /radius-proxies/{id} DELETE /radius-proxies/{id} GET /radius-proxies POST /radius-proxies GET /radius-proxies/devices

radius-proxy:r

GET /radius-proxies/{id}
GET /radius-proxies
GET /radius-proxies/devices

radius-server

GET /radius-servers/internal/{id}
PUT /radius-servers/internal/{id}
DELETE /radius-servers/internal/{id}
GET /radius-servers/external/{id}
PUT /radius-servers/external/{id}
PUT /radius-servers/external/{id}
DELETE /radius-servers/external/{id}
GET /radius-servers/internal
POST /radius-servers/internal
DELETE /radius-servers/internal
GET /radius-servers/external
POST /radius-servers/external
GET /radius-servers/external

radius-server:r

GET /radius-servers/internal/{id} GET /radius-servers/external/{id} GET /radius-servers/internal GET /radius-servers/external GET /radius-servers/internal/devices

usergroup

PUT /usergroups/{id}



DELETE /usergroups/{id} GET /usergroups POST /usergroups

usergroup:r

GET /usergroups

deployment

POST /deployments GET /deployments/status GET /deployments/overview

deployment:r

GET /deployments/status GET /deployments/overview

ad-server

GET /ad-servers

ad-server:r

GET /ad-servers

alert

POST /alerts/reports
POST /alerts/:acknowledge
GET /alerts
GET /alerts/reports/{id}
GET /alerts/count-by-{group}

alert:r

GET /alerts
GET /alerts/reports/{id}
GET /alerts/count-by-{group}



alert-policies

GET /alert-policies/{policyId}/rules/{ruleId}

PUT /alert-policies/{policyId}/rules/{ruleId}

GET /alert-policies/{id}

PUT /alert-policies/{id}

DELETE /alert-policies/{id}

GET /alert-policies

POST /alert-policies

POST /alert-policies/{policyId}/rules/{ruleId}/:enable

 $POST\ / alert-policies/\{policyId\}/rules/\{ruleId\}/: disable$

GET /alert-policies/available-sites

alert-policies:r

GET /alert-policies/{policyId}/rules/{ruleId}

GET /alert-policies/{id}

GET /alert-policies

GET /alert-policies/available-sites

alert-subscriptions

GET /alert-subscriptions/webhooks/{id}

PUT /alert-subscriptions/webhooks/{id}

DELETE /alert-subscriptions/webhooks/{id}

GET /alert-subscriptions/emails/{id}

PUT /alert-subscriptions/emails/{id}

DELETE /alert-subscriptions/emails/{id}

GET /alert-subscriptions/webhooks

POST /alert-subscriptions/webhooks

POST /alert-subscriptions/webhooks/:delete

GET /alert-subscriptions/emails

POST /alert-subscriptions/emails

POST /alert-subscriptions/emails/{id}/:verify

POST /alert-subscriptions/emails/:delete

alert-subscriptions:r

GET /alert-subscriptions/webhooks/{id}

GET /alert-subscriptions/emails/{id}

GET /alert-subscriptions/webhooks

GET /alert-subscriptions/emails



app

GET /applications
GET /applications/{id}/clients/top{n}
GET /applications/top{n}

application:r

GET /applications
GET /applications/{id}/clients/top{n}
GET /applications/top{n}

13-address-profile

GET /13-address-profiles

13-address-profile:r

GET /13-address-profiles

vlan-profile

GET /vlan-profiles POST /vlan-profiles/:delete POST /vlan-profiles/:delete GET /vlan-profiles/{id} DELETE /vlan-profiles/{id} PATCH /vlan-profiles/{id}

vlan-profile:r

GET /vlan-profiles GET /vlan-profiles/{id}

enduser

PUT /endusers/{id}
DELETE /endusers/{id}
GET /endusers
POST /endusers
POST /endusers/{id}/:regenerate-password



enduser:r

GET /endusers

radius-client-object

GET /radius-client-objects/{id} PUT /radius-client-objects/{id} DELETE /radius-client-objects/{id} GET /radius-client-objects POST /radius-client-objects

radius-client-object:r

GET /radius-client-objects/{id} GET /radius-client-objects

Idap-server

GET /ldap-servers/{id} PUT /ldap-servers/{id} DELETE /ldap-servers/{id} GET /ldap-servers POST /ldap-servers

Idap-server:r

GET /ldap-servers/{id} GET /ldap-servers

email-template

GET /email-templates

email-template:r

GET /email-templates

certificate

GET /certificates



certificate:r

GET /certificates

radio-profile

GET /radio-profiles/{id}

PUT /radio-profiles/{id}

DELETE /radio-profiles/{id}

GET /radio-profiles/wmm-qos/{id}

PUT /radio-profiles/wmm-qos/{id}

GET /radio-profiles/sensor-scan/{id}

PUT /radio-profiles/sensor-scan/{id}

GET /radio-profiles/radio-usage-opt/{id}

PUT /radio-profiles/radio-usage-opt/{id}

GET /radio-profiles/neighborhood-analysis/{id}

PUT /radio-profiles/neighborhood-analysis/{id}

GET /radio-profiles/miscellaneous/{id}

PUT /radio-profiles/miscellaneous/{id}

GET /radio-profiles/mac-ouis/{id}

PUT /radio-profiles/mac-ouis/{id}

DELETE /radio-profiles/mac-ouis/{id}

GET /radio-profiles/channel-selection/{id}

PUT /radio-profiles/channel-selection/{id}

GET /radio-profiles

POST /radio-profiles

GET /radio-profiles/mac-ouis

POST /radio-profiles/mac-ouis

radio-profile:r

GET /radio-profiles/{id}

GET /radio-profiles/wmm-qos/{id}

GET /radio-profiles/sensor-scan/{id}

GET /radio-profiles/radio-usage-opt/{id}

GET /radio-profiles/neighborhood-analysis/{id}

GET /radio-profiles/miscellaneous/{id}

GET /radio-profiles/mac-ouis/{id}

GET /radio-profiles/channel-selection/{id}

GET /radio-profiles

GET /radio-profiles/mac-ouis



iot-profile

GET /iot-profiles/{id} PUT /iot-profiles/{id} DELETE /iot-profiles/{id} GET /iot-profiles POST /iot-profiles

iot-profile:r

GET /iot-profiles/{id}
GET /iot-profiles

copilot-connectivity-wired:r

GET /copilot/connectivity/wired/quality-index

GET /copilot/connectivity/wired/locations/hardware

GET /copilot/connectivity/wired/hardware

GET /copilot/connectivity/wired/experience

GET /copilot/connectivity/wired/events

copilot-connectivity-wireless:r

GET /copilot/connectivity/wireless/views

GET /copilot/connectivity/wireless/time-to-connect

GET /copilot/connectivity/wireless/quality-index

GET /copilot/connectivity/wireless/performance

GET /copilot/connectivity/wireless/locations/time-to-connect

GET /copilot/connectivity/wireless/locations/quality-index

GET /copilot/connectivity/wireless/locations/performance

GET /copilot/connectivity/wireless/locations/events

GET /copilot/connectivity/wireless/experience

GET /copilot/connectivity/wireless/events

GET /copilot/connectivity/wireless/apps

copilot-anomalies:r

GET /copilot/anomalies/wifi-efficiency/stats

GET /copilot/anomalies/wifi-efficiency/client-list

GET /copilot/anomalies/wifi-capacity/stats

GET /copilot/anomalies/wifi-capacity/client-list

GET /copilot/anomalies/report

GET /copilot/anomalies/port-efficiency/stats



GET /copilot/anomalies/port-efficiency/speed-duplex-stats

GET /copilot/anomalies/poeflapping/stats

GET /copilot/anomalies/notifications

GET /copilot/anomalies/locations

GET /copilot/anomalies/dfs-recurrence/count-stats

GET /copilot/anomalies/dfs-recurrence/channel-stats

GET /copilot/anomalies/devices-with-locations

GET /copilot/anomalies/devices-by-location

GET /copilot/anomalies/anomalies-by-category

GET /copilot/anomalies/adverse-traffic/packet-counts

GET /copilot/anomalies/adverse-traffic/device-stats

licenses

GET /licenses/nac-entitlement-allocation

PUT /licenses/nac-entitlement-allocation

POST /licenses/legacy-licenses

POST /licenses/extreme-portal/:unlink

POST /licenses/:synchronize

GET /licenses

GET /licenses/{licenseType}

GET /licenses/viq-cuid-info

GET /licenses/summary

GET /licenses/extreme-portal-link-param

GET /licenses/application-filter

DELETE /licenses/legacy-licenses/{id}

licenses:r

GET /licenses/nac-entitlement-allocation

GET /licenses

GET /licenses/{licenseType}

GET /licenses/viq-cuid-info

GET /licenses/summary

GET /licenses/extreme-portal-link-param

GET /licenses/application-filter

copilot-assurance-scans:r

GET /copilot/assurance-scans/overview



packet-capture

GET /packetcaptures
POST /packetcaptures
POST /packetcaptures/{id}/:upload
POST /packetcaptures/{id}/:stop
GET /packetcaptures/{id}
DELETE /packetcaptures/{id}
GET /packetcaptures/files

packet-capture:r

GET /packetcaptures GET /packetcaptures/{id} GET /packetcaptures/files

country

GET /countries GET /countries/{countryCode}/:validate

country:r

GET /countries GET /countries/{countryCode}/:validate