
For immediate assistance call: 206-221-5000, Option 9 For general requests email: help@uw.edu OR go to: www.washington.edu/uwit/cte



Select [Send To Projector] to view your source selection on the projection screen

Turn on the data projector:

1) When you have selected your media source, press the [Send to Projector] button.

The projector will begin to warm-up, which will take about 60 seconds.

Adjust Volume:

- 1) Program volume will control **ALL** our source materials.
- 2) The mic volume controls work the wireless lapel

Laptop:

- 1) Connect either the VGA cable or the HDMI cable
- 2) Select [Laptop VGA] or [Laptop HDMI] based on which cable you are using
- 3) Select [Send To Projector]

Blu-ray:

- 1) Select [Blu-ray]
- 2) Use the controls to navigate the media as needed
- 3) Select [Send to Projector]

Document Camera:

- 1) Select [Doc Cam]
- 2) Use the controls to zoom and focus on your presentation material
- 3) Select [Send To Projector]

Wireless (Air Media & Apple TV):

- 1) Select [Wireless Video]
- 2) Follow the instructions on the touch panel and your laptop for wireless connectivity.

Wireless Microphone:

1)The wireless microphone is located in the drawer of the podium. You will need an IOFA key to access this. The power button is located on the **TOP** of the transmitter pack. A **GREEN** LED will indicate the mic is on.

CTE may not support the use of personal audio/video or network devices. CTE does not warrant or guarantee that third-party audio/video or network devices will be compatible with the technology installed in this