september 2018, february 2020



How to get noForth in the MSP430? (Windows/Linux/Apple)


What's needed?

- Any MSP430FRxxxx or MSP430Gxxxx
- Flash programmer software (UniFlash 4.5.0), link: http://processors.wiki.ti.com/index.php/Category:CCS_UniFlash


What to do?

- Connect the board, wait for the beep
- Start UniFlash 4.5.0

A programming session: this example is for the MSP430FR2355, but the method may be used on all MSP430Gxxxx and MSP430FRxxxx.








4a

Select: Setting & Utilities for the MSP430FR (in the menu on your left)		
Program		
Settings & Utilities		
Memory		
Standalone Command Line		
Tag: On connect, erase user code and unlock the device		
▼ Connection		
☐ On connect, erase main, information, and IP protected area ☑ On connect, erase user code and unlock the device		

4b





6

Now click: **Session** (In the upper left red bar)

Click: **Save Session** (And click the **save** button in lower left corner)

Now the software will remember all settings.