

SPAREX



173F DIESEL ENGINE SPARE PARTS

173F-DIESEL ENGINE SPARES

SL NO.	ITEM CODE	ITEM NAME	PICTURE
1	173F-001	OIL SEAL VALVE CONDUIT 173F	
2	173F-002	VALVE SPRING 173F	
3	173F-003	ROCKER ARM ASSY 173F	
4	173F-004	INTAKE / EXHAUST VALVE 173F	
5	173F-005	VALVE SEAT 173F-178F	
6	173F-006	PISTON SET WITH RINGS 173F	
7	173F-007	CONNECTING ROD 173F	
8	173F-008	STARTING SPRING 173F	

SL NO.	ITEM CODE	ITEM NAME	PICTURE
9	173F-009	RECOIL STARTER (DOUBLE CLAW) 173F	
10	173F-010	PLUNGER SET 173F	
11	173F-011	FUEL INJECTOR PUMP ASSY 173F (ECONOMIC QUALITY)	
12	173F-012	FUEL INJECTOR PUMP ASSY 173F (HIGH QUALITY)	
13	173F-013	FUEL INJECTOR 173F (ECONOMIC QUALITY)	
14	173F-014	FUEL INJECTOR 173F (HIGH QUALITY)	
15	173F-015	DIESEL FILTER ASSY 173F/170F	
16	173F-016	FUEL INJECTION PIPE 173F/170F	

<i>SL NO.</i>	<i>ITEM CODE</i>	<i>ITEM NAME</i>	<i>PICTURE</i>
<i>17</i>	<i>173F-017</i>	<i>ELECTRIC STARTER KIT WITH BATTERY SEAT (11 ITEMS) 173F</i>	
<i>18</i>	<i>173F-018</i>	<i>GASKET SET 173F</i>	
<i>19</i>	<i>173F-019</i>	<i>GEAR RING (ELECTRIC STARTER) 173F</i>	