

SPAREX




***186F DIESEL ENGINE
SPARE PARTS***

186F - DIESEL ENGINE SPARES

SL.NO	ITEM CODE	ITEM NAME	PICTURE
1	186F-001	VALVE SPRING WASHER 186F (A)	
2	186F-002	VALVE SPRING WASHER 186F (B)	
3	186F-003	OIL SEAL VALVE CONDUIT 186F	
4	186F-004	VALVE SPRING 186F	
5	186F-005	VALVE SPRING RETAINER 186F	
6	186F-006	VALVE ADJUSTING PLATE 186F	
7	186F-007	CYLINDER HEAD ASSY 186F	

SL.NO	ITEM CODE	ITEM NAME	PICTURE
8	186F-008	ROCKER ARM ASSY 186F	
9	186F-009	INTAKE EXHAUST VALVE 186F	
10	186F-010	INTAKE EXHAUST VALVE 186F (SQUARE)	
11	186F-011	VALVE GUIDE 186F	
12	186F-012	VALVE SEAT 186F	
13	186F-013	CYLINDER HEAD STUD (M10 x 105) 186F	
14	186F-014	CYLINDER HEAD STUD (M10 x 118) 186F	
15	186F-015	CYLINDER HEAD SHIM COPPER 186F	
16	186F-016	NUT (SHORT) CYLINDER HEAD 186F	

SL.NO	ITEM CODE	ITEM NAME	PICTURE
17	186F-017	NUT (LONG) CYLINDER HEAD 186F	
18	186F-018	CYLINDER RUBBER RING 186F	
19	186F-019	STUD Am (6x50) 186F-192F	
20	186F-020	CRANK CASE GASKET 186F	
21	186F-021	MAIN BEARING 186F	
22	186F-022	STARTER SLEEVE (CUP) 186F - 192F	
23	186F-023	WASHER FLYWHEEL 186F	
24	186F-024	BALANCE SHAFT TIMING GEAR 186F-188F	
25	186F-025	BALANCING SHAFT TIMING GEAR 186F - 188F	

SL.NO	ITEM CODE	ITEM NAME	PICTURE
26	186F-026	CRANKSHAFT (SHAFT TYPE 42MM) 186F	
27	186F-027	CRANKSHAFT (SHAFT TYPE 40MM) 186F	
28	186F-028	CRANKSHAFT TIMING GEAR 186F	
29	186F-029	PISTON RINGS 186F	
30	186F-030	PISTON PIN 186F	
31	186F-031	PISTON SET WITH RINGS 186F	
32	186F-032	CONNECTING ROD 186F	
33	186F-033	VALVE TAPET 186F	
34	186F-034	CAMSHAFT TIMING GEAR 186F	

SL.NO	ITEM CODE	ITEM NAME	PICTURE
35	186F-035	MOTOR - ELECTRIC STARTER (0.9-1 KW) 186F	
36	186F-036	GEAR RING (ELECTRIC STARTER) 186F	
37	186F-037	BATTERY CLAMP (TERMINAL) 178F/186F	
38	186F-038	ELECTRIC STARTER KEY 178F/186F	
39	186F-039	ELECTRIC STARTER KIT WITH BATTERY SEAT (11 ITEMS) 186F	
40	186F-040	STARTING SPRING 186F	
41	186F-041	STARTER ROPE 186F 1.6M	
42	186F-042	STARTER REEL 186F-192F	
43	186F-043	RECOIL STARTER (DOUBLE CLAW) 186F	

SL.NO	ITEM CODE	ITEM NAME	PICTURE
44	186F-044	AIR FILTER SPONGE (BIG AND SMALL) 186F	
45	186F-045	METAL FILTER (FOR SUMP) 186F - 188F	
46	186F-046	AIR FILTER ASSY 186F	
47	186F-047	GASKET INLET PIPE BENDING 186F	
48	186F-048	PLUNGER SET WITH FUEL PIPE 186F	
49	186F-049	FUEL INJECTOR PUMP ASSY (ECONOMIC QUALITY) 186F	
50	186F-050	FUEL INJECTOR PUMP ASSY (PREMIUM QUALITY) 186F	
51	186F-051	FUEL INJECTOR PUMP ASSY GASKET 186F	
52	186F-052	FUEL INJECTOR (ECONOMIC QUALITY) 186F	

SL.NO	ITEM CODE	ITEM NAME	PICTURE
53	186F-053	FUEL INJECTOR (PREMIUM QUALITY) 186F	
54	186F-054	BONNET ASSY 186F/188F	
55	186F-055	OIL FILTER ASSY 186F	
56	186F-056	UPPER STAY 186F	
57	186F-057	FUEL INJECTION PIPE ASSY 186F	
58	186F-058	GASKET SET 186F	