

The importance of loop impedance testing

Application Note


Measurement of earth loop impedance and determining the Prospective Fault Current (PFC) are critical for safety and form integral parts of the International Electrotechnical Commission (IEC) guidelines. Standard IEC 60364 (and its various national equivalent standards) specifies the requirements for fixed electrical installations in buildings, including verification of protection by automatic supply disconnection. The new Fluke 1650 Series Multifunction Installation Testers have a loop impedance test function in addition to being able to measure prospective short circuit current (PSC) and fault current (PFC).

Why measure earth loop impedance?

Earth loop impedance testing is essential since if a live conductor is accidentally connected to an earth conductor in a faulty appliance or circuit, the resulting short-circuit current to earth can easily be high enough to cause electric shock or generate enough heat to start a fire. Normally, the fuse will blow or another circuit protection device will trip, but a situation may arise where the actual short-circuit current in a faulty installation is of insufficient level and the protection device would thus take too long to activate. The delay can be disastrous for life and property. It is therefore necessary to know if the impedance of the path that any fault

current would take is low enough to allow sufficient current to flow in the event of a fault and that any installed protective device will operate within a safe time limit.

As measurement of circuit loop impedance is made with the supply normally on, precautions must be taken to avoid the possibility of electric shock and danger to personnel working in the vicinity of the circuit under test.



Verifying protection by automatic supply disconnection

In IEC 60364, fault loop testing falls under the category of 'Verifying protection by automatic supply disconnection'. This covers verification of the effectiveness of protective measures, and the test methods applied depend on the type of system. TT systems, for example, require measurement of the earth electrode resistance for exposedconductive-parts of the installation, whereas IT systems use calculation or measurement of the first fault current. This application note looks specifically at TN systems, which require measurement of the fault loop impedance and verification of the characteristics of the associated protective device (i.e. visual inspection of the nominal current setting for circuit-breakers,





the current ratings and blow characteristics for fuses and the correct functioning of RCDs).

The earth loop impedance of each individual circuit from the point of use back to the incoming supply connection point should be measured.

A separate measurement of the external loop impedance of the installation can also be made at the incoming supply point or main distribution panel and this value will form part of the overall loop impedance from any part of the final circuit installation. Knowing the earth loop impedance, it is possible to calculate the value of the prospective fault current (PFC) at any point in an installation and to ensure that all installed protective devices are of an adequate rating to clear the potential fault current level.

Measuring earth loop impedance

Since the AC impedance of a circuit may be different from its DC resistance – particularly for circuits rated at over 100 A – the fault loop impedance is measured using the same frequency as the nominal mains frequency (50 Hz). The earth loop impedance test measures the resistance of the path that a fault current would take between line and protective earth. This must be low enough to allow sufficient current to flow to trip a circuit protection device such as a fuse or miniature circuit breaker.

The Fluke 1650 Series testers can be used to carry out the test at a distribution board using the three separate test leads supplied, and at appliance outlets using a dedicated lead fitted with a mains plug. A plug of the appropriate national standard is also supplied with the instrument.

Dedicated functions on the 1650 Series

The Fluke 1650 Multifunction Installation Testers have a dedicated function to measure the earth resistance component of the total loop resistance. They also have a dedicated function for carrying out basic loop impedance measurements between line and protective earth, and can directly display the results in ohms. Measurements should be taken at all outlets of the installation, including light fittings and all distribution (sub-) panels.

The 1650 Series includes several useful features to help with earth loop testing, including an 'Auto-null' to remove test-lead resistance from measurement and Automatic overheat protection. Loop measurements are displayed with 0.01-ohm resolution. The instruments can also measure the line impedance, that is, the source impedance between line and neutral or the line-to-line impedance in three-phase systems, although these tests do not form part of the loop impedance tests specified in IEC 60364.

Conventional techniques for measuring loop impedance can often trip RCDs, preventing further measurement. Often the only way around this is to "bridge" the RCD or replace the RCD with an equivalent rated MCB for the duration of the test - both of which are potentially dangerous and time consuming practices. To overcome this in the 1650 series, Fluke has applied innovative and patented technology to ensure that both electromechanical and electronic type RCDs do not trip during earth loop impedance measurements. This technology gives more consistent results and also allows a very short test period, considerably less than the time required by most conventional installation testers.

Calculating Prospective Fault Current

In addition to measuring the earth loop impedance, the 1650 Series automatically calculates the Prospective Fault Current (PFC) and displays it in the lower part of the dual display. Determining the PFC is important to ensure that the capability of fuses and over-current circuit breakers are not exceeded.

It can also provide a direct readout of the Prospective Short Circuit Current (PSC).

Interpreting results and taking remedial action

Remember that it is not sufficient just to carry out tests and record the results. Knowledge of local regulations – and of how to interpret results – is also required to ensure the installation's safety characteristics are within the prescribed limits. An excessive earth loop impedance value should, for example, prompt an investigation into its cause. Remedial action should then be carried out, and the installation retested.

Caution!

This Application Note is not intended to replace or supercede the recognized standards in IEC 60364 (or its national equivalents), but to provide a summary of the fault loop impedance testing considerations. Always consult the appropriate standards publication.

Fluke. Keeping your world up and running.

Fluke Corporation

PO Box 9090, Everett, WA USA 98206

Fluke Europe B.V.

PO Box 1186, 5602 BD Eindhoven, The Netherlands

For more information call:

In the U.S.A. (800) 443-5853 or Fax (425) 446-5116 In Europe/M-East/Africa (31 40) 2 675 200 or Fax (31 40) 2 675 222 In Canada (800)-36-FLUKE or Fax (905) 890-6866 From other countries +1 (425) 446-5500 or Fax +1 (425) 446-5116 Web access: http://www.fluke.com

©2003 Fluke Corporation. All rights reserved. Printed in the Netherlands. 9/2003 Pub-ID 10642-eng