





## Specifications –Temperature Setting

- 1. The "Up" or "Down" buttons are used to change the required water temperature (set temperature)
- 2. The first "Up" or "Down" button press, enters the temperature setting mode
- 3. After entering temperature setting mode, a single "Up" button press increase the set temperature by 5 degrees
- 4. After entering temperature setting mode, a single "Down" button press decrease the set temperature by 5 degrees
- 5. The minimum possible set temperature is 35 degrees
- 6. The maximum possible set temperature is 75 degrees
- 7. The "External E2PROM" should save the set temperature once set
- 8. If the electric water heater is turned OFF then ON, the stored set temperature should be retrieved from the "External E2PROM"
- 9. The initial set temperature is 60 degrees



## Specifications –ON/OFF Behavior

- 1. If power is connected to the heater, the electric water heater is in OFF state
- 2. If the "ON/OFF" button is released and the electric water heater is in OFF state, the electric water heater goes to ON state
- 3. If the "ON/OFF" button is released and the electric water heater is in ON state, the electric water heater goes to OFF state
- 4. In the OFF state, all display should be turned OFF



# Specifications –Temperature Sensing

- 1. The temperature sensor measures the water temperature
- 2. The water temperature should increase, if the "Heating Element" is ON
- 3. The water temperature should decrease, if the "Cooling Element" is ON
- 4. Temperature should be sensed once every 100 ms
- 5. The decision to turn ON or OFF either the "Heating Element" or the "Cooling Element" based on the average of the last 10 temperature readings



# Specifications –Heating/Cooling Elements

- 1. The "Heating Element" should be turned ON, if the current water temperature is less than the set temperature by 5 degrees
- 2. The "Cooling Element" should be turned OFF, if the current water temperature is less than the set temperature by 5 degrees
- 3. The "Heating Element" should be turned OFF, if the current water temperature is greater than the set temperature by 5 degrees
- 4. The "Cooling Element" should be turned ON, if the current water temperature is greater than the set temperature by 5 degrees



#### Specifications –Seven Segments

- 1. Seven segment by default show the current water temperature or the set temperature
- 2. By default, the 2 seven segment display are show the current water temperature
- 3. If the electric water heater is in the temperature setting mode, the 2 seven segment displays should blink every 1 second and show the set temperature
- 4. In the temperature setting mode, every change in the set temperature should be reflected on the 2 seven segment displays
- 5. The 2 seven segment display should exit the temperature setting mode, if the "UP" and "Down" buttons are not pressed for 5 seconds



## Specifications –Heating Element Led

- 1. If the "Heating Element" is ON, the "Heating Element Led" should blink every 1 second
- 2. If the "Cooling Element" is OB, the "Heating Element Led" should be ON



# THANK YOU!



