

























	1	2	3	4	5	6
A	Power input, USB-C and 3.3 V File: 01_Power_Input_USB.kicad_sch		ESP32-S3, native USB, reset and boot File: 02_ESP32_USB_Reset.kicad_sch			
B	E-paper power and interface File: 03_Display_EPaper.kicad_sch		Touch always-on rail and RTC File: 04_Touch_RTC.kicad_sch			
C	AUTOTERM UART and 1-Wire File: 05_AUTOTERM_1Wire.kicad_sch		External controls, lighting and diagnostics File: 06_Controls_Diagnostics.kicad_sch			
D					ESP32-S3-WROOM-1U-N16R8 / 10-14V vehicle auxiliary battery / USB-C Review schematic – NOT RELEASED FOR PRODUCTION LandyHeater Sheet: / File: LandyHeater-Board.kicad_sch Title: Landy Heater Controller – Hierarchy Size: A4Date: 2026-09-06 KiCad E.D.A. 10.0.6Rev: A / Phase 2Id: 1/7	
	1	2	3	4	5	6







Touch can wake in comfort standby Wake-latch option DMP pending pulse measurement Review schematic - NOT RELEASED FOR PRODUCTION LandyHeater Sheet: /Touch always-on rail and RTC/ File: 04_Touch_RTC.kicad_sch <i>Title: Touch always-on rail and RTC</i>		BR1225
Size: A2	Date: 2026-09-06	Rev: A / Phase 2
KiCad E.D.A. 10.0.6		
		Id: 5/7

