APC Reaper Console

User manual

APC Console Panel, APC Faders, and the Akai APC mini mk2
Version 0.3.0-beta.23

macOS Apple Silicon · REAPER 7.80 or newer · Akai APC mini mk2

Contents

1. Introduction 4

1.1 What this manual covers 4

1.2 Where the manual lives 4

1.3 A short map of the system 4

2. The APC mini mk2 5

2.1 The surface 5

2.2 Pickup 5

2.3 Lights 5

3. Scenarios and mapping types 6

3.1 The four scenarios 6

3.2 The three mapping types 6

4. APC Console Panel 7

4.1 Opening the panel 7

4.2 User Profile 7

4.3 Plugin List 7

4.4 Project plugins, Delete, and Manual 7

4.5 Mapping Share 7

4.6 Diagnostics 7

5. APC Faders 9

5.1 The window 9

5.2 Assign, Clear, Rec, and Save 9

5.3 Recall Mapping 9

5.4 The mapping-type buttons 9

5.5 Learn from the hardware 9

6. Volume 11

6.1 Tracks 11

6.2 Plug-ins in Volume 11

6.3 Master plug-ins 11

6.4 The other buttons in Volume 11

7. Pan 12

7.1 What changes 12

7.2 Buttons that differ from Volume 12

8. Send 13

8.1 The send grid 13

8.2 Faders and mute 13

9. Device 14

9.1 The focused plug-in 14

9.2 Opening a plug-in 14

9.3 Mute, record, and windows ... 14
9.4 The other buttons in Device ... 14
10. Classic mapping ... 15
10.1 One page ... 15
10.2 What each fader does ... 15
11. Pages ... 16
11.1 Turning Pages on ... 16
11.2 Moving between pages ... 16
11.3 Saving a later page ... 16
12. Parametric EQ ... 17
12.1 What a band mapping is ... 17
12.2 Choosing a band ... 17
12.3 Add, mute, solo, and remove ... 17
12.4 Curve and filter type ... 17
12.5 Limits ... 17
13. Control reference ... 19
13.1 How to read this chapter ... 19
13.2 Faders ... 19
13.3 Pads ... 19
13.4 Scenario and navigation buttons ... 19
13.5 Right-hand buttons ... 19
13.6 APC Faders commands ... 20
13.7 APC Console Panel commands ... 20
14. Unplug, follow, and recovery ... 21
14.1 The selected track and the focused plug-in ... 21
14.2 What releases the faders ... 21
14.3 Removing the extension ... 21

1. Introduction

1.1 What this manual covers

This manual describes how to use APC Reaper Console from the APC mini mk2 and from the two windows the extension opens: APC Console Panel and APC Faders. It covers the four mixer scenarios and the three ways a plug-in mapping can behave.

The four scenarios are Volume, Pan, Send, and Device. The three mapping types are Classic, Pages, and Parametric EQ. Classic is the ordinary eight-fader mapping. Pages and Parametric EQ are switched on per plug-in from APC Faders.

1.2 Where the manual lives

ReaPack installs this PDF at Data/APCReaperConsole/APC_CONSOLE_MANUAL.pdf inside the REAPER resource folder. On the Library tab of APC Console Panel, Manual opens that file in the default browser.

1.3 A short map of the system

The hardware chooses the scenario and moves the controls. APC Faders edits the eight parameters of the focused plug-in. APC Console Panel keeps your name, the mapping library, import and export, and the diagnostics.

A Device fader uses the project override for that plug-in instance, then your personal template, then the shared factory or imported mapping. An empty slot does not borrow a parameter. Assign, Clear, or a swap in APC Faders drops a project override on that fader, so the open plug-in follows the personal template.

2. The APC mini mk2

2.1 The surface

The grid is eight columns by eight rows. The bottom row selects tracks. The seven rows above it show plug-ins or sends, depending on the scenario. Eight faders sit under the grid, and a ninth fader on the right is the master. Shift is the button at the lower left of the controller.

Under the grid, from left to right, are Volume, Pan, Send, Device, Up, Down, Left, and Right. The column on the right of the grid, from top to bottom, is Clip Stop, Solo, Mute, Record Arm, Pages, Remove band, Add band, and Stop All Clips.

Place	Control	Role
Grid, bottom row	Eight pads	Select the tracks in view
Grid, seven rows above	56 pads	Plug-ins, or sends in Send
Under the grid	Volume, Pan, Send, Device	Choose the scenario
Under the grid	Up, Down	Scroll the pad grid
Under the grid	Left, Right	Move the track bank, or the mapping
Right column	Eight buttons	Track state, windows, and mapping type
Faders	1–8 and Master	The value for the current scenario
Lower left	Shift	Changes the button or fader under it

2.2 Pickup

The faders are not motorized and the APC mini mk2 does not sense a touch. A fader writes only after it reaches the current value, within two steps. Moving the bank, changing scenario, or moving the same control in REAPER releases the fader. It waits again before it writes. Hold Shift with a fader to move a continuous value at one tenth of the normal travel.

2.3 Lights

A track pad is green when that track is selected and red when the track exists but is not selected. A pad with no track stays off. Volume, Pan, Send, or Device lights while that scenario is current. Device blinks during Learn. Left and Right light while another step is available. Solo, Mute, and Record Arm light while their target is on.

In Volume, Pan, and Device, a plug-in pad is lit when a plug-in is there. The selected plug-in is yellow. A bypassed plug-in is pale. In Send, a send to a track is green, the selected send is yellow, and a muted send that is not selected is a dimmer green. An empty send slot and a hardware output stay off.

3. Scenarios and mapping types

3.1 The four scenarios

The scenario decides what the eight faders write and what the seven pad rows show. The bottom row remains track select in every scenario. The master fader remains the master-track volume in every scenario.

Scenario	Eight faders	Seven pad rows
Volume	Track volume	Plug-ins on those tracks
Pan	Track pan	The same plug-ins
Send	Selected send volume	Mixer sends, including empty slots
Device	Mapped plug-in parameters	The same plug-ins as Volume

3.2 The three mapping types

Mapping type is separate from the scenario. It is stored for each plug-in and applies when that plug-in is focused and Device is in use. Pressing Volume, Pan, Send, or Device suspends Pages and Parametric EQ so Left and Right move the track bank again. The fifth button on the right, Pages, brings the stored mapping type back for the focused plug-in.

Type	How it is turned on	What changes
Classic	Pages and Parametric EQ both off	One page of eight faders
Pages	Pages in APC Faders	Up to sixteen pages of eight faders
Parametric EQ	Parametric EQ in APC Faders	The same eight roles follow each band

Parametric EQ takes priority. If both Pages and Parametric EQ are on for one plug-in, focusing that plug-in uses Parametric EQ. Turn Parametric EQ off to use Pages.

4. APC Console Panel

4.1 Opening the panel

Open Extensions > APC Reaper Console > Console panel. The window has two tabs, Library and Diagnostics. It is not docked. It reopens at the last screen position.

4.2 User Profile

Name is the author stored when you save a personal mapping. Save keeps that name. The license of a mapping you save is Personal use, and that field cannot be changed. Enter a name before you store a mapping if you want Export to be able to find it later. Export lists only mappings whose author is this name.

4.3 Plugin List

The list shows Type, Developer, Name, Version, Author, Active, and Profile. Version is the plug-in version the mapping was tried with. Profile is the mapping's own revision. It advances by one when that mapping is saved from APC Faders. A fader edit that has not been saved lasts until REAPER quits.

Active keeps one mapping checked for each plug-in. Checking a row clears the others for that plug-in. The list opens with Show Inactive off, so only checked mappings are shown. Show Errors keeps a file that did not parse, and any two mappings that share one profile id. Search is case-insensitive. Type, Developer, and Author narrow the list. Click a column title to sort, and click it again to reverse the order.

Faders, to the right of the list, shows the eight assignments of the selected mapping. An empty cell is an unassigned fader. The list does not edit those faders. Editing is done in APC Faders.

4.4 Project plugins, Delete, and Manual

Project plugins auto-map reads the plug-ins already on tracks and on the master. For each plug-in that does not already have a personal template, it fills faders 1–8 with the first suitable parameters, in the order the plug-in lists them. Fader 1 is the leftmost fader. Meters, bypass, on/off buttons, and the host Bypass, Wet, and Delta controls are left off. A plug-in that is not in the project is not part of this scan.

Delete asks, then moves a personal or imported file to the trash. A factory file cannot be deleted from the list. Delete does not change a project override. Manual sits on the same row as Delete, at the right edge of the window, and opens this PDF in the default browser.

4.5 Mapping Share

Import asks before it writes. Yes imports the file into APCReaperConsole/imports/. If that profile is already imported, Yes keeps both and No replaces the imported file. A personal template with the same id is not replaced. An import does not check Active by itself.

Export writes the mappings you check. It does not copy a project name, a project path, or track names. The file can be schema 1, or schema 2 when a fader has an explicit scale. An unknown schema is rejected and replaces nothing.

4.6 Diagnostics

The Diagnostics tab shows the MIDI input and output, the scenario, the track window, the focused plug-in, and the last error. Enable Logs is off until you turn it on. It writes apc-reaper-console.log in the REAPER resource folder. Show Logs, Export Logs, and Clear Logs open, save, or empty that file. The check is kept for the next launch.

LEDs ON restores the lights this surface owns. LEDs OFF turns them off until LEDs ON. Reset pickup states makes every fader, including the master, wait until it matches the current value again. Export bug report saves a local text file. It is not uploaded, and it does not include the project name or track names.

5. APC Faders

5.1 The window

APC Faders opens when a plug-in is focused from the APC. It shows eight faders side by side and a column of mapping commands. An empty slot is a dense red-and-black texture and has no parameter name. An assigned slot has a yellow level and the parameter name under it. Click a fader to select it. Drag one fader onto another to swap the parameters. If the destination is empty, the parameter moves and the source stays empty. Moving a Device fader on the APC also selects that fader.

5.2 Assign, Clear, Rec, and Save

The menu lists plug-in parameters that are not already on a fader. Assign puts the chosen parameter on the selected fader. Clear removes that parameter in this project. Bypass, Wet, and Delta are not in the menu.

Rec arms recording for the selected fader of this plug-in instance. The label is red, and the face is a faint red while recording is armed. The choice is stored in the project. Another instance starts disarmed when nothing was stored for it. Turning Rec on puts the track in Latch, so any armed envelope on that track can be written. Turning it off restores the previous automation mode. No envelope is created until the fader moves. The move ends shortly after the fader stops, and Latch holds the last value until transport stops. Stopped transport sets the parameter and does not write automation.

In Device, the Record Arm button on the APC toggles the same recording state for the selected fader. In Volume, Pan, and Send that button still arms the track.

Save writes the personal template and advances Profile by one. Until Save, the edit stays in the session. After a successful save, a window says the mapping was saved. If the plug-in is also installed in another format, Save asks whether to apply the template to every format or only to the current one. Parameters are matched by name. A parameter that does not exist on another format leaves that fader unassigned there.

5.3 Recall Mapping

Recall Mapping restores the arrangement captured when the plug-in was focused. Save replaces that snapshot with the saved arrangement. Use Recall to drop unsaved fader edits. If there is nothing to restore, the window says so.

5.4 The mapping-type buttons

Pages turns Pages on or off for this plug-in. The button reads Pages on while it is enabled. Parametric EQ does the same for band mapping and reads Parametric EQ on while it is enabled. The arrows under those buttons step the current page. Add band, Mute band, and Remove band act on the current Parametric EQ band. They are described in chapter 12.

5.5 Learn from the hardware

In Device, Shift+Device starts Learn. The Device button blinks. Move a control on the focused plug-in, then move fader 1–8. That fader takes the control and does not write it during the learn move. A meter that is already moving is not treated as a touch. Volume, Pan, and Send do not start Learn. Learn writes to this instance. Save stores it as the personal template.

While Learn is on, Shift+Pan prepares a clear of the eight faders on the current page. Confirming also blocks assignments inherited from the template. It does not switch the scenario to Pan.

6. Volume

6.1 Tracks

Volume is the scenario at startup. Its button is green. Faders 1–8 control the volume of the eight tracks in view, after pickup. The window starts at tracks 1–8. Right moves eight tracks forward. Left moves eight tracks back. Shift+Right and Shift+Left move one track. At the end of the project the unused faders do not write. Every bank change releases the faders.

The bottom pads select those tracks. One selected pad stays green. Pads for the other tracks in view are red. Selecting tracks with the mouse updates the pads, including a multi-selection. Solo, Mute, and Record Arm follow the first selected normal track. The master track is never that target. With no track selected, those three buttons do nothing and their lights stay off.

6.2 Plug-ins in Volume

The seven rows above the track pads show the plug-in chains of the eight tracks. The top row is the first plug-in in view. Up and Down scroll every column together. Shift+Up and Shift+Down do nothing in Volume. A lit pad opens that plug-in's window, switches to Device, and rearms the Device faders. It does not change the track selected in REAPER. A pad with no plug-in does nothing.

6.3 Master plug-ins

Shift+Volume shows the master-track plug-ins in the first column and turns the other columns off. The Volume button blinks. A pad in that column focuses that master plug-in, and the eight faders follow it as they would a plug-in on a normal track. Shift+Volume again returns the pads to the track grid. In Volume, Mute still mutes the selected track.

6.4 The other buttons in Volume

Control	Action
Faders 1–8	Volume of the eight tracks, after pickup
Shift+fader	Fine volume
Master fader	Master track volume
Bottom pads	Select the track in that column
Plug-in pads	Open the plug-in and switch to Device
Up, Down	Scroll the plug-in grid
Left, Right	Bank of eight tracks
Shift+Left, Shift+Right	One track
Solo	Toggle solo on the first selected track
Mute	Toggle mute on that track
Record Arm	Toggle record arm on that track
Clip Stop	Close the focused plug-in window
Stop All Clips	Close every open plug-in window
Shift+Volume	Show or hide master-track plug-ins

7. Pan

7.1 What changes

Pan uses the same track window and the same plug-in grid as Volume. The eight faders control pan, from full left to full right, with the centre near the middle of the fader. Volume and Pan keep separate pickup. Changing scenario or bank releases the faders. Changing the selected track does not leave Pan.

7.2 Buttons that differ from Volume

Mute still mutes the first selected track. Record Arm still arms that track. A plug-in pad still opens the plug-in and switches to Device. Shift+Up and Shift+Down do nothing. Shift+Pan, while Learn is on, prepares the page clear described in chapter 5. Otherwise Pan is only the scenario button.

Control	**Action**
Faders 1–8	Pan of the eight tracks, after pickup
Shift+fader	Fine pan
Master fader	Master track volume, not pan
Plug-in pads	Open the plug-in and switch to Device
Up, Down	Scroll the plug-in grid
Left, Right	Bank of eight tracks, unless Pages or Parametric EQ is active
Mute	Mute the first selected track

8. Send

8.1 The send grid

Send replaces the plug-in grid with the mixer sends of the eight tracks. An empty slot stays off and does not pull a later send upward. A hardware output occupies its slot, but the pad stays off and cannot be selected. Only a send to a track lights. The selected send is yellow, including when it is muted. Another send is green. A muted send that is not selected stays green at a lower brightness.

Up and Down scroll the send slots only. They do not move the plug-in grid. Returning to Volume, Pan, or Device restores the plug-in grid. Clicking a send so that REAPER selects its envelope switches to Send, brings that track into the eight columns, scrolls the slot into view, and selects the pad.

8.2 Faders and mute

Faders 1–8 write the volume of the selected send in that column, after pickup. If the send moves and the routing is unique, the selection follows. If the routing is ambiguous or the send disappears, the selection clears. Mute bypasses the selected send, and its light follows that bypass. Solo and Record Arm still act on the first selected track. The master fader still writes the master volume.

Control	Action
Faders 1–8	Volume of the selected send
Shift+fader	Fine send volume
Send pads	Select that send
Up, Down	Scroll send slots
Mute	Bypass the selected send
Left, Right	Bank of eight tracks, unless a mapping type has taken the arrows

9. Device

9.1 The focused plug-in

Device uses the same plug-in grid as Volume and Pan. Faders 1–8 write the eight slots of the current mapping page for the focused plug-in. A slot with no mapping stays still. It does not take the first eight parameters of the plug-in. Changing the plug-in, the page, the profile, or the project rearms the eight Device faders.

The first time a computer has no choices file, one factory mapping per plug-in is checked Active. After that, the checks stay as you left them. If several shared mappings match and none is checked, Device does not choose one.

9.2 Opening a plug-in

A lit plug-in pad opens that plug-in's window and does not change the selected track. If you press it from Volume or Pan, the surface switches to Device before it accepts fader moves. The last pad you press is the fader context. Focusing a plug-in in REAPER brings its track into view, switches to Device, and scrolls the grid only if that plug-in is outside the seven rows. It does not open the window again. Take FX, input FX, and plug-ins inside containers are ignored.

9.3 Mute, record, and windows

Mute bypasses the focused plug-in. The Mute light stays on while it is bypassed. Record Arm toggles recording for the selected Device fader, as Rec does in APC Faders. Clip Stop closes the focused floating window. Stop All Clips closes every open plug-in window.

9.4 The other buttons in Device

Control	Action
Faders 1–8	The eight mapped parameters, after pickup
Shift+fader	Fine movement of a continuous parameter
Shift+Device	Start or stop Learn
Up, Down	Scroll the plug-in grid
Shift+Up, Shift+Down	Step the mapping page when Pages is on
Left, Right	Track bank, or the active mapping type
Mute	Bypass the focused plug-in
Record Arm	Record the selected fader

10. Classic mapping

10.1 One page

Classic is the mapping you have when Pages and Parametric EQ are both off. Each plug-in has one page of eight faders. Left and Right move the track bank. Shift+Left and Shift+Right move one track. Shift+Up and Shift+Down do not open another page.

10.2 What each fader does

In Volume, Pan, and Send the eight faders ignore the plug-in mapping and keep writing volume, pan, or the selected send. The mapping is used only in Device, and when Shift+Volume has focused a master-track plug-in. The bottom pads, Solo, and the window buttons keep the meaning of the current scenario.

Control	**Classic behaviour**
Pages button in APC Faders	Off. The label reads Pages
Parametric EQ button	Off. The label reads Parametric EQ
< and >	No further page
Left, Right	Track bank of eight
Shift+Left, Shift+Right	One track
Fifth right button	Returns to Classic. The light stays off
Sixth and seventh right buttons	No band to remove or add
Device faders	The eight slots of the single page

11. Pages

11.1 Turning Pages on

Focus the plug-in and press Pages in APC Faders. The button reads Pages on, and the notice says that Pages is on for this plug-in. The choice is kept for that plug-in. Press Pages again to return it to Classic. If the current page is not the first, turning Pages off returns to page 1.

11.2 Moving between pages

A mapping can hold up to sixteen pages. You can move forward from a page that already has an assignment, and back to any earlier page. An empty page past the last assignment is not offered. The arrows in APC Faders step one page. On the APC, Left and Right step pages instead of the track bank, and their lights show whether another page exists. In Device, Shift+Up and Shift+Down step pages as well. Up and Down without Shift still scroll the plug-in grid.

Shift does not make Left and Right move a single track while Pages is active. Press Volume, Pan, Send, or Device to suspend Pages and use the arrows for the track bank. The fifth button on the right turns the Pages navigation back on for the focused plug-in. That button lights solid green while Pages is the active mapping type.

11.3 Saving a later page

Assignments on later pages are part of the same mapping. Save stores them in the personal template and advances Profile by one. Recall Mapping restores the whole arrangement captured for this instance, including the page you were on.

Control	While Pages is active
Left	Previous page
Right	Next page, when the current page has an assignment
Shift+Up, Shift+Down in Device	Previous or next page
Up, Down	Scroll the plug-in or send grid of the scenario
< and > in APC Faders	Previous or next page
Faders 1–8 in Device	The eight slots of the page in view
Fifth right button	Solid green. Press it to return here after a scenario change

12. Parametric EQ

12.1 What a band mapping is

Parametric EQ uses the eight faders as roles, not as eight unrelated parameters. Map the controls of one band first: frequency, gain, Q, and any other control you want on a fader. The extension then looks for the same names on the other bands. Frequency 1 and Frequency 2 are the same role on two bands. A control whose name has no band number stays on every band.

Turn it on from APC Faders with Parametric EQ, while the equalizer is focused. The button reads Parametric EQ on. The eight Device faders then move those roles on the current band. Changing band rearms the faders. Volume, Pan, and Send still move the mixer. The mapping applies when Device is writing the plug-in, including a master plug-in opened with Shift+Volume.

12.2 Choosing a band

Left and Right move to the neighbouring band by frequency. The notice reports Band N of M. If the plug-in does not report a frequency, the bands are stepped in band order. Touching a band control in the plug-in window selects that band on the APC. The seventh button on the right, Add band, lights solid green while Parametric EQ is active. The fifth button blinks.

12.3 Add, mute, solo, and remove

Add band creates or enables the next band and selects it. Map at least one fader before adding a band. If the plug-in has no further band, the notice says so. Remove band, the sixth button on the right, turns the current band off or deletes it when the plug-in allows that. Mute band, or Shift+Mute on the APC, bypasses the current band. Press it again to bring the band back.

Shift+Solo solos the current band. On a plug-in that has its own solo control, that control is used. Otherwise the other bands are bypassed and restored when solo is pressed again. Moving to another band while solo is on carries the solo to that band. Shift+Stop All Clips toggles the dynamics control of the current band when the plug-in has one. Without Shift, Stop All Clips still closes every plug-in window.

12.4 Curve and filter type

Shift+Up and Shift+Down step the curve or filter type of the current band. The notice shows the type. They do not scroll the plug-in grid while Parametric EQ is active.

12.5 Limits

A parameter the plug-in does not expose to REAPER cannot be mapped. Some equalizers report band names in a shifted order, so a later band's width or gain may have no host parameter. A control that is not a host parameter, such as a graphic length that exists only in the plug-in window, cannot be placed on a fader. ReaEQ bands are grouped by the equalizer information REAPER reports, and the learned frequency, gain, or Q role is kept on every band.

Control	While Parametric EQ is active
Device faders 1–8	The mapped role on the current band
Shift+fader	Fine movement of that role
Left, Right	Previous or next band

Control	**While Parametric EQ is active**
Shift+Up, Shift+Down	Previous or next curve type
Shift+Mute	Mute or unmute the current band
Shift+Solo	Solo or unsolo the current band
Shift+Stop All Clips	Toggle dynamics for the current band
Sixth right button	Remove the current band
Seventh right button	Add the next band. The button is green
Fifth right button	Blinks. Press it to return here after a scenario change
Add band, Mute band, Remove band	The same actions from APC Faders

13. Control reference

13.1 How to read this chapter

Each control is listed once. Where the four scenarios disagree, the scenario is named. Where Classic, Pages, and Parametric EQ disagree, the mapping type is named. A control that is not in the table does not send a command in this version.

13.2 Faders

Fader	Volume	Pan	Send	Device
1–8	Track volume	Track pan	Selected send	Mapped parameter
Shift+1–8	Fine volume	Fine pan	Fine send	Fine parameter
Master	Master volume	Master volume	Master volume	Master volume
Shift+Master	Fine master volume	Fine master volume	Fine master volume	Fine master volume

In Pages, Device faders 1–8 are the slots of the page in view. In Parametric EQ, they are the roles of the current band. In Classic, they are the single page. Volume, Pan, and Send do not change with the mapping type, except that Left and Right may have been taken over by Pages or Parametric EQ.

13.3 Pads

Pads	Volume and Pan	Send	Device
Bottom row	Select the track	Select the track	Select the track
Seven rows above	Open a plug-in and enter Device	Select a send	Open a plug-in
Shift+Volume, first column	Master plug-ins	Not shown	Master plug-ins when that view is on

13.4 Scenario and navigation buttons

Button	Classic	Pages	Parametric EQ
Volume	Volume scenario	Volume, and suspends Pages	Volume, and suspends EQ
Pan	Pan scenario	Pan, and suspends Pages	Pan, and suspends EQ
Send	Send scenario	Send, and suspends Pages	Send, and suspends EQ
Device	Device scenario	Device, and suspends Pages	Device, and suspends EQ
Shift+Device	Learn, in Device	Learn, in Device	Learn, in Device
Up, Down	Scroll the grid	Scroll the grid	Scroll the grid
Shift+Up, Shift+Down	No action in Volume or Pan. In Device, no extra page	Step the page in Device	Step the curve type
Left, Right	Track bank	Mapping page	EQ band
Shift+Left, Shift+Right	One track	Still the mapping page	Still the EQ band

13.5 Right-hand buttons

From the top	Usual action	Extra action
Clip Stop	Close the focused plug-in window	None
Solo	Solo the first selected track	Shift+Solo solos the EQ band
Mute	Track, plug-in, or send, by scenario	Shift+Mute mutes the EQ band
Record Arm	Arm the track, or the Device fader	None
Pages	Return to the stored mapping type	Solid in Pages, blinking in Parametric EQ
Remove band	No action in Classic or Pages	Remove the current EQ band
Add band	No action in Classic or Pages	Add the next EQ band. Lit in Parametric EQ

From the top	Usual action	Extra action
Stop All Clips	Close every plug-in window	Shift+Stop All Clips toggles EQ dynamics

13.6 APC Faders commands

Command	Action
Assign	Put the chosen parameter on the selected fader
Clear	Remove the parameter from the selected fader
Drag a fader	Swap, or move onto an empty fader
Rec	Arm or disarm automation for the selected fader
Save	Write the personal template and advance Profile by one
Recall Mapping	Restore the captured arrangement
Pages	Turn Pages on or off for this plug-in
Parametric EQ	Turn Parametric EQ on or off for this plug-in
< and >	Step the mapping page
Add band	Add the next Parametric EQ band
Mute band	Mute or unmute the current band
Remove band	Remove the current band

13.7 APC Console Panel commands

Command	Action
Save, under User Profile	Keep your author name
Active	Choose the mapping used for that plug-in
Show Inactive	Show mappings that are not checked
Show Errors	Show a file that did not parse
Project plugins auto-map	Create starter mappings for plug-ins in the project
Delete	Move a personal or imported mapping to the trash
Import	Add a shared mapping
Export	Write the checked mappings whose author is your User Profile name
Manual	Open this PDF in the default browser
Enable Logs	Write the console log. Off until you turn it on
Reset pickup states	Make every fader wait for the current value
Export bug report	Save a local diagnostic text file

14. Unplug, follow, and recovery

14.1 The selected track and the focused plug-in

If the first selected track leaves the eight columns, the window follows it and the faders rearm. The scenario does not change. A track that is already visible does not move the window. The master track does not move it.

A new plug-in focus brings that track into view and switches to Device. The same focus, held still, does not pull you back to Device after you press Volume. A plug-in window that loses focus is not treated as a new focus.

14.2 What releases the faders

The faders release on a project change, undo, redo, and when a track or plug-in is inserted, removed, or reordered. The focused plug-in is kept only when its identity still matches. A send is written only when its routing still matches. Unplugging the APC closes the port within about half a second. Plugging the same port name back in opens it again, even if the device index moved. Two ports with the same name stay closed.

14.3 Removing the extension

Quit REAPER. In Extensions > ReaPack > Browse packages, uninstall APC Console. That removes the extension and this manual. Factory mappings are separate packages under Factory mappings; uninstall one of those to remove that mapping. Personal templates in APCReaperConsole/user stay. An update downloads a factory mapping only when that file changed.