

PCB Designing with KiCad

From Schematic to Fabrication-Ready PCB


Introduction to KiCad: Your Gateway to Electronics

KiCad is a powerful, **free, and open-source PCB design software** that empowers hobbyists, students, and professionals alike.

It's widely used across **education, rapid prototyping, and professional electronics development**.

KiCad supports the entire PCB development cycle, from **conceptual schematic capture to final fabrication files**.

- KiCad bridges the gap between **electronic design and digital fabrication**, making complex hardware accessible.



The KiCad Workflow: A Step-by-Step Journey

Mastering KiCad means understanding its logical progression. Each step builds on the last, ensuring a robust and functional final product.



1. Schematic Creation

Define electrical connections.

2. Footprint Assignment

Link logical symbols to physical layouts.

3. PCB Layout

Arrange components and route traces.


4. Design Rule Check

Validate against manufacturing constraints.

5. Fabrication Files

Generate outputs for manufacturing.

Important: Errors introduced early in this process can cascade, leading to costly issues during fabrication.



Schematic Design Fundamentals: The Electrical Blueprint

The schematic is your circuit's electrical "story."

It represents the **electrical connections** between components using standard symbols and nets.

Best practices include **clear labeling, logical grouping, and consistent power/ground connections** to ensure readability and functionality.

Remember: A flawed schematic guarantees a flawed PCB.

Components & Footprints: Bridging Logic and Reality

Symbols vs. Footprints


A **symbol** defines a component's electrical function in the schematic. A **footprint** defines its physical dimensions and pad layout on the PCB.

Key Footprint Details

- Physical size and dimensions
- Shape and size of copper pads
- Diameter and plating of through-holes

Critical Match


Footprints must precisely match the **real-world components** you intend to use and your chosen **fabrication method** (e.g., hand-soldering, milling, or industrial manufacturing).



□ **Tip:** Always verify footprint dimensions against component datasheets before starting your PCB layout to avoid costly rework.


PCB Layout Basics: Arranging Your Circuit

A well-planned layout is crucial for both functionality and manufacturability.




Logical Component Placement

Group related components together to minimize trace lengths and signal interference. Consider thermal management for power components.



Define Board Outline

Precisely define the physical dimensions and shape of your PCB, including any cutouts or mounting holes. This ensures it fits into its enclosure.



Single-Sided for Milling

For hobbyist PCB milling, single-sided designs are often preferred as they simplify the milling process and reduce complexity.

Concept: Intuitive placement simplifies routing and improves signal integrity.

Routing Traces & Ground: Connecting the Dots

○ Trace Routing


Route traces efficiently, prioritizing signal integrity. Avoid sharp 90-degree corners and unnecessary crossings that can create signal issues.

○ Ground Strategies

Implement robust ground planes or thick ground traces. A solid ground connection is vital for noise reduction and stable circuit operation.

○ Milling Considerations

For milled PCBs, ensure wider traces and greater spacing to accommodate the physical limitations of the milling bit.



Fabrication Note: PCB milling demands careful attention to trace width and spacing for proper isolation.

Design Rules & DFM: Ensuring Manufacturability

Design for Manufacturability (DFM) is paramount for successful fabrication.



Design Rule Check (DRC)

DRC is your virtual inspector. It catches critical errors like clearance violations between traces/pads, and identifies unconnected nets (rat's nest).



Milling-Friendly Rules

When designing for milling, adapt your rules: use wider traces, larger pad sizes, and minimize the use of vias to ensure the machine can physically create the board.



The DFM Mindset

Always design with the capabilities of your fabrication method in mind. Thinking like the machine ensures your design can actually be built.



Preparing PCB for Milling: Specialized Considerations

Milling a PCB has specific requirements that differ from industrial fabrication.

1 Prefer Single-Sided Boards

Single-sided designs are significantly easier to mill accurately. If two layers are essential, consider using jumpers instead of complex vias.

2 Increase Clearance

To achieve proper isolation routing, increase the clearance between copper features. This ensures the milling bit can pass cleanly without shorting.

3 Add Reference Labels

Include clear reference labels for components and a well-defined board outline for precise cutting and assembly.

Key Point: PCB milling is a less forgiving process than professional industrial fabrication, requiring meticulous design for success.



Gerber Generation & Final Outputs

The culmination of your design work is the generation of fabrication files.

KiCad exports industry-standard **Gerber files** for copper layers, soldermask, silkscreen, and board outline. It also generates **drill files** (Excellon format) for all component holes and vias. These files are the language spoken by **CAM software, PCB mills, and professional manufacturers**.

- **Critical Rule:** Always inspect your generated Gerber files using a Gerber viewer before sending them for fabrication. This catches many errors!



Key Takeaways

Complete Workflow

KiCad supports the entire PCB design journey.

Schematic First

A clean schematic is the foundation of a good PCB.

Fabrication Ready

Design rules and proper file prep ensure manufacturing success.

Final Thought: A PCB is a physical object – design it like one.