
My robot


Robot's information and update

Here, you'll find details about your robot and NiryoStudio. Moreover, you can trigger a reboot of the robot or the motors in case of any glitches.




If needed , you can have access to the **Robot logs** from this tab





Robot Logs
• [23/02/2024 16:16:52] Command has been successfully processed
• [23/02/2024 16:16:52] Commander Action Serv - Goal has been set as succeeded
• [23/02/2024 16:16:52] Execution completed: SUCCEEDED
• [23/02/2024 16:16:52] Controller 'niryo_robot_follow_joint_trajectory_controller' successfully finished
• [23/02/2024 16:16:52] Completed trajectory execution with status SUCCEEDED ...
• [23/02/2024 16:16:51] Execution request received
• [23/02/2024 16:16:51] Arm commander - Send MoveIt trajectory to controller.
• [23/02/2024 16:16:51] SimpleSetup: Path simplification took 0.009221 seconds and changed from 4 to 2 states
• [23/02/2024 16:16:51] Solution found in 0.015980 seconds
• [23/02/2024 16:16:51] arm/arm: Created 5 states (2 start + 3 goal)
• [23/02/2024 16:16:51] arm/arm: Starting planning with 1 states already in datastructure
• [23/02/2024 16:16:51] Planner configuration 'arm' will use planner 'geometric::RRTConnect'. Additional configuration parameters will be set when the planner is constructed.
• [23/02/2024 16:16:51] Planning request received for MoveGroup action. Forwarding to planning pipeline.
• [23/02/2024 16:16:51] Commander Action Serv - Goal has been accepted
• [23/02/2024 16:16:51] Commander Action Serv - Received goal. Check if can be executed
• [23/02/2024 16:16:51] Command has been successfully processed
• [23/02/2024 16:16:50] Completed trajectory execution with status SUCCEEDED ...
• [23/02/2024 16:16:50] Execution completed: SUCCEEDED
Download
Clear

NiryoStudio Update

If a new version for NiryoStudio is available , you will see the update window where you can perform the update.



Robot stack Update



The stack inside the robots can be updated through NiryoStudio in only a few steps.

First, your robot must have an access to internet, so you have to connect it to an ethernet or a Wi-fi network that provides internet.

When your robot is properly configured, at the next boot of the robot, it will check if an update is available. A pop-up will then be displayed at each following connection from Niryo Studio with the robot to inform you that an update is available for your robot.

You then only have to click on the update button of the pop-up or the update button in the information panel.

> Ned2 will reboot itself at the end of the process (in case of update success) so it's recommended **not** to do any other operation with Ned2 before starting an update.


> Update time is heavily impacted by the internet speed of your connection so if you connect to a wi-fi network, be sure that the raspberry is not too far away from the wi-fi modem.

In case the update failed, it could be a faulty connection, try to do the update once more and if you still encounter a problem, please contact us.

Settings

The settings is where you can change the Robot connection settings and the robot settings as the speed and the volume.

You can also change the demo program which is started from the button on the base of the Ned by your custom program.



Made with Docsie.io