


+ARDUINO+APA102





UART to USB (i.e. CP2102 or FT232R - FTDI)



APA102 Strip

pcbreflux