8. PCB LAYOUT

U10001 : Earjack detector
- Can't detect Ear jack, Ear Mic

U1001 : APT/ET PAM
- no TX POWER

U11004 : Hall IC
- no magnetic regonize

U3000 : MSM8974
U5003 : Emmc memory
- no booting, Reset etc

U8002 : External charger IC
- no charging

U1008 : BC10 PAM BC10
- no Tx Power

U1002 : BC17 PAM BC10
- no Tx Power

U6002 : PMIC PM8974
- no power on,
- no booting,
- no charging

U11002 : Proximity/Ambient
- no ALC

U10000 : WCD9320 Audio codec
- no Sound

U12001 : Slimport
- no HDMI signal

U9000 : LCD Backlight booster
- no display backlight

LG-D821_MAIN_EAX65371701_1.0_TOP