



Quick User Guide

Daily monitoring, billing and first-response troubleshooting • Version 2.2.1

Every day	What to confirm
Open	Main PC: http://localhost:5080 • LAN client: http://MAIN-PC-IP:5080
Dashboard	Meters online, alarms, recent timestamps, correct Grid/Generator source
Meter	View meter → Per Day / Per Month / Per Year; hover bars for usage/cost
Invoice	Published invoices → search → View / PDF → verify → deliver
Backup	Confirm a recent protected backup exists

Add a new meter — correct order

- 1. Settings → Shops: create the customer/shop.
- 2. Settings → Controller setup: add RTU COM or TCP gateway and test.
- 3. Add meter: identity + shop + Grid/Generator/Water + register/data type/word order/scale.
- 4. Test: compare Watch Dog with the physical meter, then activate/commission.
- 5. Operations: select meter, tariff/currency, publication day 1–7 and due days; Save all settings.

Never guess Use the commissioned meter/gateway register information. A wrong register, word order or scale can produce a believable but incorrect bill.

No invoice on the selected day?

- Confirm Watch Dog was running and the PC was awake.
- Confirm the tariff and publication schedule were saved for that meter.
- Confirm readings exist around the start and end of the previous completed month.
- Check Published invoices and the Audit trail; then record evidence before changing settings.

No communication?

- RTU: Windows COM port, RS-485 polarity/wiring, baud, parity, data bits, stop bits and slave address.
- TCP: controller/gateway IP, TCP port, route, unit/slave address and one reachable LAN.
- Check the last-reading timestamp and compare the physical meter value.

Escalation note

Record meter/controller name, exact time, status, recent change and screenshot. Do not send passwords or secrets.