
Firmware Update Manual

NOTE: Only follow this guide if your UR robot's software is < V. 3.3! - If V.3.3 or above use URcap to update.

Follow these steps to firmware update the Gripper. Ensure that the file "FW_update_X_X_X.script" is accessible from the robot e.g. via USB\ON\Technical scrips\FW_update_X_X_X.scripts

- 1. Ensure that the Gripper is properly connected to the robot tool connector and then power ON the robot.
- 2. Select Empty Program
- 3. Insert a Script Code


4. Go to the **command tap.**In the **dropdown menu** chose **file**



5. Click **Edit**

6. Click Select File


7. Chose **FW_update_X_X_X.script**. Click **Open**



8. Click SAVE & EXIT



10. Click Continue



12. When done, Click **Continue**

You are about to update the firmware of the RG2 gripper. The LEO on the RG2 will flash red, during the operation. Please do not use the robot before the update is complete. The update is complete in approximately 24 minutes after continuing.

Stop Program Continue

