
CHANGING PHYSICAL PARAMETERS WISELY

Viscosity, density, speed, size and stiffness: what each one does, how to estimate the stiffnesses, and what else to change with them



Laura A. Miller

Department of Mathematics, University of Arizona

Using IB Software • Part III • Chapter 8a

Claude (Anthropic) was used to organize, combine, and format more than twelve years (2013–2026) of the instructor's tutorial notes from courses and workshops at several universities.

LEARNING GOALS

By the end of this chapter you should be able to:

1. find every physical parameter of a simulation: the ones at the top of the input file, the ones baked into the structure files by the generator, and the ones hidden in the boundary blocks and in `main.cpp`;
2. say what changes when you change one of them (viscosity, density, speed, size, stiffness), and what else must change with it (the time step, the structure spacing, the run length);
3. estimate a spring, target or beam stiffness from the forces in the flow, and a damping coefficient, and say how rough those estimates are;
4. read the Reynolds number of an example from its input file and know why the method is easiest near $\mathrm{Re} \approx 1$;
5. change a parameter in an example, run a sweep, and recognize the mistakes that make a changed run meaningless.

> This chapter is the practical half of the old “Changing physical parameters wisely” lecture; the dimensionless analysis that justifies the estimates is chapter 8b. The two were one lecture in 2015 and are split here as the 2017 course split them.

HOW THIS CHAPTER WAS CHECKED

- The parameter values quoted are read from the input files, generators and READMEs of the 13 examples in this series (IB/01–08, IBFE/01–12), as shipped on the `master-tutorial` branch.
- The estimate formulas of the 2015–2018 slides are re-derived with their units on slides 20–23; where a 2D and a 3D version were mixed up in the old slides, both are given and the mix-up is named.
- The viscosity and stiffness figures are new runs of IB/01 and IB/03 with IBAMR 0.19.0 (scripts in the references), analysed from the `hier_data` position files with a short Python script that chapter 11 explains.
- The “what can go wrong” entries that are not from the course notes were produced on purpose and the symptoms are described from the runs.

> Slide numbers refer to this deck; chapter numbers (5, 6, 7, 8b, 9a, 10, 11, 16) to the other chapters of Part III.

WHERE THE PARAMETERS LIVE

Place	What is there	To change it
the top of `input2d`/`input3d`	`L`, `MU`, `RHO`, the speed (`V`, `U_FLOW`), sometimes `Re`; the grid (`N`, `MAX_LEVELS`), `DT`, `END_TIME`; the IBFE material constants (`SHEAR_MODULUS`, `KAPPA_S`)	edit the line; no rebuild
the `VelocityBcCoefs` blocks	the boundary speeds and profiles, as block constants (chapter 7)	edit the block; no rebuild
the generator (`generate_mesh2d.m`/`.py`)	the structure's size, point spacing Δs and the stiffnesses K, EI, κ, which it writes into the files divided by Δs (chapter 6)	edit, re-run the generator, new structure files
the structure files themselves	the per-element stiffnesses and rest lengths	regenerate (or the `uniform_*` keys of chapter 6)
`main.cpp`	occasionally a hard-coded constant: a target-point velocity, a tether law, an IBFE stress law (chapters 9a, 15)	edit and rebuild

The examples in this series were edited so that each physical quantity is set in *one* place: the stream speed is `V` at the top of IB/03's input (the course version had `0.1` written into four boundary lines), the stiffnesses are variables at the top of the generators, and IB/08's viscosity can be set from a Reynolds number (slide 28).

THE PHYSICAL PARAMETERS AT THE TOP OF THE INPUT FILE

From the 2013–2018 slides: “The physical parameters are given at the top of `input2d`. The immersed boundary works best when all terms are balanced ($\mathrm{Re} = 1$). Things get harder for $\mathrm{Re} < 0.001$ or $\mathrm{Re} > 1000$. Make sure your choices make sense: imagine what this thing would be in reality. You will likely need to change spring and beam stiffnesses. Think about how the forces are changing as you change parameters.”

```
// physical parameters
L = 1.0         // length of the computational (
  fluid) domain (m)
MU = 1.0e-1     // fluid dynamic viscosity (N s /
  m^2)
RHO = 1000      // fluid mass density (kg / m^3)
```

Three numbers, and they set everything about the fluid:

- `RHO`, the density ρ: inertia, and the scale of the pressure, ρU^2;
- `MU`, the dynamic viscosity μ: the viscous stress $\mu U/L$ and the viscous time $\rho L^2/\mu$;
- `L`, the box size: with `N` it fixes Δx (chapter 7), and through the generator the point spacing.

The 2013 slide’s `MU = 1.0e-1` is water-like for a decimetre-scale body at 0.1 m/s; the examples in this series use $\mu = 100$ (IB/01, 02, 04, 06, 07), 4 (IB/03), 40 (IB/08) and 0.01 with $\rho = 1$ (the IBFE set): slide 9.

“IMAGINE WHAT THIS THING WOULD BE IN REALITY”: UNITS

IBAMR has no units. Whatever system the input file uses is the system of the results, and the only check is yours.

- The IB examples are in SI: a 1 m box, water’s density 1000 kg/m^3, a viscosity of 4 to 100 N s/m^2 (water is 0.001: these are syrup-to-honey fluids, chosen so that a decimetre-scale structure at 0.1 m/s has Re of order 1, slide 11), speeds of 0.1 m/s, times in seconds.
- The IBFE examples are dimensionless: $\rho = 1$, $\mu = 0.01$, a box of side 2 or 16, speeds of 0.1 to 1. Their μ is $1/\mathrm{Re}$ for a unit speed and a unit length; IBFE/10 writes it so (`MU = 1.0/Re`).
- A stiffness copied from one set into the other is meaningless: $K = 2000$ in SI for a rubber band in syrup is not $K = 2000$ in a $\rho = 1$ world.

> The test: write the problem down in words with units. “A 20 cm rubber band in a fluid a hundred thousand times more viscous than water, relaxing from a 20% stretch in about a second.” If you cannot, the parameters are not yet chosen; if you can, the Reynolds number and the stiffness estimates follow (slides 11, 20).

Chapter 8b does the same with dimensionless groups, so that one run stands for every physical case with the same Re, k' and St.

REMINDER FROM CHAPTER 7: THE DOMAIN, THE GRID AND THE TIME STEP

The 2013 and 2017 lectures opened with the domain and grid slides before the parameters; they are chapter 7 here, and this slide is the reminder.

```
CartesianGeometry {
   domain_boxes = [ (0,0) , (N - 1,N - 1) ]
   x_lo = -0.5*L, -0.5*L   // lower end of computational domain.
   x_up =  0.5*L,  0.5*L   // upper end of computational domain.
   periodic_dimension = 1, 1   // "overrides everything"
}
MAX_LEVELS = 4            // "4 is a good default"
REF_RATIO  = 4            // "a rather strict refinement ratio"
N = 8
NFINEST = (REF_RATIO^(MAX_LEVELS - 1))*N   // 512
DX = (1.0*L)/NFINEST
DT = 3.125e-2/NFINEST     // the 2013 guess; see chapter 7
```

- "As you start changing domain size, spatial step size, etc., you need to take care that everything still makes sense" (2013). Change `x_lo`/`x_up` and `domain_boxes` together; keep the cells square; coarsest counts ≥ 4.
- `L` and `N` set Δx, and the generators set the point spacing from the same N: change one and re-run the other (slide 27).
- The `DT` line is a CFL-type guess; the examples set it by hand from the stiffness (slide 26).

REMINDER FROM CHAPTER 7: OUTPUTS, END TIME, VORTICITY TAGGING

```
// visualization dump parameters
   viz_writer = "VisIt"
   viz_dump_interval = 4000            // steps, not a count; 0
  turns it off
   viz_dump_dirname = "viz_IB2d"
   visit_number_procs_per_file = 1
// hierarchy data dump parameters
   data_dump_interval = 1000           // steps
   data_dump_dirname = "hier_data_IB2d"   // the 2017 slide wrote
   _IB3d in a 2D file
IBStaggeredHierarchyIntegrator {       // 2013 name; now
  IBHierarchyIntegrator
   start_time = 0.0e0
   end_time   = 1.0e2                  // "another way to fill up
   the hard drive"
   grow_dt    = 1.1e0
   max_integrator_steps = 10000000
}
   using_vorticity_tagging = TRUE      // "too small tags the
  whole domain,
   vorticity_abs_thresh = 0.25         //  too big misses the
  wake"
```

Why they matter for *parameter* changes:

- the intervals are in steps: when a new stiffness forces a smaller `DT`, the same interval writes more frames per second of simulated time. The series' inputs compute the interval from `END_TIME` and `DT` (fifty frames per run) so this takes care of itself;
- `end_time` must cover the slowest process of the new run: a more viscous fluid relaxes more slowly (slide 14), a softer structure swings longer;
- a higher Reynolds number makes a longer wake: the vorticity threshold that followed the old wake may miss the new one.

The block name `IBStaggeredHierarchyIntegrator` is from the 2013 IBAMR; today the time integrator block is `IBHierarchyIntegrator` (or `IBExplicitHierarchyIntegrator`) and the fluid block `INSStaggeredHierarchyIntegrator` (chapter 3).

THE EXAMPLES' PARAMETERS: THE IB SET

example	μ	ρ	speed	structure stiffness (generator)	in the file	DT	END_TIME
IB/01 rubber band	100	1000	its own	$K = 2000$	$K/\Delta s = 2.04 \times 10^6$	10^{-4}	2
IB/02 pulsatile channel	100	1000	0–1 (pulse)	targets $\kappa = 10^4$; springs, beams 10^{-10}	$\kappa/\Delta s = 2.048 \times 10^6$	10^{-4}	2
IB/03 tethered leaf	4	1000	0.1	$K = 30$, $EI = 5 \times 10^{-3}$, $\kappa = 30$	3.06×10^4, 5.31×10^6, 3.06×10^4	10^{-4}	2
IB/04 moving cylinders	100	1000	prescribed path	targets κ written directly	4.096×10^6	2×10^{-5}	0.2
IB/06 growing springs	100	1000	its own	$K = 2000$, rest length grows	2.04×10^6	10^{-4}	0.5
IB/07 moving plates	100	1000	prescribed path	$K = 2000$, $EI = 5 \times 10^{-3}$, $\kappa = 2000$	2.04×10^6, 5.31×10^6, 2.04×10^6	10^{-4}	1
IB/08 glycocalyx (3D)	40	1000	lid 0.1	targets $\kappa = 5$	$\kappa/\Delta s = 3.19 \times 10^4$	10^{-5}	0.2

All boxes are 1 m (IB/02: 5 m; IB/08: $\frac{1}{8} \times \frac{1}{8} \times 1$ m), all finest grids 512 cells per metre (IB/04: 1024), all point spacings about $\Delta x/2$. The file values are the generator's stiffness divided by Δs (springs, targets) or Δs^3 (beams): chapter 6. "Its own" speed means nothing is imposed: the structure moves because it is stretched or because its rest lengths change.

THE EXAMPLES' PARAMETERS: THE IBFE SET

example	μ	ρ	speed	solid	DT	END_TIME
IBFE/01 tethered plate	0.01	1	tether 0.5	neo-Hookean, $\mu_s = 10$; tether $\kappa = 10^6$	10^{-3}	4
IBFE/05 gmsh triangle	0.01	1	tether 0.5	same material and tether	5×10^{-4}	4
IBFE/06 active tension	0.01	1	its own	$\mu_s = 10$ plus an active stress	10^{-3}	4
IBFE/08 plate hits circle	0.01	1	tether 0.25	$\mu_s = 10$ both parts; tether 10^6	5×10^{-4}	4
IBFE/10 flow tank (3D)	$1/\mathrm{Re} = 0.01$	1	stream 0.1	compressible neo-Hookean, $\nu = 0.3$; tether 10^5	10^{-4}	0.5
IBFE/12 advection–diffusion	0.01	1	tether 0.5	IBFE/01's plate; scalar diffusivity 10^{-6}	10^{-3}	4

Boxes of side 2 (IBFE/10: $32 \times 16 \times 16$), finest grids of 128 cells (IBFE/10: 256 per 16). The solid's stiffness is a material constant (the shear modulus μ_s, in units of pressure) rather than a spring constant per point, so it does not scale with Δs; what scales with the mesh is the tether penalty κ, a force per unit volume per unit displacement (chapter 15). The time steps are ten times those of the IB set because the fluid is a thousand times lighter: slide 26.

THE REYNOLDS NUMBER OF AN EXAMPLE

$\mathrm{Re} = \rho U L/\mu$: inertial over viscous forces. The number means nothing until U and L are named; the examples' READMEs name them.

example	U	L	Re
IB/03 leaf	the stream, 0.1 m/s	the leaf's length, 0.1 m	2.5
IB/08 glycocalyx	the shear flow at the fibre's height, $Vh/L = 0.0156$ m/s	the fibre's height, 0.156 m	0.061
IBFE/10 flow tank	the stream, 0.1	the plate's width, 2	20 (the input's `Re = 100` is for $U = L = 1$)
IB/01 rubber band	the band's own speed, about 0.02 m/s as it rounds up	its diameter, 0.2 m	about 0.04
IB/02 channel	the peak, 1 m/s	the channel width, 1 m	10 (and a Womersley number of 8.9, chapter 7)
IBFE/01 plate	the tether's speed, 0.5	the plate's length, 1	50

So the series runs from creeping flow (IB/01, IB/08) through $\mathrm{Re} \sim 1$ (IB/03) to the tens (IB/02, IBFE/01, IBFE/10): all within the band where the 2013 slide says the method is comfortable. None is above 1000. Chapter 8b has the dimensionless numbers that go with Re (Strouhal, Womersley, Péclet) and the biological ranges.

WHY THE METHOD IS EASIEST NEAR $\mathrm{Re} \approx 1$

The 2013 statement, “the immersed boundary works best when all terms are balanced ($\mathrm{Re} = 1$); things get harder for $\mathrm{Re} < 0.001$ or $\mathrm{Re} > 1000$”, is a rule of thumb. The reasons behind it:

- Low Re (creeping flow): nothing is wrong with the fluid solve (the viscous term is implicit), but the structure must be *stiff* relative to the viscous forces to hold its shape, and a stiff structure means a small time step (slide 26); the viscous time $\rho L^2/\mu$ is short, so transients die at once, but any motion you impose is resisted by large forces that the explicit coupling must survive. At $\mathrm{Re} \ll 10^{-3}$ one is better off with a Stokes solver and a different method.
- High Re: boundary layers of thickness $\delta \sim L/\sqrt{\mathrm{Re}}$ must be resolved by the grid, while the IB kernel smears the interface over about four cells (chapter 5); when δ falls below a few Δx the forces on the body are wrong. The wake carries vorticity far downstream (vorticity tagging, bigger boxes, chapter 7), and in 3D the flow becomes turbulent. Above $\mathrm{Re} \sim 1000$ the cost grows fast and the thin-interface assumption weakens.
- Near 1: viscous and inertial forces are comparable, both are resolved by the same grid, the structure forces are moderate, and the time step is set by the structure alone.


Biology spends most of its time in this comfortable band: small swimmers, cilia and flagella (low), larvae, jellyfish, insect wings (1–1000); chapter 8b’s chart.

CHANGE ONE PARAMETER, AND WHAT CHANGES WITH IT

You change	what changes in the physics	what you must change with it
μ (`MU`)	$\mathrm{Re} \propto 1/\mu$; the viscous time $\rho L^2/\mu$; viscous forces on the structure $\propto \mu$ (at low Re)	`END_TIME` (slower relaxation at high μ, slide 14); stiffnesses, if the structure must hold against the larger forces; `DT` only indirectly (slide 26)
ρ (`RHO`)	$\mathrm{Re} \propto \rho$; inertia; the pressure scale ρU^2; the added mass felt by the structure	the stiffnesses that were estimated from ρU^2; `DT`: the stable step of an explicit IB coupling scales with $\sqrt{\rho}$ (the IBFE set at $\rho = 1$ runs ten times the step of the IB set at 1000)
U (`V`, `U_FLOW`)	$\mathrm{Re} \propto U$; forces $\propto U^2$ ($\mathrm{Re} > 1$) or U ($\mathrm{Re} < 1$); the CFL number $U\Delta t/\Delta x$; the time to cross the box L/U	`DT` if the CFL limit is approached (rare for the IB set, slide 26); stiffnesses (slide 20); `END_TIME` (more or fewer cycles)
L or N	$\Delta x = L/N$; the point spacing $\Delta s \approx \Delta x/2$; the resolution of the structure	re-run the generator (slide 27); the file stiffnesses change with Δs automatically when you do; `DT` if Δx shrinks
a stiffness (K, EI, κ)	how far the structure deforms or strays from its target	`DT`: halve it when you multiply a stiffness by four (slide 26); nothing else

"Think about how the forces are changing as you change parameters" (2013): every row above is a force balance. The next slides show two rows in runs: viscosity on the rubber band, stiffness on the leaf.

VISCOSITY: THE RUBBER BAND AT $\mu = 100$, 10 AND 1



IB/01's band starts as an ellipse (0.12×0.10 m) and its springs pull it toward a circle of radius 0.1 m. Three runs differ only in `MU`:

- $\mu = 100$ (shipped): overdamped; the semi-axes creep together, within 2 mm of each other by $t = 0.24$ s, and never cross;
- $\mu = 10$: underdamped; the band overshoots (half-width down to 0.104 m at $t = 0.16$ s, taller than wide) and swings with a period of 0.37 s, each swing smaller than the last;
- $\mu = 1$: a deeper overshoot (0.101 m) and a period of 0.32 s, with little decay over the 2 s.

The spring constant is the same in all three; only the fluid's resistance changed. The curves are the band's half-width (solid) and half-height (dashed) from the `X.*` position files, written every 0.04 s.

IB/01 with IBAMR 0.19.0, `MU` = 100, 10, 1, everything else as shipped (`wsl/final/run_ch8a_ib01.sh`); semi-axes computed by `tools/ch8a_figures.py` from `hier_data_IB2d/X.*`.


WHY THE BAND SETTLES AT 0.1095 M, NOT AT ITS REST RADIUS

All three runs end on the same circle, of radius 0.1095 m, and none reaches the springs' rest radius of 0.1 m.

- The fluid inside the band is incompressible and the band is closed, so the enclosed area cannot change: the ellipse with semi-axes 0.12 and 0.10 m becomes the circle with the same area, $\pi\,(0.12 \times 0.10) = \pi\,(0.1095)^2$.
- The springs therefore stay stretched by 9.5%, and their tension is balanced by a pressure inside the band that is higher than outside: a tension of $K \times 0.095$ per unit depth over a radius of 0.1095 m gives, by Laplace's law, $\Delta p = T/R \approx 2000 \times 0.095/0.1095 \approx 1.7 \times 10^3$ N/m^2 at the end of every run.
- This is the IB method's volume conservation at work (chapter 5): a closed membrane in an incompressible fluid holds its area to the accuracy of the discrete divergence, which is why the three final radii agree to four digits (0.1095, 0.1095, 0.1096).

> Two checks fall out of this for any closed structure: the final size is set by the enclosed area, not by the rest lengths, and a steady pressure jump across the membrane of T/R should be visible in the `P` field in VisIt. If the band *did* shrink to its rest radius, fluid would be leaking through it (points too far apart, chapter 5).

VISCOSITY: THE BAND'S SHAPE AT THREE TIMES



Rows: $\mu = 100$, 10, 1; columns: three times during the run. The dashed circle is the final shape, the circle with the ellipse's area. At $\mu = 100$ the band is never far from an ellipse shrinking onto the circle; at $\mu = 10$ and 1 it passes through the circle at about $t = 0.12$ s and comes out the other side, taller than wide, then swings back.

Same runs; outlines drawn from `X.*` by `tools/ch8a_figures.py`.

WHAT THE VISCOSITY SWEEP SHOWS


Two time scales compete in the band:

- the elastic one: a ring of radius R with tension stiffness K (N/m per unit depth) moving the fluid it encloses, of mass $\sim \rho R^2$ per unit depth, has a time scale $\sqrt{\rho R^3/K} = \sqrt{1000 \times 0.0013/2000} \approx 0.026$ s, or 2π times that, 0.16 s, for a period. The measured swing is 0.32 s ($\mu = 1$) to 0.37 s ($\mu = 10$): the right order, with a factor of two from the added mass outside the band and the shape of the mode;
- the viscous one: momentum diffuses across the band in $\rho R^2/\mu$, which is 0.12 s at $\mu = 100$ (the fluid stops the band within a fraction of a period: overdamped), 1.2 s at $\mu = 10$ (a few decaying swings), 12 s at $\mu = 1$ (many swings with little decay, as the run shows).

> The rule in one line: viscosity does not change what the structure wants to do, only how fast the fluid lets it, and whether it overshoots. A run that "does nothing" after a viscosity increase has not been run long enough: scale `END_TIME` with μ. A run that oscillates after a viscosity decrease is not unstable; it is underdamped. Instability looks different (chapter 16: growth without bound, then `Time step size change encountered`).

The same three runs are IB/01's job-array sweep (`params.txt`: 100, 10, 1; chapter 3), so the figure can be reproduced on Puma with one `sbatch`.

STIFFNESS: THE LEAF WITH THE BEAM STIFFNESS DIVIDED AND MULTIPLIED BY TEN



IB/03's leaf in the same stream ($\mathrm{Re} = 2.5$) with three bending stiffnesses: $EI = 5 \times 10^{-4}$, the shipped 5×10^{-3}, and 5×10^{-2}. The structure files were regenerated with `kappa_beam` changed in `generate_mesh2d.py`; nothing else was touched except, for the stiff case, `DT` (next slide).

- left: the leaf's shape at $t = 2$ s for the three runs, with the starting line dashed;
- right: the downstream displacement of the top tip against time.

The shipped leaf bends most at $t \approx 0.7$ s (1.4 cm) and relaxes to 0.9 cm as the flow around it settles; the ten-times-softer leaf folds over, its tips 4 cm downstream and pointing with the flow; the ten-times-stiffer one moves about a millimetre.

IB/03 with IBAMR 0.19.0 (`wsl/final/run_ch8a_ib03.sh`, `run_ch8a_ib03b.sh`); shapes and tip positions from `X.*` by `tools/ch8a_figures.py`. The shipped run is the one of chapters 6 and 7.

WHAT THE STIFFNESS SWEEP SHOWS, AND WHAT IT COST

- The displacement is not proportional to $1/EI$: a tenth of the stiffness gave about three times the tip displacement at $t = 2$ s (4.0 cm against 0.9), not ten. The bent leaf presents less area to the stream and lets it flow past, so the softer it is, the less force it feels. That is the fluid–structure coupling at work, and the reason the estimates of the next slides are only estimates: they assume the load of the undeformed shape.
- The shipped leaf's overshoot at $t \approx 0.7$ s is the stream's start-up: the tanh ramp (chapter 7) is still accelerating the fluid, and the leaf is pushed furthest while the flow around it is still developing; it springs back as the wake forms.
- The stiff leaf did not run at the shipped time step. With `kappa_beam` ten times larger and `DT = 1e-4` unchanged, the run stopped at step 15 ($t = 0.0015$ s) with `IBHierarchyIntegrator::preprocessIntegrateHierarchy(): Time step size change encountered`: the explicit coupling could not take the stiffer beam's forces at that step, the integrator cut the step, and `error_on_dt_change` turned the cut into an abort (chapter 5). With `DT = 2.5e-5`, a quarter, it ran to the end, four times slower.

> So the sweep demonstrates both rows of slide 13 for a stiffness: the deformation changes less than linearly, and the time step must follow the stiffness, by roughly $1/\sqrt{\text{factor}}$ (slide 26).

ESTIMATING k_{spring} (AND A TARGET STIFFNESS)

The 2017 recipe, kept word for word: "By estimating the force acting on the boundary (F_b) and the desired displacement (x_s), one can make an educated guess for k_{spring}. The idea is to set $k_{\text{spring}} = F_b/x_s$. Choose x_s to be the maximum desired displacement from the target point or the maximum amount of displacement from a resting length. The estimate for F_b will depend on Re and dimension (dim). For the characteristic velocity, U, I recommend using $U_{\max}$."

$$F_b \sim \tfrac{1}{2}\,\rho\,\Delta x^{\,\mathrm{dim}-1}\,U^2 \quad (\mathrm{Re} > 1), \qquad F_b \sim \mu\,U\,\Delta x^{\,\mathrm{dim}-2} \quad (\mathrm{Re} < 1).$$

"Warning to user: these are really rough estimates."

- F_b is the force on one point, which represents a piece of boundary Δx across (in 2D, per unit depth). At $\mathrm{Re} > 1$ it is the dynamic pressure $\frac{1}{2}\rho U^2$ on that piece's area, $\Delta x^{\mathrm{dim}-1}$. At $\mathrm{Re} < 1$ it is a Stokes drag, viscosity times speed times a length: $\mu U \Delta x$ in 3D, μU per unit depth in 2D.
- k here is the stiffness in the file, the one that multiplies the displacement of that point: for a target point $\kappa/\Delta s$, for a spring $K/\Delta s$ (chapter 6).

> Correction. The 2017 slide wrote the viscous case as $F_b \sim \mu\,\Delta x\,U$ for both dimensions. That is the 3D form; in 2D the Δx drops out (units: μU is already a force per unit depth), hence the $\Delta x^{\mathrm{dim}-2}$ above.

THE ESTIMATE APPLIED TO THE EXAMPLES

example (points)	F_b on one point	x_s	estimate	in the file
IB/03 springs ($\mathrm{Re} = 2.5$, 2D)	$\frac{1}{2}\rho\Delta x U^2 = \frac{1}{2}\cdot 1000 \cdot \frac{1}{512}\cdot 0.01 = 9.8\times 10^{-3}$	10% of Δs, 10^{-4} m	$\approx 10^2$	3.06×10^4 (300×)
IB/02 targets ($\mathrm{Re} = 10$, 2D)	$\frac{1}{2}\cdot 1000 \cdot \frac{5}{512}\cdot 1 = 4.9$	$0.1\,\Delta x = 10^{-3}$ m	$\approx 5\times 10^3$	2.05×10^6 (400×)
IB/08 targets ($\mathrm{Re} = 0.06$, 3D)	$\mu U\Delta x = 40\cdot 0.0156\cdot \frac{1}{512} = 1.2\times 10^{-3}$	$0.1\,\Delta x = 2\times 10^{-4}$ m	≈ 6	3.19×10^4 (5000×)
IB/04 targets ($\mathrm{Re} \ll 1$, 2D)	$\mu U = 100\cdot U_{\mathrm{cyl}}$; with $U_{\mathrm{cyl}} \sim 0.1$: 10	$0.1\,\Delta x = 10^{-4}$ m	$\approx 10^5$	4.10×10^6 (40×)

Every example is far stiffer than the estimate, by a factor of 40 to 5000. That is deliberate:

- the estimate is the stiffness at which the point moves by x_s under the *mean* load; a wall that must stay put against a pulsing flow, or a fibre that must be inextensible, wants ten to a hundred times more;
- the price is the time step: the file stiffness sets the stable `DT` (slide 26), which is why IB/04, the stiffest, runs at 2×10^{-5} s.

So use the estimate as a floor, multiply by 10–100 for a wall or a tether, and then pay for it in `DT`. If the structure still stretches or strays too far, the stiffness goes up again; if the run becomes unstable, `DT` goes down.

ESTIMATING k_{beam}

The 2015/2017 recipe: "By using the dimensionless beam stiffness k'_{beam}, one can make an educated guess for k_{beam}. Setting $k'_{\text{beam}} = 10$ typically results in a little bit of bending (maybe 2–10 degrees). U is the characteristic velocity (try $U_{\max}$) and L is the characteristic length. I would use the length of the boundary."

$$\text{2D, } \mathrm{Re} > 1: \quad k'_{\text{beam}} = \frac{k_{\text{beam}}}{\rho U^2 L^3}; \qquad \text{2D, } \mathrm{Re} < 1: \quad k'_{\text{beam}} = \frac{k_{\text{beam}}}{\mu U L^2}; \qquad \text{3D:} \quad k'_{\text{beam}} = \frac{EI}{\rho U^2 L^4}.$$

- k_{beam} is the flexural rigidity, EI in 3D (N m^2) and EI per unit depth in 2D (N m): the generator's `kappa_beam`, not the file value, which is $k_{\text{beam}}/\Delta s^3$ (chapter 6).
- The denominators are the fluid's bending moment scale: a pressure ρU^2 (or a viscous stress $\mu U/L$) over a length L, times a lever arm L, times the width (L again in 3D, unit depth in 2D).

> Correction. The 2017 slide wrote $k'_{\text{beam}} = k_{\text{beam}}/(\rho U^2 L^4)$ under the heading "in 2D". L^4 is the 3D form (the 2015 and 2020 slides have L^3 for 2D); with L^4 the number is not dimensionless in 2D and is off by a factor L, which for a decimetre-scale body is a factor of ten.

THE BEAM ESTIMATE APPLIED TO THE LEAF, AND WHAT THE SWEEP SAYS

IB/03: $k_{\mathrm{beam}} = 5 \times 10^{-3}$ N m, $\rho = 1000$, $U = 0.1$ m/s, $L = 0.1$ m (the leaf's length):

$$k'_{\mathrm{beam}} = \frac{5 \times 10^{-3}}{1000 \times 0.01 \times 10^{-3}} = 0.5.$$

- So the shipped leaf is twenty times *softer* than the "$k' = 10$, a few degrees" setting, and it bends accordingly: the top tip is 0.9 to 1.4 cm downstream on a leaf whose half-length is 5 cm, a chord angle of 10–16 degrees from the vertical (slide 18).
- The ten-times-stiffer run ($k' = 5$) bends about a degree, near the recipe's "2–10 degrees at $k' = 10$" for a stiffness twice the recipe's; the ten-times-softer run ($k' = 0.05$) folds over.
- At $\mathrm{Re} = 2.5$ the viscous form gives $k_{\mathrm{beam}}/(\mu U L^2) = 5 \times 10^{-3}/(4 \times 0.1 \times 0.01) = 1.25$: the same order, as it should be when Re is near 1.

How to use it: decide how much bending you want (a stiff fin: $k' \sim 10$; a flapping flag or a leaf in the wind: $k' \sim 0.1$–1; a filament that folds: $k' \ll 0.1$), compute $k_{\mathrm{beam}} = k' \rho U^2 L^3$ (2D), put it in the generator, and let chapter 10 refine it with the beam theory (the bending length and the Cauchy number). "Warning to user: these are really rough estimates."

THE STIFFNESSES AND THEIR UNITS, IN ONE PLACE

element	generator constant	file value	force law (chapter 6)
spring	K: tension per unit strain; N (3D) or N/m (2D, per depth)	$K/\Delta s$	$(K/\Delta s)\,(\lvert\mathbf{X}_j - \mathbf{X}_i\rvert - r)$ along the spring
target point	κ: tether stiffness per unit length of boundary	$\kappa/\Delta s$	$(\kappa/\Delta s)\,(\mathbf{X}_{\text{target}} - \mathbf{X}) - \eta\,\mathbf{U}$
beam	EI: flexural rigidity; N m^2 (3D), N m (2D)	$EI/\Delta s^3$	$-(EI/\Delta s^3)\,(\mathbf{X}_{i-1} - 2\mathbf{X}_i + \mathbf{X}_{i+1})$ on the triple
IBFE tether	κ_s (`KAPPA_S`): force per unit volume per unit displacement	as is	$\kappa_s\,(\mathbf{X}_0 - \mathbf{X})$ per unit reference volume
IBFE material	μ_s (`SHEAR_MODULUS`): a pressure	as is	the stress law of the example (chapter 15)

Two consequences for parameter changes:

- the file values depend on Δs: refine the grid and the generator must be re-run so that $K/\Delta s$ and $EI/\Delta s^3$ are recomputed; copying the old files onto a finer grid makes the structure softer by the ratio of spacings (springs) or its cube (beams);
- the estimates of slides 20–23 are for the file value (spring, target) and for the generator constant (beam), because the point force uses the file value and the bending moment uses EI. Keep the two straight; the generators' comments say which is which.

ESTIMATING DAMPING

The 2017 recipe: “The goal is to make the springs close to critically damped. This means setting the damping coefficient $c = 2\sqrt{k_{\text{spring}}\, m}$. The hard part is estimating m. Recall the boundary is massless, but there is the added mass of the fluid. My recommendation is to try setting $m = \rho\, \Delta x^{\dim}$. Warning to user: these are really rough estimates.”

- Where damping is available: IBAMR’s target points take an optional damping coefficient η as a third column of the `.target` file (or `uniform_target_damping`), which adds $-\eta\, \mathbf{U}$ to the tether force (chapter 6). Plain springs and beams have none; a damped spring is a custom force (chapter 9b). IB2d has damped springs as a file type (chapter 4a).
- $m = \rho\, \Delta x^{\dim}$ is the mass of the fluid in one cell: the fluid that the point drags with it, which is what resists a change of its velocity.
- Worked number, IB/02’s walls: $k = 2.05 \times 10^{6}$ (file), $m = 1000 \times (5/512)^{2} = 0.095$ kg per unit depth, so $c = 2\sqrt{2.05 \times 10^{6} \times 0.095} \approx 880$. The shipped file has $\eta = 0$ and the walls still hold, because the stiff tether and the viscous fluid already damp the motion; add damping when a target point rings.

> Too much damping is as bad as too little: a heavily damped target point lags its target and the structure follows the prescribed motion late (chapter 9a’s moving targets). Critical damping is the aim; test with a short run and a plot of the point against its target.

STIFFNESS AND THE TIME STEP

Chapter 5's rule: with an explicit IB coupling, a point of (added) mass $m \sim \rho \Delta x^{\dim}$ on a spring of file stiffness k oscillates at $\omega = \sqrt{k/m}$, and the step must resolve it, $\Delta t \lesssim 2/\omega$ and in practice a fraction of that:

$$\Delta t \lesssim \frac{c}{\omega} = c\, \Delta x^{\dim/2} \sqrt{\frac{\rho}{k}}, \qquad c \text{ of order } 0.1\text{–}1.$$

- Four times the stiffness, half the step. Four times finer grid: k (as $K/\Delta s$) doubles and $\Delta x^{\dim/2}$ halves in 2D, so the step drops by $2\sqrt{2}$.
- A thousandth of the density (the IBFE set): $\sqrt{1000} \approx 30$ times the step, before the material's own stiffness is counted; the IBFE examples run at 10^{-3} against the IB set's 10^{-4}.
- The measured limits (chapter 5 and the READMEs): IB/01 at $k = 2.04 \times 10^6$ is fine from 10^{-6} to 5×10^{-4} and aborts at 10^{-3} (`Time step size change encountered`); IB/04 at 4.1×10^6 runs at 2×10^{-5}; IB/08 at 3.2×10^4 but in 3D at 10^{-5}.

> The CFL limit is rarely the one that binds in these examples: IB/03 runs at a CFL number of 0.005 (chapter 7). The stiffness is. So when a run blows up after a parameter change, look at the stiffness first, then at the speed. And keep `CFL_MAX` as the safety net for the cases where the speed does bind.

CHANGING THE SIZE OR THE RESOLUTION: RE-RUN THE GENERATOR

```
# IB/03 generate_mesh2d.py (top)
L = 1.0            # length of computational domain (m)
N = 512            # finest-level cells across the domain
dx = L / N
plate_length = 0.1
npts = math.ceil(2 * (plate_length / L) * N)    # 103: spacing ~ dx/2
ds = plate_length / (npts - 1)
kappa_spring = 3.0e1       # K; file stores K/ds
kappa_beam = 5.0e-3        # EI; file stores EI/ds^3
kappa_target = kappa_spring
```

The generators take `L` and `N` and compute Δs from them. The input file has its own `L` and `N`. Nothing links the two: you keep them equal.

What goes wrong when they are not:

- finer grid, old files: points Δx or more apart; the fluid leaks between them (chapter 5's spacing rule), and the file stiffnesses are those of the coarser Δs;
- coarser grid, old files: points crowded within one cell; the forces pile up, the structure is effectively stiffer, and the time step may fail;
- bigger box, same `N`: Δx grows and the structure, still generated for the old Δx, is suddenly dense; the Reynolds number and the physics are unchanged but the resolution of the structure is not.

The procedure: change `L` or `N` in *both* files, re-run the generator, check the point count in the log (chapter 6), check $\Delta s \approx \Delta x/2$, then run.

SETTING THE VISCOSITY FROM A REYNOLDS NUMBER

```
// IB/08 input3d (2014 option, commented out as shipped)
L = 1.0
RHO = 1000
V = 0.1
// RE = 1.0                          // target Reynolds number
// MU = RHO*(V*H_GLYCO/L)*H_GLYCO/RE   // viscosity from it
MU = 40                              // as shipped
```

```
// IBFE/10 input3d
Re = 100.0
MU = 1.0/Re          // rho = 1, U = 1, L = 1
RHO = 1.0
```

The cleanest way to change the physics is to name the dimensionless target and derive the dimensional parameter from it in the input file's own arithmetic:

- IB/08's 2014 version set `MU` from `RE` with the fibre's height and the shear speed at that height; the README has the numbers ($\mathrm{Re} = 1$ gives $\mu = 2.44$);
- IBFE/10 writes `MU = 1/Re`; the README notes that this Re is for unit speed and length, and that with the actual $U = 0.1$ and $D = 2$ the run is at $\mathrm{Re} = 20$.

The same trick works for a stiffness: `K = KPRIME*RHO*U*U*L` at the top of the generator. Then a sweep is a sweep in k' and Re, which is what chapter 8b says to report.

A PROCEDURE FOR CHANGING A PARAMETER

1. Say what you want in dimensionless terms: the new Re, the new k', the new Strouhal or Womersley number (chapter 8b). Then compute the dimensional value from it, in the input file or the generator, so that the arithmetic is on record.
2. Change one thing. Two changes at once cannot be told apart in the result.
3. Follow the row of slide 13: regenerate if L or N changed; re-estimate the stiffness if U, ρ or μ changed by more than a factor of a few; re-estimate `DT` if a stiffness or ρ changed; rescale `END_TIME` with the slowest time scale.
4. Run two steps and read the log (chapter 7's checklist), then a short run (a fraction of `END_TIME`) and look at it in VisIt next to the old run.
5. Compare one number between old and new: a tip position, a force from the `integral{F}` line, a period. The READMEs record such numbers for every example so that the shipped run is the baseline.
6. Write it down: a line in a notebook or in `params.txt` with the parameter, the value, `DT`, and the one number. Sweeps are made of such lines.

SWEEPS: ONE PARAMETER, MANY RUNS

```
# IB/01 params.txt: one MU per line
100
10
1
```

```
# job_array.slurm (chapter 3), the core of it
MU=$(sed -n "${SLURM_ARRAY_TASK_ID}p" params.
  txt)
mkdir -p run_$SLURM_ARRAY_TASK_ID
cp rubber_band_512.* run_$SLURM_ARRAY_TASK_ID
  /
sed "s/^MU *=.*/MU = $MU/" input2d >
  run_$SLURM_ARRAY_TASK_ID/input2d
cd run_$SLURM_ARRAY_TASK_ID && mpirun ../
  build/main2d input2d
```

The viscosity sweep of slide 14 is IB/01's job array: one line of `params.txt` per task, a folder per run, the input edited by `sed`. The pattern extends to any top-level constant.

- A stiffness sweep needs the generator in the loop: edit `kappa_*` in a copy of the generator, run it in the run folder, then run (that is what `run_ch8a_ib03.sh` does, with `sed` on the Python file).
- A resolution sweep changes `N` in both files and the generator, and `DT` with it (chapter 5's convergence study, chapter 16).
- Keep `DT` in the sweep file when the stiffness changes; a sweep that fails at the stiff end is a sweep with the wrong `DT`, not a physical result.

On a laptop, run two or three at a time with four processes each (chapter 3); on Puma, the array runs them all.

WHAT CAN GO WRONG

The change	What happens, and the fix
units mixed: an SI stiffness in a $\rho = 1$ input, or centimetres in the generator and metres in the input	nothing fails; the Reynolds number and k' are not what you think. Compute both before running (slide 6)
`L` or `N` changed in the input only	the structure is too sparse or too dense for the grid; leaks or a stiff, jittery boundary (slide 27). Re-run the generator
a stiffness raised ten times, `DT` unchanged	the run aborts within the first steps with `Time step size change encountered`, or the structure explodes (chapter 16). Halve `DT` per factor four (slide 26)
`MU` raised a hundred times	the run "does nothing": the structure relaxes a hundred times more slowly and `END_TIME` ends before it moves (slide 17)
`MU` lowered a hundred times	the structure overshoots and swings; this is physics, not instability. Also Re rose a hundredfold: check the boundary layer against Δx (slide 12)
`RHO` set to 1 in an IB input with stiffnesses chosen for 1000	Re drops a thousandfold, the pressure scale with it; the structure is now absurdly stiff for the forces and `DT` could be thirty times larger. Re-estimate everything (slide 13)
a speed raised ten times	forces up a hundredfold ($\mathrm{Re} > 1$): a structure that held before now stretches or strays; the stiffness estimate must be redone, and `DT` may hit the CFL limit
a zero stiffness in a file	the element does nothing, and the log says so only as a warning (chapter 6: `zero stiffness`); a structure with $K = 0$ springs is a cloud of points

HOMEWORK

From the 2015–2018 courses and the READMEs (Appendix C collects the full set):

1. IB/01: run the viscosity sweep (`MU` = 100, 10, 1), plot the band's half-width and half-height against time, and measure the swing period at `MU = 1`. Then find the viscosity at which the band is critically damped (no overshoot, fastest approach).
2. IB/03: estimate the spring and beam stiffness of the leaf from slides 20 and 22, compare with the generator's values, and run the leaf at $k'_{\mathrm{beam}} = 10$. Report the tip angle.
3. IB/03: double `V`. Before running, write down what changes (Re, forces, `DT`, `END_TIME`); after running, say which of your predictions held.
4. "Imagine what this thing would be in reality": pick one example and write its parameters as a real object with units (a jellyfish, a leaf in a stream, a glycocalyx fibre); then compute its Reynolds number and say whether the example's choice is realistic.

> What to hand in: the edited lines (input file or generator), the one number you compared (slide 29), and one picture per run. For item 1, the plot; for item 2, the arithmetic.

Extension: IB/08 with `RE = 1` through the viscosity option, compared with the shipped $\mu = 40$ run (the README has the force at $t = 0.2$ s for the shipped run).

RULES OF THUMB

- Write the problem in words with units before you type a number; then compute Re and k'.
- Re near 1 is the comfortable band; below 10^{-3} or above 10^{3} expect to pay in stiffness or in resolution.
- One knob at a time; follow the row of slide 13 for what else to touch.
- Stiffness estimate: $k = F_b/x_s$ with $F_b = \frac{1}{2}\rho\Delta x^{\dim-1}U^2$ or $\mu U\Delta x^{\dim-2}$; then multiply by 10–100 for a wall or a tether.
- Beams: $k'_{\mathrm{beam}} = EI/(\rho U^2 L^3)$ in 2D (L^4 in 3D); 10 is stiff, 0.1–1 bends, 0.01 folds.
- Four times the stiffness, half the `DT`; a thousandth of the density, thirty times the `DT`.
- Viscosity sets the pace, not the destination: scale `END_TIME` with μ; overshoot at low μ is physics.
- Change `L` or `N`: re-run the generator, check $\Delta s \approx \Delta x/2$.
- Set μ (and K) from the dimensionless target in the input file's own arithmetic, and sweep the dimensionless number.
- Two steps, a short run, one number compared with the baseline, a line in the notebook.

SUMMARY

1. The physical parameters are ρ, μ, the box and the speeds at the top of the input file and in the boundary blocks, and the stiffnesses in the generators; the examples set each in one place, and the file values of the stiffnesses are the generator's constants divided by Δs or Δs^3.
2. IBAMR has no units; the IB set is SI with syrup-like viscosities, the IBFE set is dimensionless with $\mu = 1/\mathrm{Re}$. Name U and L, compute Re; the method is easiest near 1 and the examples span 0.04–50.
3. Each parameter drags others with it: viscosity the run length, density and stiffness the time step, size and resolution the generator, speed the forces and hence the stiffnesses. The viscosity sweep (overdamped at $\mu = 100$, swinging at 10 and 1) and the beam sweep (bends ten times more at a tenth of EI) show the two most common cases.
4. Estimates: $k = F_b/x_s$ with the dynamic-pressure or Stokes force on one point, used as a floor; $k'_{\mathrm{beam}} = EI/(\rho U^2 L^3)$ in 2D with 10 stiff and 0.5 (the leaf) bending visibly; damping $c = 2\sqrt{km}$ with $m = \rho \Delta x^{\mathrm{dim}}$ for target points. All "really rough".
5. Procedure: dimensionless target, one change, the propagation row, two steps and a short run, one number against the baseline, a line in the sweep file.

Next, chapter 8b: non-dimensionalization and the dimensionless numbers (Reynolds, Strouhal, Womersley, Péclet, the stiffness and force coefficients), with the biological ranges and the 2015 lecture's derivations.

WHAT CHANGED SINCE THE OLDER COURSE NOTES

- The estimate formulas are kept word for word and then re-derived with units. Two corrections: the viscous point force is $\mu U \Delta x^{\dim - 2}$ (the 2017 slide's $\mu\, \Delta x\, U$ is the 3D form), and k'_{beam} in 2D uses L^3 (the 2017 slide's L^4 is the 3D form, as the 2015 and 2020 slides have it).
- "The IB method works best at $\mathrm{Re} = 1$" and "`MAX_LEVELS = 4` is a good default" are labelled rules of thumb and given their reasons.
- The 2013 `DT = 3.125e-2/NFINEST` line and the "10^{-5} per flap" advice are reconciled: one is a CFL guess, the other a stiffness guess, and the examples' steps are set by stiffness (slide 26).
- `viz_dump_interval` is stated as a step interval, not a count; the 2017 slide's `hier_data_IB3d` in a 2D file and the 2013 block name `IBStaggeredHierarchyIntegrator` are noted as obsolete.
- The parameter tables of all 13 examples, the Reynolds-number table, the propagation table, the stiffness-estimate table applied to four examples, the units table and the damping worked number are new; so are the two sweeps and their figures.
- Damping is placed where IBAMR has it (target points, η) rather than left generic.
- The 2017 MBI deck's three empty slides (4–6) hold no recoverable content: they are blank in the export, not image-only as the inventory guessed.

RECORDINGS (LISTED, NOT INCORPORATED)

The front matter's video list (chapter 0.1) has one recording that covers this material together with chapter 8b's:

Recording	Date	Course
`2-IntroDimensionlessParameters.mp4`	2018-02-11	MATH 769 (Lectures on FSI in Biology)

The 2015 MATH 769 Lecture 7 (parameters half) and the 2017 MBI deck have no recording in the list; the 2020 Zoom series went from boundary conditions (chapter 7) straight to target points and springs (chapter 9a).

REFERENCES

- The examples of this series, branch `master-tutorial`: the input files (parameters at the top), the generators (`generate_mesh2d.py`/`.m`, stiffness constants and the Δs scalings in their comments), and the READMEs (measured facts: run times, Reynolds numbers, DT limits, forces). https://github.com/fairyflies9/Using-IB-Software
- IBAMR 0.19.0: `include/ibamr/IBStandardInitializer.h` (the target-point damping column), `src/IB/IBStandardForceGen.cpp` (the force laws). https://github.com/IBAMR/IBAMR
- The runs behind slides 14–18: `wsl/final/run_ch8a_ib01.sh`, `run_ch8a_ib03.sh`; the figures: `tools/ch8a_figures.py` (reads `hier_data_IB2d/X.*`; chapter 11 explains the format).
- Damping: https://en.wikipedia.org/wiki/Damping (the 2017 slide's link).
- Chapter 8b for the dimensionless groups; chapter 5 for the stability of the explicit coupling; chapter 6 for the file scalings; chapter 10 for beam theory; chapter 16 for the symptoms of instability.
- Sources: *IBAMR – parameter changes* (MATH 769, February 5, 2013); *MATH 769 Lecture 7: Boundary Conditions and How to start changing things* (2015, second half); *4 – IBAMR Tutorial: Changing physical parameters wisely* (MBI, 2017; the 2018 public-folder copy has the same text); *MATH 769 Lecture 9: Changing Parameters* (2015, the estimate slides, which chapter 8b takes up in full).