



# TITAN HERO - THOR



THESE INSTRUCTIONS PROBABLY WORK FOR OTHER TITAN HERO TOYS AS WELL. CAREFULLY REMOVE THE BACKPACK FROM THE PACKAGING. THE GOAL WILL BE TO REPACKAGE IT WHEN DONE.





REMOVE THE FOUR SCREWS FROM THE BACK. YOU CAN LEAVE THE ONE FOR THE BATTERY COMPARTMENT IN PLACE. OPEN THE BACKPACK THEN REMOVE THESE TWO SCREWS ON THE SWITCH




USE AN 1/8" DRILL BIT TO DRILL A HOLE IN THE SIDE OF THE BACKPACK ABOUT HERE.

GENTLY LIFT OUT THE SWITCH. YOU MAY NEED TO GENTLY UNTANGLE THE WIRES.







PREPARE YOUR MONO JACK, TIN THE ENDS OF THE WIRE WITH A LITTLE SOLDER



BE SURE TO NOT DO WHAT I DID HERE. FEED YOUR WIRES THROUGH THE HOLE BEFORE YOU SOLDER TO THE SWITCH.



FASTEN THE SWITCH BACK IN PLACE AND THEN HOT GLUE THE WIRES DOWN.



BEFORE CLOSING THE BACKPACK BESIDE THIS CLIP IS STILL IN PLACE.