WB-2 r1 test pads: red = signal (net name), green = GND probe pad. Design frame mm, origin board bottom-left. RTN3 is never a probe ground.

