

| MNEMONIC        | DESCRIPTION   | ITEM/PANEL   | TML         |
|-----------------|---|--------------|-------------|
| B_VF_3F_S16_OFS | ON/OFF STATUS<br>SUPPLY FAN 16<br>3RD FLOOR         | Point no. 15 | 5PI0<br>5PL |
| B_VF_3F_S16_TRP | TRIP ALARM<br>SUPPLY FAN 16<br>3RD FLOOR            | Point no. 16 | 5PI1<br>5PC |
| B_VF_3F_S16_AMS | AUTO/MANUAL STATUS<br>SUPPLY FAN 16<br>3RD FLOOR    | Point no. 17 | 5PI3<br>5PB |
| B_WS_WS4_OFS    | ON/OFF STATUS<br>WTR.SCRUB.4<br>WATER SCRUBBER      | Point no. 18 | 5PI4<br>5PL |
| B_WS_WS4_TRP    | TRIP ALARM<br>WTR.SCRUB.4<br>WATER SCRUBBER         | Point no. 19 | 5PI6<br>5PL |
| B_WS_WS4_AMS    | AUTO/MANUAL STATUS<br>WTR.SCRUB.4<br>WATER SCRUBBER | Point no. 20 | 5PI7<br>5PL |