


3 = M33094

6 = M33097 7 = M33098

11 = M33304 12 = M33305 13 = M33306



1 = M33093 2 = M33424

4 = M33096 5 = M33099

8 = M33301 9 = M33302 10 = M33303

☒ EMERGENCY AREA LIGHT MAIN AISLE

▲ EMERGENCY OVER DOOR AREA LIGHT

⊗ EXIT IDENTIFIER

• FLOOR PROXIMITY LIGHTS (GALLEY , SEAT , PARTITION , LAVATORY)

■ EXIT SIGN (WITHOUT ARROW)

➡ EXIT SIGN (WITH ARROW)

■ EMERGENCY AREA LIGHT CROSS AISLE

◐ EXTERNAL SLIDE LIGHT

POUR DEPANNAGE VOIR

TN 33 0005 : Installation cables
"seat to seat"

Infos Techniques sous Lotus Notes
pour localisation EPSU dans OFAR et
OFCR