

Get a

Education (Https://Www.Giatecscientific.Com/Category/Education/)

Concrete Maturity Calculation Methods



BY GIATEC SCIENTIFIC INC.(HTTPS://WWW.GIATECSCIENTIFIC.COM/AUTHOR/ADMIN/)

JULY 19, 2019



Maturity is a concept that has existed since the 1950s. Since then, various equations have been proposed to measure the maturity of concrete. This chapter discusses three different methods that can be used in concrete maturity measurement: the temperature-time factor, the equivalent age, and the weighted maturity. All of the maturity methods are primarily dependent on the temperature history of the concrete but additional parameters related to concrete properties are also required to predict the in-place strength.

Temperature-Time Factor

The temperature-time factor (TTF) method, also known as the Nurse-Saul maturity function, was the first maturity method developed in the early 1950s, thanks to the work of Nurse[40], McIntosh[36] and Saul[42]. The goal of their work was to understand the effect of accelerated curing and the impact of different curing temperatures on the strength development of concrete. This method was standardized in 1987 by ASTM C1074. Today, the Nurse-Saul function is the most commonly used maturity method in North America because of its simplicity.

This approach takes into consideration that the maturity value is linearly dependent on temperature and can simply be represented by the area below the temperature curve, as graphically shown in Figure 4-1. In this approach, the area under the temperature curve is taken as the difference between the average recorded temperature and the datum temperature (T). The datum temperature is defined as the temperature at which the hydration of the cement stops, in other words, the temperature at which concrete stops developing strength. The Nurse- Saul equation is mathematically represented as follow:

(Eq. 4-1)

(hi

Get a

M(t) Maturity at age t(°C-hrs)

 T_a Maturity at age (°C)

 T_d Datum Temperature (°C)

 Δ_t Time interval(hrs)

Notes: Days can also be used as the units for the time interval

1°C-hrs = 1.8 °F-hrs

Most of the variables in Eq. 4–1 can easily be obtained without a complex analysis. "T" is simply obtained by the maturity monitoring system at a given time. "?t" is the default value given by the frequency of measurements taken by the maturity meter and is usually defined as 1 hour, 30 min, or less. The only variable that is unknown and needs to be calculated or estimated is the datum temperature. For a better accuracy, "T" can be calculated through laboratory testing as specified in ASTM C1074, but, in most cases, it can be defined as 0°C (32°F), -5°C (23°F) or -10°C (14°F).

ASTM C1074 states that: "for type I cement without admixture and a curing range between 0 to 40° C, the recommended datum temperature is 0° C". Originally, the datum temperature was defined as -10° C. However, studies have shown that the datum temperature for any given type of cement is within 0 to -10° C. Assuming a 0° C datum temperature in most cases is often considered a conservative approach, as it assumes that there is no strength gain if the temperature of the concrete falls below freezing point. Since concrete cannot lose strength as it hydrates, any given condition that would cause (Ta - Td)? 0 would result in no strength gain, M(t) = 0.




Figure 4-1: Temperature Time Factor Method

During the summer, when the temperature of the concrete is higher, assuming any datum temperature from 0 to -10°C for calibration will not necessarily have a significant impact on the results. However, in winter when the temperature can easily fall below freezing in certain regions, closer attention needs to be given when determining the actual datum temperature. In general, project specifications require that the temperature of the concrete remain above a certain temperature (>5°C) for a certain period of time during curing.

Example

Figure 4-2 and Figure 4-3 below show an example of maturity and strength calculations using different datum temperature (0°C, -5°C, -10°C). Each maturity calibration curve was developed by taking into account the different datum temperature to calculate maturity for the same strength data. The difference of those three mix calibrations are shown in Figure 4-2, where it is possible to observe that any difference is simply a shift to the right because the maturity corresponding to each strength gets larger as the datum temperature decreases (more area under the temperature curve). Given a temperature curve that falls below freezing point, it is possible to observe how the maturity and strength value can vary for different datum temperatures (Figure 3).







Figure 4-2: Mix Calibration (example)







c) Example: Strength Calculation Figure 4-3: Effect of datum temperature on the maturity and strength calculations

4.1.1. Datum Temperature Calculation

As mentioned above, "Ta" can be defined as 0° C for simplicity (other temperatures also used in the industry are -5° C and -10° C). Nevertheless, it is possible to determine the datum temperature by following the steps provided in ASTM C1074 A1, which are summarized below.

The datum temperature procedure consists of making a minimum of 54 mortar cubes (ASTM C109) representing the concrete mix. The cubes should be divided into 3 different sets; each containing 18 cubes. Each of these three sets will be cured at a different temperature. The temperature chosen for curing should be based on the maximum and minimum expected curing temperature as well as an average temperature of the jobsite. Three cubes are then broken at six different times to obtain the strength of the concrete (ASTM C109).

4.1.1.1. Rate Constant (K-value)

To calculate the datum temperature, the k-value must be determined for each curing condition. The k-value is the reaction rate constant which is dependent on time and temperature. It represents the rate of the chemical reaction, in this case, the cement hydration reaction which represents the strength development in concrete.

There were originally 3 approaches suggested by ASTM C1074 to determine the k-value, in the last revision of ASTM C1074 only one approach was kept as the standard procedure to determine the reaction rate k.

The k-values can be solved using a computer program for Eq. 4-2. In this equation, in addition to the rate constant, "to" and "Su" are also unknowns that need to be solved, ASTM C1074- 17 provides an example of calculation and spreadsheet set up to solve for those parameters.

$$S = S_u \frac{k(t - t_0)}{1 + k(t - t_0)}$$
 (Eq. 4-2)

Where:

S Average compressive strength of the teswt cube at time $\,t\,$

t Teat age

Su Limiting strength

 $t_{\scriptscriptstyle 0}$ Age when strength development is assumed to begin

k Rate constant

Once the k-value has been calculated for each curing temperature, the reciprocal of k vs. curing temperature can be plotted. By fitting a linear interpolation, the intersection with the x-axis represents the datum temperature (Figure 4-4).

0

Figure 4-4: Datum Temperature

15

Temperature,

10

20

25

 $^{\circ}C$

30

35

4.2. Equivalent Age

Even though the temperature-time factor equation is widely used and accepted worldwide, the linear approach to determine maturity is not accurate for all curing conditions, especially at temperatures outside the range of $0-40^{\circ}$ C. To mitigate this effect, in 1977 Freiesleben-Hansen and Pedersen proposed a more accurate equation in which the maturity is exponentially dependent on temperature. This maturity method is known as the equivalent age method and is based on the Arrhenius equation. This approach is standardized in most codes including ASTM C1074 and European standards (European countries typically allow the Arrhenius method instead of the Nurse-Saul). Despite the fact that this approach is a bit more complex than the temperature-time factor, if the assumptions are done properly, it can lead to a more accurate prediction of the in-place strength. The equivalent age can be calculated using Eq. 4-3.

$$t_e = \sum_{c} e^{-Q\left(\frac{1}{T_o} - \frac{1}{T}\right)} \Delta t$$
 (Eq. 4-3)

Where:

 t_e Equivalent age at T_s (hrs. or days)

 T_a Average temperature during Δ_t (Kelvin)

Ts Specified temperature (Kelvin)

Q Activation energy divided by gas constant (Kelvin)

 Δ_t Time interval (hrs. or days)

Similar to the Nurse–Saul equation, "Ts" and "?t" can be obtained from the maturity meter. "Ts" represents a specified temperature and is usually defined as 23°C in North America and 20°C in Europe. The activation energy divided by gas constant must be determined experimentally using very similar steps as shown in the calculation of datum temperature. ASTM C1074 also proposes a standard value where Q can be defined as 5000 K for type I cement without admixtures.

To determine "Q", the k-value must be obtained following the same steps presented in Section 4.1.1.1. By plotting the natural logarithm of k vs. the reciprocal of the curing temperature (in Kelvin), the negative of the linear slope represents "Q".

4.3 Weighted Maturity

The third method proposed to calculate maturity is the weighted maturity, which was developed in the 1970 Papadakis and Bresson and later modified by de Vree in 1979. This method is not typically used in North America as it is not standardized by ASTM C1074. However, it is currently standardized in the Netherlands (NEN5790) and accepted in Europe.

Would you like us to send a few more articles like this one via email?

(h

Get a

(Eq. 4-4)

The general approach of the weighted maturity method is described in Eq. 4-4. This equation is very similar to the Nurse-Saul equation as "tkTk" represents the area under the temperature curve while the "Cnk" represents a correction factor. (https://www.giatecscientific.com)

(hi

Get a

$$Mw = \sum t_k - T_k C^{n_k}$$

Where

Mw Weighted maturity (°C-hrs)

hardening time of concrete (hrs)

hardening temperature interval

C-value of cement

temperature-dependent parameter for T_k

Using this equation is, however, not practical as the "nk" factor is temperature-dependent. A discontinuous function to simplify the calculation of the proposed linear equation (Eq. 4-5), can be used in determining the n parameter. Therefore, the weighted maturity equation can be rewritten in a simpler form by taking the integral of "Cnk" from datum temperature (-10°C) to average temperature. The weighted maturity equation can now be defined as Eq. 4-6 with a continuous n function. It is graphically represented in Figure 4-5.

$$n = 0.1T-1.245$$
 (Eq. 4-5)

$$M_{w} = \sum_{0}^{t} \frac{10(C^{0.17-1.245} - C^{-1.245})}{lnC} \Delta t$$
 (Eq. 4-6)

 M_w Weighted maturity (°C-hrs)

 $T\quad \hbox{Average temperature during the time interval}$

C C-value of cement

Time interval (hrs)

The C-value is a cement-specific value which indicates the influence of the sensitivity of the cement to temperature. The C-value can be obtained directly from the cement producer or through the standardized procedure in NEN 5790. The value typically varies from 1.25 to 1.75.




Figure 4-5: Weighted Maturity



(https://info.giatecscientific.com/concrete-maturity-ebook)

**Editor's Note: This post was originally published On July 19, 2019 and has been updated for accuracy and comprehensiveness.



(https://www.giatecscientific.com/author/admin/)

Giatec Scientific Inc.

(https://www.giatecscientific.com/author/admin/) Ottawa-based company, Giatec Scientific Inc., is revolutionizing the construction industry by bringing smart concrete testing technologies and real-time data collection to the forefront of every jobsite. Learn more about Giatec Scientific Inc Mission and Core Values (/company/about-us/), or read more about Giatec Scientific's Line of Products (/products/). We are bringing longoverdue change to a conservative industry by addressing the current challenges in concrete testing, analysis, design, and production. Click the following links to learn more about Giatec Scientific's Management Team (/company/management-team/) and Research and Development Team (/our-researchdevelopment-team/).

View All Articles (https://www.giatecscientific.com/author/admin/)

2 Responses



llango says: September 7, 2020 at 8:12 am (https://www.giatecscientific.com/education/concrete-maturity-calculation-methods/#comment-1285)

Concrete monitoring system from production till completion including maturity calculator, temperature monitoring, strength monitoring, surface finish monitoring, uniform color monitoring with the integration of software tools is required

Hi,

In one of our project we follow this specification, can u guide me what is the equipements required to fullfill the needs.

Would you like us to send a few more articles like this one via email?



Alicia Hearns

September 16, 2020 at 5:14 pm (https://www.giatecscientific.com/education/concrete-maturity-calculation-methods/#comment-1451)

(h

Get a



Hi llango, thank you for your comment. To monitor concrete maturity on your jobsite all you need is a concrete maturity sensor, like SmartRock. Once installed on the rebar, it gives you strength/maturity on your mobile device. No other equipment is needed except for the sensors and your phone. Read more about SmartRock here https://www.giatecscientific.com/products/concrete-sensors/smartrock-maturity-meter/

Get a

(h

(https://www.giatecscientific.com/products/concrete-sensors/smartrock-maturity-meter/)

Reply

Leave a Reply

| Your email address will not be published. Required fields are marked * |
|--|
| Comment |
| |
| |
| |
| |
| |
| |
| Name * |
| |
| Email * |
| |
| |
| Website |
| |
| $\hfill \square$ Save my name, email, and website in this browser for the next time I comment. |

Related Articles



Post Comment

(https://www.giatecscientific.com/general/measuring-relativehumidity-with-embedded-with-bluerock-sensors-in-concrete/)



(https://www.giatecscientific.com/education/use-these-tech-toolsfor-more-efficient-cold-weather-concreting/)

Measuring Relative Humidity With

GIAET Bedded BlueRock Sensors In Concrete

(https://www.pittps://www.giatecscientific.com/general/
relative-humidity-with-embedded-withbluerock-sensors-in-concrete/)

JANUARY 31, 2022

During construction, the internal relative humidity (RH) of concrete plays a significant role in the progression of work. Especially in slabs-on-ground or suspended slabs that are to receive moisture-sensitive flooring materials, professionals often rely on experience to understand the drying time of field concrete. Flooring materials such as sheet rubber, epoxy coatings, vinyl composition tile, sheet vinyl, carpet, athletic flooring, laminates, and hardwood can suffer issues such as delamination, blistering, mold growth, and other similar problems due to exposure to moisture and high RH conditions...

Use These Tech Tools for More Efficient Cold Weather Concreting (https://www.giatecscientific.com/educatio these-tech-tools-for-more-efficient-coldweather-concreting/)

NOVEMBER 19, 2021

Let's dive into our sensors in detail. SmartRock Sensors: SmartRock is a wireless concrete sensor designed for temperature and strength monitoring with the ability to record real-time temperature data for every 15-minute interval for 2 months and comes with remote-monitoring capabilities. It is fast, simple, designed rugged and waterproof, and can be activated and installed hassle-free. The sensor contains two points of temperature measurements located in the sensor cable and body, and comes with an extended temperature cable and probe for mass concrete purposes. This sensor can measure temperature as low as -22°F (-30°C) with an accuracy range of ±1°C. The SmartRock sensor, containing a black box, a cable, and



(https://www.giatecscientific.com/education/everything-youneed-to-know-about-pouring-concrete-in-winter/)

Everything You Need to Know About Pouring Concrete in Winter (https://www.giatecscientific.com/educatio you-need-to-know-about-pouringconcrete-in-winter/)

NOVEMBER 19, 2021

Winter is coming! Worried about the cold weather concreting that comes with it in the construction industry? We've got it covered with Giatec's SmartRock sensors. Keep reading to learn more. The temperature is dropping, the days start to get shorter, and frost covers the ground. While it may be exciting to imagine a festive winter season, that is not what comes to mind when working in the construction industry. Especially, when you have a project to complete, a schedule to maintain, and a desired concrete temperature and strength to achieve; the pressure is on when dealing with factors like freezing of concrete at an early age, rapid temperature changes, all while trying...

Would you like us to send a few more articles like this one via



(h



(/)

(https://www?ejateiastleinsstreecomprete industry by bringing smart testing technologies and IoT solutions to the forefront of every jobsite.

(ht Get a

Global Headquarters: 245 Menten Place, Suite 300 (htt ps:/ POttawa, Ontario Canada K2H 9E8 /w ube win ps:/ .co sta /w m/c gra ww. han m.c fac nel/ om ebo ra.c om /pr ofil om /c han nel/ om UC pan GA y/gi 3DI ate co m/ Gia /gia ok.c tec_ om scie /gia ntifi tec/ SEIROPUCTS LEGAL SUPPORT COMPANY ntifi fq9J en) (/products/concrete-About(/company/about-us/) (/legal-privacy/privacy-Contact(/contact/) Privacy policy/) SmartRock ®sensors/smartrock-Careers(/careers/) F.A.Q.(/faq/) maturity-meter/) (/legal-Disclaimer privacy/disclaimer/) (/company/leadership-team/) Dealer Portal(/portal/dealers/) (/products/concrete-SmartRock ®sensors/smartrock-plus-Copyright(/legal-privacy/copyright/) for-ready-mix-Board of (/company/board-ofproducers/) Directors (/terms-anddirectors) Terms and Conditions conditions/) (/products/concrete-(/research-and-Research & BlueRock™. Development development/) ' humidity-temperature-In the Media(/press/) meter/) Blog(/blog/) (/products/concrete-ndtiCOR ®devices/icor-rebar-corrosionrate/) (/products/concrete-ndt-XCell™devices/xcell-half-cellcorrosion-potential/) (/products/concrete-ndt-Perma™devices/perma-rapidchloride-permeability/) (/products/concrete-ndt-RCON™ devices/rcon-bulkresistivity/) (/products/concrete-ndt-Surf™devices/surf-surfaceresistivity/) CONTACT Toll-Free: +1 (877) 497-6278 (tel:+1 (877) 497-6278) sales@giatecscientific.com (mailto:sales@giatecscientific.com) support@giatecscientific.com (mailto:support@giatecscientific.com) NEWSLETTER SIGNUP Email Enter your Email * By clicking submit, you consent to Giatec's Privacy Policy. (https://www.giatecscientific.com/legal-privacy/) Submit

Would you like us to send a few more articles like this one via email?

©2022 Giatec Scientific Inc. All Rights Reserved. SmartRock is a registered trademark of Giatec Scientific Inc., the U.S. registration no.

5,930,038.