

FUNCTION DESCRIPTION

Functional Design Specification Central Wind Farm Controller

Windpark Zeewolde

Discipline Name Uitvoeringsontwerp

Prepared

20-12-2019

10-03-2020

ABB-PGGI

3.3.8 CWFC Central Wind

Farm Controller

Prepared by

Karsten Schoenmaker

Approved By Eric Niekerk Ugur Cicek

Confidential

Document Kind

Customer Doc No.#

VWHV-UO-3.3.8.CWFC-OWN-E0014032-E51-FE1-000002

Purpose of submission

For Review and Approval

Purpose of issue First Issue

VWHV-UO-3.3.8.CWFC-OWN-E0014032-E51-FE1-000002

guage

1/23

We reserve all rights in this document and in the information contained therein. Reproduction, use or disclosure to third parties without expressed authority is strictly forbidden. © ABB Power Grids The Netherlands B.V. 2020



Contents

1	General	6
	1.1 Scope of document	6
	1.2 Scope of design	6
	1.3 Conventions of the sign of active and reactive power	6
2	System Architecture	7
	2.1 Wind Farm General overview	7
	2.2 Central Wind Farm Controller Architecture.	8
	2.3 Active Power Control	9
	2.4 Reactive Power Control Modes	10
	2.4.1 Voltage Control Mode sub mode 1	10
	2.4.2 Voltage Control mode submode 2	13
	2.4.3 Reactive Power Control Mode	15
	2.4.4 Powerfactor Control Mode	16
3	Hardware setup	17
	3.1 19" Swing frame rack for RTU 560	17
	3.2 Communication units	17
	3.3 Power supply unit	18
	3.4 Component overview	19
4	· ····································	20
	4.1 Setting the Setpoint Procedure	20
	4.2 Reactive Power Control Mode Selection	20
	4.3 PPA access	20
	4.4 Local/Remote	20
	4.5 Communication with LWFC is down.	20
_	4.6 Shutting down the LWFC	20
5	HMI	21
6	References	22
7	Tabel of Figures	23

INTERNAL STATUS	SECURITY LEVEL	DOCUMENT ID.	REV.	LANG.	PAGE
[Status]		VWHV-UO-3.3.8.CWFC-OWN- E0014032-E51-FE1-000002	A	en	2/23



Abbreviations

A Ampere CU Copper

CWFC Central Wind Farm Controller
GIS Gas Insulated Switchgear
HMI Human Machine Interface
IED Intelligent Electronic Device

kV Kilo Volt kA Kilo Ampère

LWFC Local Wind Farm Controller

MV Medium Voltage
N/A Not Applicable
P&C Protection and Control
PCC Point of Common Coupling
SA Substation Automation
SAT Site Acceptance Test

SCADA Supervisory Control and Data Acquisition

V Volt

WEC Wind Energy Converter WTG Wind Turbine Generator

Related documents

Document number Title

SOC_11-175 D4-Wind_Farm_Connection_Requirements_5_9

180507 F1-WPZ Functional Requirements Wind Farm Controller 1.0

081116 D5-Compliance Wind Farms V 4.2 Clean 181116 D6-Data Exchange Wind Farms V 5.3

180513 F2-WPZ Functional Scheme power management 1.0

E0014032-E03-FP1-000002 I/O list CWFC

Revisions

Rev. Ind.	Page (P) Chapter (C)	Description	Date DeptInit.
Α	All	First issue	11-03-2020/KSc

Approval

Approved by	Role	Date	Visa	
Eric Niekerk	Project manager	10-03-2020		
Ugur Cicek	Project Engineer	10-03-2020		
Karsten Schoenmaker	Author	10-03-2020		

Distribution

Company	Department	Person	Date	Сору	
Vogelweg HV station B.V.				1	
ABB Power Grids The Netherlands B.V.	PGGA	Eric Niekerk	10-03-2020	1	
		Karsten Schoenmaker	10-03-2020	1	
		Document control	10-03-2020	1	

Vogelweg HV station B.V.

Visit Address Landauer 2 3897 AB Zeewolde Postal Address

ABB Power Grids The Netherlands B.V.

INTERNAL STATUS	SECURITY LEVEL	DOCUMENT ID.	REV.	LANG.	PAGE
[Status]	Confidential	VWHV-UO-3.3.8.CWFC-O	WN- A	en	3/23
		F0014032-F51-FF1-00000	, ,	Cit	'



Visit Address George Hintzenweg 81 3068 AX Rotterdam Postal Address P.O. Box 301 3000 AH Rotterdam

INTERNAL STATUS

SECURITY LEVEL

DOCUMENT ID.

REV.

LANG.
PAGE

(Status)

Confidential

VWHV-UO-3.3.8.CWFC-OWNF0014032-F51-F61-000002



Introduction

This Functional Design Specification describes the soft- and hardware configuration of the Central Wind Farm Controller (CWFC) intended for Wind Farm Zeewolde. The purpose of the CWFC is to ensure grid compliance by coordinating the efforts of six Local Wind Farm Controllers (LWFC) by acting as a master controller. The main function will be controlling the active & reactive power at the Point of Common Coupling (PCC). The CWFC will also function as a gateway in providing information from the LWFC's to the Substation SCADA system.

INTERNAL STATUS	SECURITY LEVEL	DOCUMENT ID.	REV.	LANG.	PAGE
[Status]	Confidential	VWHV-UO-3.3.8.CWFC-OWN-	A	en	5/23
		E0014032-E51-FE1-000002			



1 General

1.1 Scope of document

The main function of this design specification is to provide a clear view, how we envision the central wind farm controller as part of the wind farm.

This document will serve as a continued working- and discussion basis for the actual realization of the CWFC.

1.2 Scope of design

The central wind farm controller will be in charge of maintaining grid compliance. To achieve grid compliance the Windfarm must comply with the TSO regulations as specified in SOC 11-175. The PCC will be the reference point for determining Grid Compliance.

To achieve Grid Compliance the CWFC will be able to regulate the active and reactive power provided by the WTG's. The CWFC will also be able to coordinate the efforts of multiple LWFC's in order to manage the active and reactive power. Design will be according to requirement 448 [1].

1.3 Conventions of the sign of active and reactive power




Figure 1 Power Sign Convention

INTERNAL STATUS	SECURITY LEVEL	DOCUMENT ID.	REV.	LANG.	PAGE
[Status]	Confidential	VWHV-UO-3.3.8.CWFC-OWN-	A	en	6/23
		E0014032-E51-FE1-000002			



2 System Architecture

2.1 Wind Farm General overview

The CWFC will communicate with all involved parties over the IEC60870-5-104, as shown in the overview below.




Figure 2 System Architecture Overview

The PPA will access the WTG SCADA directly with regards to monitoring data and performing curtailment. As discussed on 8-1-2020. Proposed by Outsmart.

Tennet B.V. will no longer connect directly to the CWFC. Outsmart will communicate with Tennet directly via phone, when this is necessary. The CWFC will be configured in a way that minimal adjustments are needed in case Tennet will be connected to the CWFC directly according to [3]. As discussed on 21-1-2020.

INTERNAL STATUS	SECURITY LEVEL	DOCUMENT ID.	REV.	LANG.	PAGE
[Status]	Confidential	VWHV-UO-3.3.8.CWFC-OWN-	A	en	7/23
		E0014032-E51-FE1-000002			



2.2 Central Wind Farm Controller Architecture.

This paragraph shows the general architecture of the Central Wind Farm Controller. The systems connected to the CWFC are the LWFC and the System Operator.

The TSO will not be connected but preparations have to be made for the TSO to be able to pass on setpoint requests, send/receive data routed through the gateway function.

The System Operator will have the ability to pass on setpoint requests, select new Control modes and send/receive data routed through the gateway function.

The Local Wind Farm Controllers will receive setpoints from the CWFC and provide information regarding the available P & Q.




Figure 3 CWFC Architecture Layout

- Setpoint selection
- Reactive Power Control Mode Selection
- Power Divider
- Data concentrator / Gateway LWFC->CWFC

INTERNAL STATUS	SECURITY LEVEL	DOCUMENT ID.	REV.	LANG.	PAGE
[Status]	Confidential	VWHV-UO-3.3.8.CWFC-OWN-	A	en	8/23
		E0014032-E51-FE1-000002			



2.3 Active Power Control

Active Power Control will regulate the active power from the WEC's to the Grid. Generally the maximum available power will be used as setpoint. It will also be possible to enter a setpoint. Also called "Absolute Production Constraint". As requested in [2] subsubparagraph 4.2.2.2

The P divider will dynamically calculate the setpoints for the LWFC.




Figure 4 Diagram active Power Control

If P at the PCC is equal to the "P setpoint" or "P max" then the P total measured (LWFC's) should be equal to "P setpoint" or "P max" respectively. This applies when the system is in a settled state.

The local wind farm controller will divide the supplied setpoint into setpoints to the WEC units. The WEC unit setpoint must be calculated in a way that it will compensate for the "Line Losses" and "Phase Rotation" caused by the cables in order to be able to match the values measured by the LWFC to the received setpoint.

Setpoint Ramp & Gradient constraint will be handled via the LWFC.

	LANG.	PAGE
[Status] Confidential VWHV-UO-3.3.8.CWFC-OWN- E0014032-E51-FE1-000002	en	9/23



2.4 Reactive Power Control Modes

The CWFC will have three control modes for regulating the reactive power at the Grid Connection Point. As requested in [2] subsubparagraph 4.2.2.1

- Voltage Control Mode (sub mode 1 & 2)
- Power Factor Control
- Reactive Power Control

The next paragraphs will give an overview how the reactive power control modes will be implemented.

2.4.1 Voltage Control Mode sub mode 1

Voltage control (U-control), characterized by Voltage Droop, Set Point Voltage, with additional functionality to periodically check and if necessary adjust locally the Set Point Voltage to bring the Reactive Power Exchange at the PCC to the Reference Steady State Reactive Power Exchange.

During normal operation of Voltage Control Mode sub mode 1 the system will measure the voltage at the PCC and compare this with the U setpoint. If the value deviates, reactive power exchange will be increased or decreased according to the voltage droop settings.

While the Voltage control mode is active there will be periodic checks if the Voltage and Reactive Power at PCC exceed dynamic threshold or disturbance threshold.




Figure 5 Chart stating ΔQ or ΔU over time

Exceeding the "Dynamic Upper/lower Threshold will trigger the "Usetpoint set" mode and it will set Usetpoint to match the Upcc at the point where Qpcc = Qref.

INTERNAL STATUS	SECURITY LEVEL	DOCUMENT ID.	REV.	LANG.	PAGE
[Status]	I .	VWHV-UO-3.3.8.CWFC-OWN-	A	en	10/23
		E0014032-E51-FE1-000002			



The CWFC will have the ability to determine locally the Set Point Voltage based on the Agreed Steady State Reactive Power Exchange at the PCC indicated by the Reference Steady State Reactive Power Exchange. The CWFC must have the ability to process the Reference Steady State Reactive Power Exchange indicated by the Network Operator.

When the Disturbance threshold is surpassed the system will go into disturbance mode. During this mode the Reactive power will be held for 15minutes before returning to normal operations.

During a voltage drop/rise larger than the droop percentage the maximum Q available will be injected/absorbed.

If Q at the PCC is equal to the "Q ref" then the Qtotal measured by the LWFC should be equal to "Qoffset". This applies when the system is in a settled state.

The local wind farm controller will divide the supplied setpoint into setpoints to the WEC units. The WEC unit setpoint must be calculated in a way that it will compensate for the "Line Losses" and "Phase Rotation" caused by the cables in order to be able to match the values measured by the LWFC to the received setpoint.

INTERNAL STATUS	SECURITY LEVEL	DOCUMENT ID.	REV.	LANG.	PAGE
[Status]		VWHV-UO-3.3.8.CWFC-OWN- E0014032-E51-FE1-000002	A	en	11/23



2.4.1.1 Block Diagram Voltage Droop Control Mode 1




Figure 6 Block diagram voltage power control mode1

$$Qsetpoint\ LWFCx = \left(\alpha * \left(\frac{Usetpoint - Upcc}{Usetpoint}\right) * Qmax + Qoffset\right)\ RX$$

The alpha coefficient represents the Droop percentage.

- 25 = 4%
- 18 = 5.6%
- 10 = 10%

The Q divider will use static ratio's. RX is the factor that divides the calculated Q over the LWFC output.

The Overflow Detection and Redistribution Function will detect the event where a Qsetpoint will become bigger than the Q available per LWFC. The amount of Q unaccounted for will be redistributed over the other LWFC's that still have an unaccounted amount of Q available.

INTERNAL STATUS	SECURITY LEVEL	DOCUMENT ID.	REV.	LANG.	PAGE
[Status]	Confidential	VWHV-UO-3.3.8.CWFC-OWN- E0014032-E51-FE1-000002	A	en	12/23



2.4.2 Voltage Control mode submode 2

Voltage control (U-control), characterized by Voltage Droop, Set Point Voltage

The CWFC must have the ability to process the Set Point Voltage indicated by the Network Operator. So it will periodically check if there is a new setpoint given.

The Voltage Control mode Sub mode 1 will measure the voltage at the PCC and compare this with the Voltage setpoint. If the value deviates, reactive power exchange will be increased or decreased according to the voltage droop settings.

There is no automatic "Setpoint Set Mode" or "Disturbance" mode.

During a voltage drop/rise larger than the droop percentage the maximum Q available will be injected/absorbed.

2.4.2.1 Block Diagram Voltage Droop Control Mode 2




Figure 7 Block diagram voltage power control mode2

$$Qsetpoint \ LWFCx = \left(\ \alpha * \left(\frac{Usetpoint - Upcc}{Usetpoint} \right) * Qmax + Qoffset \ \right) \ RX$$

The alpha coëfficient represents the Droop percentage.

- 25 = 4%
- 18 = 5.6%
- 10 = 10%

The Q divider will use static ratio's. RX is the factor that divides the calculated Q over the LWFC output.

INTERNAL STATUS	SECURITY LEVEL	DOCUMENT ID.	REV.	LANG.	PAGE
[Status]	Confidential	VWHV-UO-3.3.8.CWFC-OWN-	A	en	13/23
		E0014032-E51-FE1-000002			



The Overflow Detection and Redistribution Function will detect the event where a Qsetpoint will become bigger than the Q available per LWFC. The amount of Q unaccounted for will be redistributed over the other LWFC's that still have an unaccounted amount of Q available.

INTERNAL STATUS	SECURITY LEVEL	DOCUMENT ID.	REV.	LANG.	PAGE
[Status]	Confidential	VWHV-UO-3.3.8.CWFC-OWN-	A	en	14/23
		E0014032-E51-FE1-000002			



2.4.3 Reactive Power Control Mode

This paragraph will provide an overview how the "Reactive Power Control Mode" is implemented in the CWFC. Beginning with this block diagram giving a schematic overview of the control mode.

The CWFC will measure the Reactive Power Q at the PCC. It will then be compared with the Q setpoint and corrective action will be taken by increasing or decreasing the reactive power per Local Wind Farm Controller.

2.4.3.1 Block Diagram Reactive Power Control Mode




Figure 8 Block diagram reactive power control

INTERNAL STATUS	SECURITY LEVEL	DOCUMENT ID.	REV.	LANG.	PAGE
[Status]		VWHV-UO-3.3.8.CWFC-OWN- E0014032-E51-FE1-000002	A	en	15/23



2.4.4 Powerfactor Control Mode

This paragraph will provide an overview how the "Power Factor Control Mode" is implemented in the CWFC. Beginning with this block diagram giving a schematic overview of the control mode.

First step will be to determine the PF at PCC then it will be compare to the PF setpoint. The difference will be added/subtracted from the total PF calculated from the LWFC measurements. From this value the new Reactive Power Q will be determined.

2.4.4.1 Block Diagram Power Factor Control Mode




Figure 9 Block diagram power factor control

INTERNAL STATUS	SECURITY LEVEL	DOCUMENT ID.	REV.	LANG.	PAGE
[Status]		VWHV-UO-3.3.8.CWFC-OWN-	A	en	16/23
		E0014032-E51-FE1-000002			



3 Hardware setup

The hardware for the central wind farm controller will exist of a remote terminal unit of the type RTU560 that is fitted with PLC functionality. In this chapter we will elaborate on the proposed hardware.

3.1 19" Swing frame rack for RTU 560

The RTU560 modules will be places in a 19" Rack 560SFR02. The rack has sufficient slots available and gives the opportunity to expand the system in the future.




Figure 10 560SRF02 Swing rack frame

3.2 Communication units

This RTU560 module of type 560CMR01 will be used for communication purposes. The ethernet connections will be setup via this unit. Two ethernet connection are available per unit. Four units are accounted for in this design.

One of the four units will also have the PLC License to run the CWFC application.

INTERNAL STATUS	SECURITY LEVEL	DOCUMENT ID.	REV.	LANG.	PAGE
[Status]	Confidential	VWHV-UO-3.3.8.CWFC-OWN-	A	en	17/23
		E0014032-E51-FE1-000002			





Figure 11 560CMR01 Communications card

3.3 Power supply unit

This RTU560 module of type 560PSU02 will be used to power the RTU560. The input range is 48 ... 220 V DC (-20%... +20%). The output voltages are 5 and 48 VDC.



Figure 12 560PSU02 Power supply unit

INTERNAL STATUS	SECURITY LEVEL	DOCUMENT ID.	REV.	LANG.	PAGE
[Status]	Confidential	VWHV-UO-3.3.8.CWFC-OWN- E0014032-E51-FE1-000002	A	en	18/23



3.4 Component overview

Item	Quantity	Part Number	Description
1	1	560SFR02 R0001	19" Rack Frame (Swing)
2	1	560BCU05R0001	Bus Connection Unit
3	4	560CMR01 R0001	Communication Unit
4	3		Rel. 12 Basic license open DP, SD
5	1		Rel. 12 HMI/PLC/Archives license open DP, SD
6	1	560PSU02 R0001	Power Supply Unit
7	15	560FPR01 R1002	Blanc cover plate
8	2	560BCU05R1002	BCU connectors

Tabel 1 Component Overview

INTERNAL STATUS	SECURITY LEVEL	DOCUMENT ID.	REV.	LANG.	PAGE
[Status]		VWHV-UO-3.3.8.CWFC-OWN- E0014032-E51-FE1-000002	A	en	19/23



4 Functionality

4.1 Setting the Setpoint Procedure

A setpoint is the level of system output which is desired. The regulator will steer the process output towards this value. The type of setpoint is determined by the type of "Reactive Power Control Mode". The setpoint is entered via the CWFC "Configuration and Operation" menu.

When a new setpoint has been submitted, it will be checked for validity. When found to be valid, it will be implemented. Upon rejection, the user will be notified that the given setpoint is invalid.

nr.	Reactive Power Control Mode	Input	Remarks	Disturbance mode*
1	Voltage Control submode 1	Qref, Droop %	Automatic determinaton Uset = Upcc at Qpcc == Qref	yes
2	Voltage Control submode V2	Uset, Droop %		no
3	Power Factor Control	Cosine Phi		no
4	Reactive Power Control	Qset		no

Disturbance mode: CWFC will hold reactive power for 15min.

Tabel 2 Input Overview per Reactive power control mode

4.2 Reactive Power Control Mode Selection

It will be possible to select another "Reactive Power Control Mode" in the CWFC "Configuration and Operation" menu.

4.3 PPA access

PPA's will connect to the Enercon SCADA for monitoring data and Curtailment. They will no longer connect directly to the CWFC. As stated in req. 449 [1].

4.4 Local/Remote

Local/Remote functionality is available with regards to changing setpoint or reactive power control modes.

4.5 Communication with LWFC is down.

If the connection between CWFC and LWFC is lost. The standard course of action should be that het LWFC is stopped and the associated WEC units are stopped. Due to the fact that it is not possible to monitor/regulate the LWFC and associated WEC's.

4.6 Shutting down the LWFC

The CWFC will be able to generate a stop signal to all or some LWFC.

INTERNAL STATUS	SECURITY LEVEL	DOCUMENT ID.	REV.	LANG.	PAGE
[Status]		VWHV-UO-3.3.8.CWFC-OWN-	A	en	20/23
		E0014032-E51-FE1-000002			



5 HMI

Will be made available during the "Detail Design Phase".

•	INTERNAL STATUS	SECURITY LEVEL	DOCUMENT ID.	REV.	LANG.	PAGE
	[Status]	Confidential	VWHV-UO-3.3.8.CWFC-OWN-	A	en	21/23
			E0014032-E51-FE1-000002			



6 References

- [1] Windpark Zeewolde B.V., "Vraagspecificatie deel 1 Technische Eisen 1.2," 2018.
- [2] Windpark Zeewolde B.V., "Functional requirements Central Wind Farm Controller 1.0," 2018.
- [3] Tennet B.V., "Data Exchange Wind Farms 5.3," 2016.

INTERNAL STATUS	SECURITY LEVEL	DOCUMENT ID.	REV.	LANG.	PAGE
[Status]		VWHV-UO-3.3.8.CWFC-OWN- E0014032-E51-FE1-000002	A	en	22/23



7 Tabel of Figures

Figure 1 Power Sign Convention	6
Figure 2 System Architecture Overview	7
FIGURE 3 CWFC ARCHITECTURE LAYOUT	8
Figure 4 Diagram active Power Control	9
Figure 5 Chart stating ΔQ or ΔU over time	10
FIGURE 6 BLOCK DIAGRAM VOLTAGE POWER CONTROL MODE1	12
FIGURE 7 BLOCK DIAGRAM VOLTAGE POWER CONTROL MODE2	13
FIGURE 8 BLOCK DIAGRAM REACTIVE POWER CONTROL	15
FIGURE 9 BLOCK DIAGRAM POWER FACTOR CONTROL	16
FIGURE 10 560SRF02 SWING RACK FRAME	17
FIGURE 11 560CMR01 COMMUNICATIONS CARD	18
FIGURE 12 560PSU02 POWER SUPPLY UNIT	18

•	INTERNAL STATUS	SECURITY LEVEL	DOCUMENT ID.	REV.	LANG.	PAGE
	[Status]	Confidential	VWHV-UO-3.3.8.CWFC-OWN-	A	en	23/23
			E0014032-E51-FE1-000002			